

[Manuals.plus](#) /

> [BoxWave](#) /

> BoxWave ClearTouch Anti-Glare Screen Protector for Newland SP830 User Manual

BoxWave SP830

BoxWave ClearTouch Anti-Glare Screen Protector for Newland SP830

User Manual

INTRODUCTION

The BoxWave ClearTouch Anti-Glare Screen Protector is designed to protect the display of your Newland SP830 device. This matte film reduces glare, resists fingerprints, and provides a smooth, paper-like surface for enhanced usability. It is precision-cut to ensure a perfect fit and maintain full functionality of your device's screen.

PACKAGE CONTENTS

Each package of the BoxWave ClearTouch Anti-Glare Screen Protector for Newland SP830 includes the following items:

- Two (2) ClearTouch Anti-Glare Screen Protectors
- One (1) Applicator Card
- One (1) Microfiber Cleaning Cloth
- One (1) Dust Removing Sticker





Image: Contents of the BoxWave ClearTouch Anti-Glare Screen Protector package, showing two screen protectors, an applicator card, a microfiber cleaning cloth, and a dust removing sticker.

ClearTouch screen protector *included accessories*



**Applicator
Card**



**Microfiber
Cleaning Cloth**



**Dust Removing
Sticker**

Image: Detailed view of the included accessories: applicator card, microfiber cleaning cloth, and dust removing sticker.

SETUP: INSTALLATION INSTRUCTIONS

Follow these steps for optimal installation of your ClearTouch Anti-Glare Screen Protector:

1. **Prepare Your Workspace:** Ensure you are in a clean, dust-free environment. Wash your hands thoroughly to avoid transferring oils or dirt to the screen or protector.
2. **Clean the Device Screen:** Use the provided microfiber cleaning cloth to thoroughly wipe down the Newland SP830 screen. Ensure all dust, smudges, and fingerprints are removed. For stubborn marks, a screen cleaner (not included) can be used, followed by drying with the microfiber cloth.
3. **Remove Dust:** Use the dust removing sticker to lift any remaining dust particles from the screen. Gently dab the sticker across the entire screen surface.
4. **Peel Back Layer 1:** Carefully peel back a small portion of the protective film labeled 'Layer 1' from one corner of the screen protector. Avoid touching the adhesive side.
5. **Align the Protector:** Align the exposed adhesive edge of the screen protector with the corresponding edge of your Newland SP830 screen. Ensure precise alignment with all cutouts (if any) and edges of the device.
6. **Apply the Protector:** Slowly and steadily lower the screen protector onto the device screen while simultaneously peeling off more of 'Layer 1'. Use the applicator card to gently smooth out any air bubbles as you go, pushing them towards the edges.
7. **Remove Air Bubbles:** If bubbles remain, use the applicator card to push them towards the nearest edge of

the screen. For persistent bubbles, you may gently lift the nearest edge of the protector and re-apply, smoothing with the card.

8. **Remove Layer 2:** Once the screen protector is fully applied and free of major bubbles, carefully peel off the top protective film labeled 'Layer 2'.



Image: Illustration of a hand carefully aligning and applying the screen protector to a device screen.



Image: Demonstrating the use of an applicator card to smooth out air bubbles during screen protector installation.

OPERATING (USAGE)

Once installed, the BoxWave ClearTouch Anti-Glare Screen Protector enhances your Newland SP830 experience in several ways:

- **Anti-Glare Protection:** The matte finish disperses light, significantly reducing reflections and glare from ambient light sources, improving screen readability in various lighting conditions.
- **Anti-Fingerprint Surface:** The specialized surface repels smudges and fingerprints, keeping your screen cleaner for longer and maintaining a clear view.
- **Paper-like Feel:** The unique texture provides a tactile experience similar to writing on paper, which can be beneficial for stylus use and general touch interaction.
- **Scratch Resistance:** The protector adds a layer of defense against scratches and minor abrasions, preserving the original screen of your device.

Paper-like Feel

Write and draw on your screen with the same feel as on paper






Image: A device screen with the ClearTouch Anti-Glare protector, illustrating the paper-like feel when used with a stylus.



Please note this is a general product photo for display purposes.
The actual product is tailored specifically to fit your device

Image: A visual comparison demonstrating the anti-smudge properties of the ClearTouch protector against a standard screen, highlighting reduced fingerprint visibility.

MAINTENANCE

To maintain the clarity and effectiveness of your BoxWave ClearTouch Anti-Glare Screen Protector, follow these simple maintenance guidelines:

- **Cleaning:** Use the provided microfiber cleaning cloth to gently wipe the screen protector. For more thorough cleaning, lightly dampen the cloth with water or a mild, screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Avoid Sharp Objects:** While the protector offers scratch resistance, avoid contact with sharp objects that could damage the film.
- **Reusability:** The ClearTouch protector features a glueless adhesive, allowing for re-application if necessary. If you need to remove and re-install, ensure both the screen and the adhesive side of the protector are free of dust and debris.

TROUBLESHOOTING

If you encounter issues with your screen protector, consider the following:

- **Persistent Bubbles:** Small bubbles often disappear within 24-48 hours. For larger or persistent bubbles, gently lift the nearest edge of the protector and re-apply, using the applicator card to smooth it down. Ensure no dust is trapped underneath.
- **Dust Under Protector:** If dust particles are visible, carefully lift the nearest edge of the protector and use the dust removing sticker to gently lift the dust from both the screen and the adhesive side of the protector. Re-apply slowly.
- **Misalignment:** If the protector is misaligned, carefully peel it off entirely. Clean the screen and the protector's adhesive side thoroughly, then re-align and re-apply following the installation instructions.

SPECIFICATIONS

Brand	BoxWave
Model Compatibility	Newland SP830
Material	Polyethylene Terephthalate
Special Feature	Anti-Glare
Screen Surface Description	Matte
Number of Items	2
Item Weight	0.7 ounces

WARRANTY AND SUPPORT

BoxWave products are designed for quality and performance. For any questions, concerns, or support regarding your ClearTouch Anti-Glare Screen Protector, please contact BoxWave Corporation directly. Refer to your purchase documentation or the BoxWave website for specific warranty information and customer service contact details.