Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Benkut P60-7SDC1

Benkut 7 Rings Modern LED Chandelier Instruction Manual

Model: P60-7SDC1

Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Benkut 7 Rings Modern LED Chandelier. Please read this manual thoroughly before installation and retain it for future reference.



The Benkut 7 Rings Modern LED Chandelier, showcasing its design in a spacious entryway.

Safety Information

- Always turn off the main power supply at the circuit breaker before beginning installation or maintenance.
- Installation should be performed by a qualified electrician or a person with adequate knowledge of electrical wiring.
- Ensure all electrical connections are secure and comply with local codes and ordinances.
- Do not connect the fixture to a dimmer switch unless specifically designed for LED dimming. This chandelier includes its own remote control dimming functionality.
- Handle the chandelier components with care to prevent damage.


Package Contents

Verify that all components are present before beginning installation:

- Chandelier Rings with Integrated LED
- Ceiling Canopy
- Adjustable Suspension Wires
- Remote Control
- Mounting Hardware (screws, wire connectors, etc.)
- Instruction Manual

Specifications

Brand	Benkut
Model Number	P60-7SDC1
Color	Silver
Material	Acrylic, Aluminum, Metal
Light Source Type	Integrated LED
Wattage	155 Watts
Brightness	8100 Lumens
Color Temperature	3000K (Warm White) - 6500K (Cool White)
Dimmable	Yes (10% - 100% via remote control)
Voltage	110 Volts
Product Dimensions	32"L x 32"W x 4"H (Overall, adjustable)
Ring Diameters	13.78", 15.7", 19.7", 21.65", 23.7", 29.5", 31.5"
Max Cable Length	110 inches



Detailed product specifications and dimensions for the chandelier.

Setup and Installation

1. **Preparation:** Ensure the power is turned off at the circuit breaker. Unpack all components and inspect for any damage.
2. **Mounting the Canopy:** Secure the ceiling canopy to the junction box using the provided mounting hardware. Ensure it is firmly attached to a structural element in the ceiling.
3. **Electrical Connections:** Connect the chandelier's electrical wires to your household wiring according to the provided wiring diagram. Typically, this involves connecting live to live, neutral to neutral, and ground to ground.
4. **Adjusting Ring Height:** The suspension wires for each ring are adjustable. Press the button on the cable gripper located at the canopy to release and adjust the length of each wire. This allows for customization of the chandelier's shape and height. The maximum adjustable length is 110 inches.
5. **Securing Rings:** Once the desired height and arrangement for each ring are achieved, ensure the wires are securely locked in place.

6. **Final Check:** Double-check all connections and ensure the chandelier is securely mounted before restoring power.

Installation Tip: *The suspension wires may appear slightly bent or kinked upon initial unpacking. These wires are load-bearing and will straighten over time once the chandelier is hung.*



Details on how to adjust the height of the chandelier rings by pressing the button on the cable gripper.

Operating Instructions

The Benkut LED Chandelier is controlled via the included remote control, offering dimming and color temperature adjustment.

- **Power On/Off:** Use the dedicated power buttons on the remote to turn the chandelier on or off.
- **Brightness Adjustment (Dimming):** The remote allows for stepless dimming from 10% to 100% brightness. Use the brightness control buttons to adjust the light intensity to your preference.
- **Color Temperature Adjustment:** You can select from three color temperature settings:
  - **3000K (Warm White):** Provides a cozy and inviting ambiance.
  - **4500K (Neutral White):** Offers a balanced and comfortable light.

- **6500K (Cool White):** Delivers a bright and energetic illumination.

Use the color temperature buttons on the remote to cycle through these options.

Note: *This chandelier is not compatible with external dimmable wall switches. It is designed to work with a standard on/off switch and its dedicated remote control for dimming and color temperature adjustments.*




Illustration of the remote control's dimming range (10%-100%) and color temperature options (3000K, 4500K, 6000K).



Visual representation of the chandelier in off, on, cool, neutral, and warm light settings.

Your browser does not support the video tag.

Video demonstrating the Benkut LED Chandelier's various lighting modes and configurations.

Your browser does not support the video tag.

Showcase video highlighting the Benkut LED Chandelier's features and aesthetic appeal.

Maintenance

- **Cleaning:** To clean the chandelier, ensure the power is off. Use a soft, dry, or slightly damp cloth to wipe down the rings and canopy. Avoid abrasive cleaners or solvents that could damage the finish or LED components.
- **Inspection:** Periodically check the suspension wires and electrical connections for any signs of wear or loosening.
- **LED Longevity:** The integrated LED lights are designed for long-term use and do not require replacement.

Troubleshooting

Problem	Possible Cause	Solution
Chandelier does not light up.	No power supply; loose wiring; remote control battery dead.	Check circuit breaker. Ensure all wiring connections are secure. Replace remote control battery.
Light flickers or dims unexpectedly.	Unstable power supply; interference; faulty remote signal.	Ensure stable power. Check for nearby devices causing interference. Re-pair remote if applicable (refer to remote instructions).
Remote control not responding.	Battery dead; remote not paired; obstruction.	Replace remote battery. Ensure direct line of sight to the chandelier. Re-pair remote if necessary.

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Benkut customer service directly. Keep your purchase receipt as proof of purchase.
You may also visit the Benkut Store on Amazon for additional product information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C6Z32WQ4

More documents and user manuals: **https://manuals.plus/**