Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

truke Buds F1 Ultra (S31)

truke Buds F1 Ultra True Wireless In-Ear Earbuds

Model: S31



The truke Buds F1 Ultra earbuds in their open charging case, showcasing their sleek design and compact form factor.

Introduction

Welcome to the user manual for your truke Buds F1 Ultra True Wireless In-Ear Earbuds. These earbuds are designed to provide an immersive audio experience with features like Spatial Audio, extended playtime, clear calls with Quad Mics ENC, and ultra-low latency for gaming. Please read this manual carefully to ensure proper use and maintenance of your device.

What's in the Box

- truke Buds F1 Ultra Earbuds (Left and Right)
- Charging Case
- Type-C USB Cable
- Eartips (various sizes)
- Warranty Card
- User Manual

Setup

Charging the Earbuds and Case


Before first use, fully charge the earbuds and the charging case. Connect the provided Type-C USB cable to the charging port on the case and the other end to a USB power source. The indicator light on the case will show charging status.



The truke Buds F1 Ultra offer up to 60 hours of total playtime and support fast charging, providing 100 minutes of playtime with just 10 minutes of case charge.

Pairing with Your Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, and their indicator lights will flash.
3. On your smartphone or Bluetooth-enabled device, go to Bluetooth settings and turn on Bluetooth.
4. Search for available devices and select "truke Buds F1 Ultra" from the list.
5. Once connected, the earbud indicator lights will turn off or show a steady light, indicating successful pairing.



The earbuds feature advanced Bluetooth 5.3 for faster and more stable connections, supporting voice assistants like Google Assistant and Siri.

Operating Instructions

Touch Controls

The truke Buds F1 Ultra feature intuitive touch controls on each earbud for easy management of music, calls, and modes.

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap
Next Track	Double Tap	
Previous Track		Double Tap
Answer/End Call	Single Tap	Single Tap
Reject Call	Long Press (2s)	Long Press (2s)
Activate Voice Assistant	Triple Tap	Triple Tap
Switch Modes (Dynamic/Movie/Bass Boost)	Long Press (2s)	
Toggle Gaming Mode		Long Press (2s)

Spatial Audio and Equalizer Modes

Experience immersive 360° spatial audio and customize your listening with three preset equalizer modes:

- **Dynamic Mode:** Balanced sound for general listening.
- **Movie Mode:** Enhanced vocals and soundstage for cinematic experiences.
- **Bass Boost Mode:** Amplified bass for powerful audio.



The earbuds feature 360° spatial audio and 13mm Graphene Drivers, along with three preset equalizer modes for a tailored listening experience.

Gaming Mode

Activate Gaming Mode for an ultra-low latency experience, reducing audio delay to as low as 40ms. This ensures synchronized audio and visuals, crucial for competitive gaming.



The truke Buds F1 Ultra provide an ultra-low latency of up to 40ms, enhanced with RGB LEDs, for an optimized gaming experience.

Crystal-Clear Calls with Quad Mics ENC

The earbuds are equipped with Quad Mics and Environmental Noise Cancellation (ENC) technology to ensure clear voice transmission during calls, even in noisy environments.



Advanced Quad-Mic Environmental Noise Cancellation (ENC) technology ensures crystal-clear conversations.

Maintenance and Care

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Eartips:** Remove eartips and clean them with water and mild soap if necessary. Ensure they are completely dry before reattaching.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds frequently. Charge them regularly, even if not in constant use.
- **Water Resistance:** The earbuds are water-resistant, but not waterproof. Avoid submerging them in water or exposing

them to excessive moisture. Dry them thoroughly if they get wet.

Troubleshooting

Problem	Possible Solution
No sound or low volume	Check device volume. Ensure earbuds are properly seated in ears. Clean earbud mesh if blocked. Re-pair earbuds.
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget the device in Bluetooth settings and re-pair. Reset earbuds (refer to specific reset instructions if available in product packaging).
Intermittent connection	Ensure no obstacles between earbuds and device. Stay within the 30-meter operating distance. Avoid strong electromagnetic interference.
Charging issues	Check Type-C cable and power source. Ensure earbuds are correctly placed in the charging case. Clean charging contacts on earbuds and case.
Microphone not working	Ensure earbuds are connected. Check microphone permissions on your device. Clean microphone openings if blocked.

Specifications

Feature	Detail
Model Name	Buds F1 Ultra
Model Number	S31
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Driver Size	13 mm
Audio Driver Type	Dynamic Driver (Graphene)
Battery Life (Total)	Up to 60 Hours
Audio Latency	40 Milliseconds (Gaming Mode)
Microphone	Quad Mics with Environmental Noise Cancellation (ENC)
Control Type	Touch Control
Water Resistance Level	Water Resistant
Item Weight	45 Grams

Feature	Detail
Material	Plastic
Maximum Operating Distance	30 Metres
Form Factor	In Ear
Noise Control	Sound Isolation

Warranty and Customer Support

Your truke Buds F1 Ultra earbuds come with a **12-month warranty** from the date of purchase, assuring quality and customer satisfaction. Please retain your purchase receipt for warranty claims.
For any queries, technical support, or warranty claims, please contact our customer care team:

Contact Number: +91 9354170767

Email ID: support@eccentricindia.com

Website: www.truke.in

We have a vast service network of **350+ active service centers** to ensure convenient and accessible support wherever you are.



Information regarding truke's 12-month warranty, 350+ service centers, and customer care contact details.

© 2024 truke. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C73215SQ

More documents and user manuals: **https://manuals.plus/**