Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

STARSIKI Ultra-Slim Quiet Mouse Jiggler

STARSIKI Ultra-Slim Quiet Mouse Jiggler Instruction Manual

Model: Ultra-Slim Quiet Mouse Jiggler

Contents | Introduction | Safety Information | Package | Setup | Operation | Compatibility | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

The STARSIKI Ultra-Slim Quiet Mouse Jiggler is a device designed to prevent your computer from entering sleep mode or displaying an inactive status. It achieves this by subtly moving the mouse pointer, simulating active user presence. This device features an ultra-slim design, a quiet micro motor, and adjustable interval settings for varied movement patterns.



Image: The STARSIKI Ultra-Slim Quiet Mouse Jiggler in operation, keeping a computer active.

2. Safety Information

- Keep the device away from water and moisture.
- Do not attempt to disassemble or repair the device. Refer to qualified personnel for service.

- Use only with compatible USB power sources (e.g., computer USB port, wall adapter).
- Avoid placing heavy objects on the device.
- Ensure proper ventilation around the device during operation.

3. Package Contents

Please check the package for the following items:

- 1 x STARSIKI Ultra-Slim Quiet Mouse Jiggler Unit
- 1 x USB Power Cable
- 1 x User Manual (this document)

4. Setup

Follow these steps to set up your mouse jiggler:

1. **Connect Power:** Plug the provided USB cable into the mouse jiggler unit and connect the other end to a USB power source. This can be a computer USB port or a wall adapter (not included).
2. **Power On:** Press the power button on the side of the device to turn it on. Indicator lights will illuminate.
3. **Place Mouse:** Place your optical mouse on the turntable surface of the jiggler. Ensure the mouse's optical sensor is positioned directly over the rotating part for optimal movement detection.



Image: The mouse jiggler connected via USB, with a mouse placed on its surface.

Your browser does not support the video tag.

Video: Demonstration of correctly placing the mouse sensor on the jiggler's turntable for effective operation.

5. Operation

The mouse jiggler operates by rotating a small turntable, causing the optical sensor of your mouse to detect subtle movement. This prevents your computer from going to sleep or showing an inactive status.

Adjusting Interval Timer

The device features an adjustable interval timer with four settings to simulate varied mouse activity. The turntable runs for approximately 15 seconds, then pauses for a set interval before restarting.

- **10s:** Pauses for 10 seconds.
- **30s:** Pauses for 30 seconds.
- **3min:** Pauses for 3 minutes.
- **1-60s Random:** Pauses for a random duration between 1 and 60 seconds.

To change the interval setting, press the dedicated interval button on the device. The corresponding indicator light will show the selected setting.




Image: Close-up of the mouse jiggler showing the interval setting buttons and indicator lights.

Your browser does not support the video tag.

Video: Demonstration of adjusting the interval timer settings on the mouse jiggler.

Subtle Pointer Movement

The device is designed to move the mouse pointer subtly, typically 1-2 pixels at a time. This minimal movement is

intended to keep the computer active without causing noticeable cursor displacement on the screen, allowing for simultaneous use of another mouse if desired.

6. Compatibility

The STARSIKI Ultra-Slim Quiet Mouse Jiggler is compatible with a wide range of operating systems and mice:

- **Operating Systems:** Windows 7 and above, Mac OS 10.10 and above, iOS 12 and above, Android 7.1.1 and above, Chrome OS, Linux, Unix.
- **Mice:** Suitable for most optical mice. Not compatible with trackball mice.
- **Devices:** Compatible with laptops and personal computers.



Image: Visual representation of the mouse jiggler's broad compatibility with different operating systems and devices.

7. Maintenance

To ensure the longevity and optimal performance of your mouse jiggler, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place when not in use.
- **Handling:** Handle the device with care to avoid physical damage.

8. Troubleshooting

If you encounter issues with your STARSIKI Ultra-Slim Quiet Mouse Jiggler, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mouse pointer does not move.	Device not powered on; mouse sensor not aligned; incompatible mouse.	Ensure the device is powered on and indicator lights are active. Reposition the mouse so its optical sensor is directly over the rotating turntable. Confirm your mouse is an optical type (not trackball).

Problem	Possible Cause	Solution
Computer still enters sleep mode.	Incorrect interval setting; specific software/system settings overriding jiggler.	Adjust the interval timer to a shorter duration (e.g., 10s or 30s). Check your computer's power management settings to ensure they do not conflict with the jiggler's operation.
Device makes unexpected noise.	Obstruction on turntable; internal issue.	Ensure no debris is on the turntable. The device is designed with a super-quiet micro motor; if unusual noise persists, contact customer support.

9. Specifications

Feature	Detail
Brand	STARSIKI
Model	Ultra-Slim Quiet Mouse Jiggler
Color	White
Connectivity Technology	USB
Special Feature	Super-Silent, Undetectable Subtle Movement, Adjustable Interval Timer
Movement Detection	Optical
Button Quantity	1 (Power), 1 (Interval)
Hand Orientation	Ambidextrous
Compatible Devices	Laptop, Personal Computer
Operating System Compatibility	Windows 7+, Mac 10.10+, iOS 12+, Android 7.1.1+, Chrome OS, Linux, Unix
Power Source	Corded Electric (USB)
Item Weight	2.82 Ounces
Item Dimensions (L x W)	5.51"L x 3.22"W
Enclosure Material	Plastic

10. Warranty & Support

Warranty Information

This STARSIKI product comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper installation.

Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact STARSIKI customer support through the retailer's platform or the official STARSIKI website. Please have your purchase receipt and product model information

ready when contacting support.

© 2026 STARSIKI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C73VYZCL

More documents and user manuals: **https://manuals.plus/**