

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UpBright 24V AC/DC Adapter User Manual for LegXercise LEGX-011, LEGX-012, LEGX-010

## UPBRIGHT LEGX-011 Power Supply

# UpBright 24V AC/DC Adapter User Manual

For LegXercise LEGX-011, LEGX-012, and LEGX-010 Motorized Leg Activators

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective use of your UpBright 24V AC/DC Adapter. This adapter is designed to provide power to compatible LegXercise motorized leg activator machines.

### 1.1 Package Contents

- 1 x UpBright 24V AC/DC Adapter
- 1 x User Manual (this document)

### 1.2 Compatibility

The UpBright 24V AC/DC Adapter is compatible with the following LegXercise models:

- LegXercise LEGX-011
- LegXercise LEGX011 Pro
- LegXercise LEGX-012
- LegXercise LEGX012 MAX
- LegXercise LEGX-010
- LegXercise LEGX010 MAX

# Security Protection

Multiple professional protection, so that fast  
Charge more safe




Image 1.1: The UpBright 24V AC/DC Adapter powering a LegXercise machine.



Image 1.2: Visual confirmation of adapter compatibility with LegXercise models.

## 2. SETUP INSTRUCTIONS

Follow these steps to properly set up your UpBright 24V AC/DC Adapter:

1. **Unpack the Adapter:** Carefully remove the adapter from its packaging. Inspect it for any visible damage.
2. **Connect to LegXercise Machine:** Locate the power input port on your LegXercise machine. Insert the DC output plug of the UpBright adapter firmly into this port. Ensure a secure connection.
3. **Plug into Power Outlet:** Insert the AC input plug of the adapter into a standard 100-240VAC 50/60Hz wall outlet. Ensure the outlet is easily accessible and not overloaded.

Once connected, your LegXercise machine should be ready for operation.



Image 2.1: Proper connection of the adapter to the LegXercise machine and power outlet.

### 3. OPERATING INSTRUCTIONS

---

The UpBright 24V AC/DC Adapter functions as a power supply for your LegXercise machine. Once properly connected as described in the Setup section, the adapter continuously supplies the necessary 24V DC power to the device. There are no specific operational controls on the adapter itself.

- Ensure the adapter is always connected to a functional power outlet and the LegXercise machine during use.
- Disconnect the adapter from the power outlet when the LegXercise machine is not in use for extended periods.

### 4. SAFETY FEATURES

---

The UpBright 24V AC/DC Adapter is designed with multiple safety features to protect both the adapter and your connected device:

- **OVP (Over Voltage Output Protection):** Prevents damage to your device from excessive voltage output.

- **OCP (Over Current Output Protection):** Protects against damage caused by excessive current draw.
- **SCP (Short Circuit Output Protection):** Automatically shuts down power in case of a short circuit, preventing damage and potential hazards.
- **Overcharge Protection:** Safeguards against battery overcharging if the connected device has a rechargeable battery.
- **Overheat Protection:** Monitors internal temperature to prevent overheating.
- **Lightning Protection:** Offers a degree of protection against power surges from lightning.

## One Outlet Design

| UpBright                                                                           | Typical Charger:                                                                     |
|------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| Uses One Outlet                                                                    | Uses Two Outlets                                                                     |
|  |  |

**- Did YOU know ?**

UpBright chargers has one outlet design to keep other outlets free for your other devices!

UpBright

Image 4.1: Overview of the adapter's built-in safety circuits.



Image 4.2: Detailed view of the adapter's security protection features.

## 5. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Cable Care:** Avoid bending, twisting, or crimping the power cord excessively. Do not place heavy objects on the cord. Regularly inspect the cord for any signs of damage, such as fraying or exposed wires.

- **Ventilation:** Ensure the adapter has adequate ventilation during operation. Do not cover it or place it in an enclosed space that could restrict airflow.



Image 5.1: The adapter features a durable and flexible wire designed for longevity.

## 6. TROUBLESHOOTING

If you encounter issues with your UpBright 24V AC/DC Adapter, refer to the following table for common problems and solutions:

| Problem                               | Possible Cause                      | Solution                                                                                                                              |
|---------------------------------------|-------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| LegXercise machine does not power on. | Adapter not properly connected.     | Ensure the adapter's DC plug is fully inserted into the LegXercise machine and the AC plug is firmly in the wall outlet.              |
|                                       | Wall outlet is not functional.      | Test the wall outlet with another device to confirm it is supplying power. Try a different outlet.                                    |
|                                       | Damaged adapter or cable.           | Inspect the adapter and cable for any visible damage. If damaged, discontinue use and contact support.                                |
| Adapter feels unusually hot.          | Poor ventilation or excessive load. | Ensure the adapter is in a well-ventilated area. Disconnect for a few minutes to cool down. If overheating persists, discontinue use. |

If the problem persists after trying these solutions, please contact customer support.


## 7. SPECIFICATIONS

Key technical specifications for the UpBright 24V AC/DC Adapter:

| Feature            | Detail                           |
|--------------------|----------------------------------|
| Model Number       | LegXercise LEGX-011 Power Supply |
| Input Voltage      | 100-240VAC, 50/60Hz              |
| Output Voltage     | 24 Volts (DC)                    |
| Connector Type     | 2-Pin                            |
| Product Dimensions | 4 x 3 x 2 inches                 |
| Item Weight        | 3.52 ounces                      |

| Feature          | Detail                                                                     |
|------------------|----------------------------------------------------------------------------|
| Material         | Plastic                                                                    |
| Special Features | Short Circuit Protection, Over Voltage Protection, Over Current Protection |


Come With A Suitable Outlet Adapter (Only One) to Fit  
Your Country/Area For International Order



The image shows three black plastic outlet adapters. The first is labeled 'AU' and has two silver prongs. The second is labeled 'EU' and has two silver prongs. The third is labeled 'UK' and has three prongs: two silver and one black.

THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE  
+ UPBRIGHT® LIMITED WARRANTY



The image shows a document titled 'Product Warranty and Return Policy' with detailed terms and conditions. To the right of the document is a gold seal with the words 'PRODUCT WARRANTY' and a ribbon at the bottom.

Image 7.1: Product label displaying adapter specifications.

8. WARRANTY AND SUPPORT

UpBright offers the following warranty and support for this product:

- **Refund Policy:** 30 days refund from the date of purchase.
- **Exchange Policy:** 24 months exchange for defective units.

For warranty claims or technical assistance, please contact UpBright customer support through your purchase platform or the official UpBright website.



Image 8.1: Example of a warranty certificate.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

### Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

### Details

[Submit question](#)

---

Open the live page

<https://manuals.plus/asin/B0C73YY313>

More documents and user manuals: <https://manuals.plus/>