

[Manuals.plus](#) /

› [Coleshome](#) /

› Coleshome 66-inch L-Shaped Gaming Desk with Power Outlet User Manual

Coleshome Coleshome-LShape-001

Coleshome 66-inch L-Shaped Gaming Desk with Power Outlet

Model: Coleshome-LShape-001

INTRODUCTION

Thank you for choosing the Coleshome 66-inch L-Shaped Gaming Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

- Read all instructions thoroughly before assembly and use.
- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Ensure all screws and connections are securely tightened before placing items on the desk or using the power outlets.
- Do not exceed the maximum weight capacity of the desk.
- Do not overload the integrated power outlets. Refer to the power strip specifications for maximum electrical load.
- Place the desk on a level surface to prevent instability. Use the adjustable foot pads to compensate for uneven floors.

PACKAGE CONTENTS

Please verify that all components listed below are present in your package. If any parts are missing or damaged, please contact customer support.

- Desk Panels (Engineered Wood)
- Metal Frame Components
- CPU Stand
- Integrated Power Strip (with 3 AC outlets and 2 USB ports)
- Iron Hook
- Adjustable Foot Pads
- Assembly Hardware (screws, bolts, washers, etc.)

Note: All necessary assembly tools are not included. You may need a screwdriver and wrench for assembly.

SETUP & ASSEMBLY

Assembly is recommended for one adult. Follow the detailed instructions provided in the separate assembly guide included with your package. The general steps are outlined below:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them with the parts list in your assembly guide to ensure everything is present and undamaged.
2. **Assemble the Metal Frame:** Connect the metal frame components using the provided hardware. Ensure all screws are finger-tight initially.
3. **Attach Desk Panels:** Secure the engineered wood desk panels to the assembled metal frame. Once all panels are in place, fully tighten all screws.
4. **Install Power Strip:** Mount the integrated power strip into its designated recessed area on the desk surface.
5. **Attach CPU Stand:** Secure the CPU stand to the underside of the desk frame as indicated in the assembly guide.
6. **Install Iron Hook:** Attach the iron hook to the side of the desk frame.
7. **Adjust Foot Pads:** Screw the adjustable foot pads into the bottom of the desk legs. Adjust them to ensure the desk is stable and level on your floor.

Dimensions



Ergonomic Height and Width



Figure 1: Desk Dimensions. This image illustrates the overall dimensions of the L-shaped desk, including its length (66 inches), width (47 inches on one side, 20 inches on the other), and height (28.7 inches). A person is shown for scale, and the power cord is visible.

OPERATING INSTRUCTIONS

Your Coleshome L-Shaped Gaming Desk is designed for optimal functionality and convenience.

Integrated Power Strip

The desk features a built-in power strip with 3 standard AC outlets (125V/12A) and 2 USB charging ports (5V-2A). The power cord is 6.6 feet long.

- Plug the desk's power cord into a wall outlet.
- Connect your laptop, smartphone, tablet, printer, or gaming devices to the available AC outlets or USB ports.
- Ensure devices are compatible with the power strip's voltage and current ratings.



Figure 2: Recessed Power Strip. This image shows a close-up of the integrated power strip with 3 AC outlets and 2 USB ports, along with its 6.6-foot power cord. A smartphone is shown charging via one of the USB ports.

CPU Stand

The included CPU stand provides a dedicated space for your computer tower, keeping it off the floor and improving airflow.

- Place your computer tower securely on the CPU stand.
- Ensure cables are routed safely to avoid tripping hazards.

Computer Tower Stand



Figure 3: Computer Tower Stand. This image displays a computer tower resting on the dedicated stand, positioned beneath the desk surface, illustrating how it saves space and keeps the tower accessible.

Iron Hook

The iron hook is designed for convenient storage of headphones or other lightweight accessories, keeping your workspace tidy.

- Hang your headphones or other items on the hook.
- Avoid hanging heavy objects that could damage the hook or desk.

Iron Hook



Figure 4: Iron Hook. This image provides a close-up view of the iron hook attached to the side of the desk, with a pair of headphones hanging from it, demonstrating its utility for accessory storage.

MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as they may damage the laminated finish.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Spills:** Clean up spills immediately to prevent damage to the desk surface.

TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common problems and solutions:

- **Desk Wobbles:**
 - Ensure all assembly screws are fully tightened.
 - Adjust the leveling foot pads on each leg to stabilize the desk on uneven floors.
- **Power Strip Not Functioning:**
 - Verify that the desk's power cord is securely plugged into a working wall outlet.
 - Check your home's circuit breaker to ensure it hasn't tripped.

- Ensure you are not exceeding the maximum electrical load for the power strip (125V/12A for AC, 5V-2A for USB).

- **Missing or Damaged Parts:**

- Review the package contents list. If parts are missing or damaged, contact Coleshome customer service for assistance.

SPECIFICATIONS

Feature	Detail
Brand	Coleshome
Model Number	Coleshome-LShape-001
Product Dimensions (L x W x H)	167.9 x 119.9 x 74 cm (66 x 47 x 29.1 inches)
Weight	19.96 kg (44 lbs)
Shape	L-Shape
Color	Black
Top Material Type	Engineered Wood
Base Material	Metal
Finish Type	Laminated
Special Features	Adjustable Foot Pads, Integrated Power Outlet, CPU Stand, Iron Hook
Power Outlet	3 AC Outlets (125V/12A), 2 USB Ports (5V-2A), 6.6-foot Power Cord
Assembly Required	Yes
Recommended Assembly Persons	1
Tools Included	No
Recommended Uses	Gaming, Work, Writing

WARRANTY AND SUPPORT

Coleshome is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this manual, we offer professional 24-hour online customer service to assist you with any questions or issues you may encounter.

For support, please refer to the contact information provided with your purchase or visit the official Coleshome website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C74CJJ9K>

More documents and user manuals: <https://manuals.plus/>