

[Manuals.plus](#) /

› [Weibath](#) /

› Weibath 73-inch Whirlpool Tub Water Massage Bathtub Instruction Manual Model 62588849

Weibath 62588849

Weibath 73-inch Whirlpool Tub Water Massage Bathtub Instruction Manual

Model: 62588849

1. INTRODUCTION

Thank you for choosing the Weibath 73-inch Whirlpool Tub. This manual provides essential information for the safe installation, operation, and maintenance of your new jetted bathtub. Please read all instructions carefully before installation and use to ensure proper function and longevity of the product.



Image 1.1: The Weibath 73-inch Whirlpool Tub, showcasing its design and illuminated water features.

2. SAFETY INSTRUCTIONS

WARNING: To reduce the risk of injury, do not permit children to use this product unless they are closely supervised at all times. Always ensure the bathtub is properly grounded. Do not operate the tub without water. Consult a qualified electrician and plumber for installation.

- Always ensure the power supply is disconnected before performing any maintenance or cleaning.
- Do not use abrasive cleaners or harsh chemicals that may damage the acrylic surface or internal components.
- Avoid placing heavy or sharp objects on the tub's surface to prevent scratches or damage.
- Ensure proper ventilation in the bathroom to prevent moisture buildup.
- Keep all electrical connections dry and protected from water exposure.

3. PRODUCT FEATURES AND COMPONENTS

The Weibath 73-inch Whirlpool Tub is designed for a luxurious bathing experience, featuring advanced hydro-massage and chromatherapy.

3.1 Key Features

- **Acrylic Construction:** Made from high-quality, non-toxic, odorless acrylic for durability and easy cleaning.
- **Two-Person Capacity:** Spacious design (73.23"L x 47.24"W x 24.21"H) with a water capacity of 105.67 gallons.
- **Whirlpool Water Massage:** Equipped with 6 large and 16 small water jets powered by a 1.5HP water pump for a vibrant massage.
- **LED Chromatherapy:** Features 12 solid brass LED bubble jets and an underwater automatic color-changing LED light system for ambiance.
- **Smart Touch Panel:** Intuitive LED LCD display for easy operation and control of tub functions.
- **Waterfall Spout:** Integrated waterfall feature for enhanced relaxation.
- **Comfort:** Includes sloped lumbar support and comfortable PU pillows.



Image 3.1: An overview highlighting the main features of the 73-inch Weibath Whirlpool Bathtub.

3.2 Material Construction

The bathtub is constructed with multiple layers to ensure durability and heat retention.



Acrylic Material

Thickened material retains water temperature longer, enhancing bath comfort.



Image 3.2: Cross-section diagram illustrating the multi-layered acrylic construction for enhanced insulation and strength.

4. INSTALLATION GUIDE

Professional installation by a licensed plumber and electrician is highly recommended to ensure compliance with local codes and proper functionality. This tub is designed for freestanding installation.

4.1 Pre-Installation Checks

- Verify all components are present and undamaged.
- Ensure the installation area can support the weight of the tub filled with water and occupants (approximately 1200 lbs).
- Confirm access to appropriate electrical and plumbing connections.

4.2 Dimensions

Refer to the diagram below for precise measurements to plan your installation space.




Image 4.1: Detailed dimension diagram of the bathtub for installation planning.

4.3 Electrical Requirements

The tub requires a dedicated electrical circuit. Consult the product label for specific voltage and amperage requirements. Ensure a Ground Fault Circuit Interrupter (GFCI) is installed for safety.

4.4 Plumbing Connections

Connect hot and cold water lines to the tub filler. Ensure the drain and overflow are properly installed and sealed to prevent leaks. The tub filler, LCD control, drain, and overflow are included.

5. OPERATING INSTRUCTIONS

Familiarize yourself with the Smart Touch Panel to control the various functions of your whirlpool tub.

5.1 Smart Touch Panel

The waterproof LED LCD display provides intuitive control over all features.



Smart Touch Panel

-  LED LCD display
-  Easy to operate
-  Waterproof

Image 5.1: The Smart Touch Panel, showing its LED LCD display and user-friendly interface.

5.2 Filling the Tub

Ensure the drain is closed. Use the tub filler to fill the tub with water to a level above the jets but below the overflow. Do not operate the jets or bubble system without sufficient water.

5.3 Activating Water Massage (Whirlpool Jets)

Press the designated button on the Smart Touch Panel to activate the 1.5HP water pump, initiating the whirlpool massage through the 22 water jets.

Surf Massage


Deliver a powerful hydromassage, relaxing and invigorating



Image 5.2: A close-up of a surf massage jet providing a powerful hydro-massage.

5.4 Activating Bubble Massage and LED Chromatherapy

Press the corresponding button on the Smart Touch Panel to turn on the 300W bubble pump and the 12 LED bubble jets. The LED lights will automatically cycle through colors, or you may be able to select a specific color depending on the model's controls.



Bubble Massage

Bubble nozzles and gentle water flow give the skin the right massage

Image 5.3: Bubble nozzles generating a gentle massage effect.

LED Colorful Bulbs

Waterproof LED lights, creating different moods and atmospheres for bathing at night.



Image 5.4: Examples of the colorful LED lighting options for chromatherapy.

5.5 Waterfall Spout Operation

Activate the waterfall spout via the control panel or dedicated faucet handle, if applicable, to enjoy the cascading water feature.

Waterfall Spout

Splendid、Efficient



Image 5.5: The integrated waterfall spout in operation.

6. CARE AND MAINTENANCE

Regular cleaning and maintenance will ensure your Weibath whirlpool tub remains in excellent condition.

6.1 Cleaning the Tub Surface

- Use a soft cloth and a non-abrasive, mild bathroom cleaner.
- Wipe down the acrylic surface after each use to prevent soap scum and mineral buildup.
- For stubborn stains, use a cleaner specifically designed for acrylic surfaces.

6.2 Cleaning the Jets and Plumbing System

- Periodically fill the tub with warm water and add a small amount of a jetted tub cleaner or white vinegar.

- Run the jets for 10-15 minutes, then drain the tub.
- Rinse the tub thoroughly with clean water.

6.3 Draining the Tub

After each use, ensure the tub is completely drained to prevent stagnant water and potential bacterial growth.

7. TROUBLESHOOTING

This section addresses common issues you might encounter. For problems not listed here, please contact customer support.

Problem	Possible Cause	Solution
Jets not working	No power; insufficient water level; air lock in pump.	Check power supply/GFCI; ensure water level is above jets; turn off and on pump to clear air.
LED lights not illuminating	Power issue; light module malfunction.	Check power connection; contact customer support if problem persists.
Water leakage	Loose plumbing connections; damaged seals.	Inspect all connections and seals; tighten or replace as necessary. Professional assistance recommended.
Control panel unresponsive	Power interruption; panel malfunction.	Reset power to the tub; ensure panel is dry. Contact support if issue continues.

8. TECHNICAL SPECIFICATIONS

Specification	Detail
Brand	Weibath
Model Number	62588849
ASIN	B0C74F6NTH
Product Dimensions (L x W x H)	73.23" x 47.24" x 24.21" (1860mm x 1200mm x 615mm)
Material	Acrylic
Color	White
Capacity	105.67 Gallons
Item Weight	434 pounds
Water Pump Power	1.5 HP
Bubble Pump Power	300W
Number of Water Jets	22 (6 large + 16 small)

Specification	Detail
Number of LED Bubble Jets	12
Installation Type	Freestanding
Included Components	Tub filler, LCD control, drain, overflow

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact Weibath customer service. For technical support or replacement parts, please reach out to the manufacturer directly. Keep your purchase receipt and model number handy for all inquiries.

Manufacturer: Weibath

Item Model Number: 62588849

ASIN: B0C74F6NTH

© 2023 Weibath. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

