Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MOBILLA MBUDS131

MOBILLA TWS Earbuds - MBUDS131 User Manual

Model: MBUDS131

Introduction

This user manual provides detailed instructions for the operation, maintenance, and troubleshooting of your MOBILLA TWS Earbuds MBUDS131. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

Package Contents

Verify that all items are present in the package:

- 1N True Wireless Earbuds
- 1N Charging Cable
- 1N Warranty Card

Product Overview



Image: The MOBILLA TWS Earbuds MBUDS131 in blue, displayed with their charging case open. The left earbud is partially removed from its slot, while the right earbud remains in place. A digital display on the case shows "100", indicating full charge. The transparent lid of the charging case is visible in the background.

The MOBILLA MBUDS131 are True Wireless Stereo (TWS) earbuds designed for portable audio. They feature a compact charging case with an LED battery indicator. The earbuds are lightweight and include an in-built microphone for calls and voice assistant functionality. They are also sweatproof with an IPX4 rating.

Setup

Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided charging cable to the charging port on the case and a compatible USB power source. The LED battery indicator on the case will show the charging status. A full charge provides up to 24 hours of playback time (with case).

Pairing with a Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode (Instant Auto Connect).
3. On your Bluetooth-enabled device (e.g., smartphone, tablet), go to the Bluetooth settings.
4. Search for available devices and select "MBUDS131" from the list.
5. Once connected, the earbuds are ready for use. They will automatically reconnect to the last paired device when removed from the case.

Operating Instructions

Basic Controls

The MBUDS131 earbuds feature touch controls for various functions. Specific touch gestures for play/pause, skip tracks, answer/end calls, and activate voice assistant are typically detailed in a quick start guide or on the product packaging. Refer to those for precise instructions.

Voice Assistant

The earbuds are Voice Assistant Enabled. To activate your device's voice assistant (e.g., Google Assistant, Siri), use the designated touch control on the earbud. Once activated, you can issue commands through the in-built microphone.

Maintenance

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The earbuds are IPX4 sweatproof. This means they are resistant to splashing water from any direction. Do not submerge them in water or expose them to heavy rain.

Troubleshooting

Problem	Solution
Earbuds not pairing/connecting.	• Ensure earbuds are charged. • Turn off and on Bluetooth on your device. • Forget "MBUDS131" from your device's Bluetooth list and try pairing again. • Place earbuds back in the case, close the lid, wait a few seconds, then open again.
No sound from earbuds.	• Check volume levels on both earbuds and connected device. • Ensure earbuds are properly connected to your device. • Try playing different audio sources.
Charging case not charging.	• Ensure the charging cable is securely connected. • Try a different USB power source or cable.

Specifications

Feature	Detail
Model Name	MBUDS131
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth
Playback Time	Up to 24 Hours (with charging case)
Water Resistance Level	IPX4 (Sweatproof)
Microphone	In-Built Microphone
Control Type	Voice Control
Voice Assistant	Enabled
Material	Acrylonitrile Butadiene Styrene (ABS), Thermoplastic Elastomer (TPE)
Form Factor	In Ear
Manufacturer	MOBITECH INDUSTRIES LLP PVT LTD

Warranty and Support

Your MOBILLA TWS Earbuds MBUDS131 come with a warranty. Please refer to the included Warranty Card for detailed terms and conditions. For technical support, service, or further inquiries, please contact MOBILLA customer service through their official website or the contact information provided on the warranty card.
You can also visit the official MOBILLA store on Amazon for more information: MOBILLA Store

© 2023 MOBILLA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C74HBNP1

More documents and user manuals: **https://manuals.plus/**