

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [NEDIS](#) /

› [Nedis LED Plug-in Night Light with Motion Sensor LNLW10WT Instruction Manual](#)

## NEDIS LNLW10WT

# Nedis LED Plug-in Night Light with Motion Sensor (Model: LNLW10WT) - Instruction Manual

Model: LNLW10WT

[Introduction](#)   [Safety Instructions](#)   [Setup](#)   [Operating](#)  
[Instructions](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

Thank you for purchasing the Nedis LED Plug-in Night Light with Motion Sensor. This manual provides important information regarding the installation, operation, and maintenance of your device. Please read it thoroughly before use and keep it for future reference.

### Product Features:

- Compact plug-in design, ideal for bedrooms, hallways, and nurseries.
- Emits a comfortable warm white light in dark environments.
- Equipped with a motion sensor that activates the light upon detecting movement.
- Features a day/night sensor, ensuring the light only activates in darkness.
- Automatic shut-off approximately 30 seconds after motion ceases.
- Energy-efficient LED lighting.



Figure 1: Front view of the Nedis LED Plug-in Night Light, showing its warm white illumination.

## 2. SAFETY INSTRUCTIONS

---

To ensure safe operation, always follow these basic safety precautions:

- This product is for indoor use only.
- Do not expose the device to water or moisture.
- Do not attempt to disassemble, repair, or modify the device. This will void the warranty.
- Ensure the power outlet is easily accessible and not overloaded.
- Keep out of reach of children.
- Do not cover the night light when in use, as this may cause overheating.
- Avoid placing the night light near heat sources or in direct sunlight.

## 3. SETUP

---

The Nedis LED Plug-in Night Light is designed for simple, direct use.

1. **Unpack the device:** Carefully remove the night light from its packaging.
2. **Select a suitable location:** Choose an indoor power outlet in a hallway, bedroom, nursery, or any area where soft, automatic lighting is desired. Ensure the motion sensor (located at the bottom front) is not obstructed.
3. **Plug into power outlet:** Insert the night light directly into a standard wall power outlet. Ensure it is securely seated.





Figure 2: Side and back views illustrating the plug-in design for direct insertion into a power outlet.

## 4. OPERATING INSTRUCTIONS

---

The Nedis LED Plug-in Night Light operates automatically once plugged in.

- **Automatic Activation:** The integrated day/night sensor detects ambient light levels. The night light will only activate when the surrounding environment is dark enough.
- **Motion Detection:** Once in a dark environment, the motion sensor will detect movement within its range. Upon detection, the warm white LED light will illuminate.
- **Automatic Shut-off:** The light will remain on as long as motion is detected. Approximately 30 seconds after the last detected movement, the light will automatically turn off to conserve energy.



Figure 3: The night light in an unlit state, highlighting the motion sensor for automatic operation.

## 5. MAINTENANCE

---

The Nedis LED Plug-in Night Light requires minimal maintenance.

- **Cleaning:** Before cleaning, always unplug the device from the power outlet. Use a soft, dry cloth to wipe the surface. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.
- **Storage:** If not in use for an extended period, unplug the device and store it in a cool, dry place away from direct sunlight.
- **No User-Serviceable Parts:** There are no user-serviceable parts inside this device. Do not attempt to open or repair it.

## 6. TROUBLESHOOTING

---

If you encounter issues with your night light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	Not plugged in correctly. Power outlet is not active. Environment is too bright (day/night sensor). No motion detected.	Ensure the night light is firmly plugged into the outlet. Test the outlet with another device. Move the night light to a darker location or wait for ambient light to decrease. Ensure there is movement within the sensor's range.
Light stays on continuously.	Constant motion detected. Sensor obstructed or faulty.	Ensure no continuous movement is occurring near the sensor. Check if the sensor is clean and unobstructed.
Light flickers or is dim.	Unstable power supply. Device malfunction.	Try plugging the night light into a different outlet. If the problem persists, contact customer support.

## 7. SPECIFICATIONS

Feature	Detail
Brand	NEDIS
Model Number	LNLW10WT
Color	White
Special Features	Motion Detector, Energy Efficiency
Finish Type	Polished
Base Material	Plastic
Product Dimensions (D x W x H)	81 x 44 x 60 mm (approx. 3.2 x 1.7 x 2.4 inches)
Item Weight	41.3 Grams
Lamp Type	Night Light (LED)
Light Output	11 lumens
Power Consumption	0.55 W
Switch Type	Automatic (Motion/Light Sensor)
Country of Origin	China

## 8. WARRANTY AND SUPPORT

Nedis products are built to high quality standards and are covered by a warranty period for manufacturing defects. The specific warranty period may vary depending on the region and point of purchase. Please refer to your purchase receipt or contact your retailer for detailed warranty information.

For technical support or inquiries, please visit the official Nedis website or contact their customer service department. Contact information can typically be found on the product packaging or the Nedis website.

*Note: Keep your proof of purchase (receipt or invoice) for any warranty claims.*

© 2026 Nedis. All rights reserved. Information in this manual is subject to change without notice.