

TOTO SW4726AT40#01

TOTO WASHLET S7 Electronic Bidet Toilet Seat Instruction Manual

Model: SW4726AT40#01

1. INTRODUCTION

The TOTO WASHLET+ S7 Electronic Bidet Toilet Seat is designed to provide an exceptionally clean and comfortable experience. This electronic bidet seat offers continuous warm water cleansing, replacing traditional toilet paper with a gentle and effective wash. The WASHLET+ S7 model is specifically engineered for a seamless installation, concealing the power cord and water supply hose when paired with compatible TOTO WASHLET+ ready toilets, though it is also compatible with standard elongated toilet bowls.

Key features include the EWATER+ system for wand and bowl cleaning, PREMIST technology to prevent waste adhesion, a heated seat, air deodorizer, nightlight, and instantaneous water heating. Control is managed via a luxury-style illuminated touch button remote with memory settings for up to four users.



Image: TOTO WASHLET S7 Electronic Bidet Toilet Seat with its remote control unit.

Video: Overview of TOTO WASHLET S7 Electronic Bidet Seat Features. This video highlights the continuous warm water spray, self-cleaning wand, EWATER+ bowl cleaning, heated seat, warm air dryer, and PREMIST technology.

2. SETUP AND INSTALLATION

2.1 Before You Begin

Ensure you have all necessary parts and tools before starting installation. A Ground Fault Circuit Interrupter (GFCI) 120V outlet is required within reach of the bidet seat's 3-foot power cord. Professional electrical installation may be necessary if an appropriate outlet is not available.

2.2 Parts Included

- TOTO WASHLET S7 Electronic Bidet Seat
- Remote Control & Wall Mount
- Mounting Bracket
- Tee Connector
- Installation Hardware

2.3 Tools Required

- Phillips Head Screwdriver
- Adjustable Wrench
- Measuring Tape

WHAT'S INCLUDED:



WASHLET



Remote &
Wall Mount




Bracket



Tee Connector

WHAT'S REQUIRED

120V GFCI
Outlet



Tools




Image: Visual guide showing the included components (WASHLET, remote, bracket, tee connector) and required items (120V GFCI outlet, screwdriver, measuring tape).

2.4 Installation Steps

1. **Remove Existing Toilet Seat:** Unscrew and remove your current toilet seat. Clean the surface around the mounting holes thoroughly.
2. **Install Mounting Bracket:** Place the WASHLET mounting bracket over the toilet's mounting holes. Use a Phillips head screwdriver to tighten the screws just enough to allow slight movement for adjustment.
3. **Attach WASHLET Seat:** Slide the WASHLET seat onto the mounting bracket until it clicks into place. Adjust the seat and bracket front-to-back and side-to-side to center it over the toilet rim.
4. **Secure Bracket:** Release the WASHLET seat from the bracket (usually by pressing a quick-release button), then fully tighten the bracket screws. Re-attach the WASHLET seat.
5. **Shut Off Water Supply:** Turn off the water supply valve to your toilet. Flush the toilet to relieve pressure and drain the tank.
6. **Disconnect Supply Tube:** Disconnect the existing water supply tube from the toilet's fill valve.
7. **Install Tee Connector:** Screw the WASHLET tee connector onto the toilet's fill valve. Hand-tighten only; do not overtighten.
8. **Connect Water Lines:** Connect one end of the white WASHLET supply line (pre-attached to the

WASHLET) to the tee connector. The other end of the supply line, with a grey plastic tip and O-ring, pushes into the threaded part of the tee connector. Hand-tighten the white plastic nut.

9. **Restore Water and Power:** Turn the water supply back on and check for leaks. Plug the WASHLET into the GFCI outlet and turn it on using the button on the left side of the unit. The LED lights on the rear of the seat will illuminate.



Image: Step-by-step visual guide for installing the WASHLET S7, including removing the old seat, installing the bracket, attaching the bidet seat, and connecting water lines.

Video: Detailed installation guide for TOTO WASHLET models. This video demonstrates the process of removing the old toilet seat, installing the mounting bracket, connecting the water supply, and powering on the unit.

2.5 Compatibility and Optional Accessories

The WASHLET S7 is designed to fit most standard elongated toilet bowls. For certain skirted toilets that restrict access to the fill valve, optional accessories such as a 2-inch extender (9AU321-A) or a 6-inch hose (THU9090R) may be required.

FITS BOTH TOTO & NON-TOTO TOILETS

washlet®+
CONCEALED CONNECTION

CONVENTIONAL CONNECTION



OR



THE S7 WASHLET CAN FIT TOTO WASHLET+ T40 TOILETS FOR A STREAMLINED LOOK. THE S7 CAN ALSO FIT MOST STANDARD NORTH AMERICAN TOILETS USING THE CONVENTIONAL CONNECTION.

Image: Diagram illustrating how the S7 WASHLET fits both TOTO WASHLET+ T40 toilets for a streamlined look and most standard North American toilets using a conventional connection.

OPTIONAL ACCESSORIES:

For difficult to reach fill valves



Image: Illustration of optional accessories, including a 2-inch extender, for toilets with difficult-to-reach fill valves.

3. OPERATING INSTRUCTIONS

The WASHLET S7 offers a range of customizable features for personal comfort and hygiene, controlled via the included remote.

3.1 Cleansing Functions

- **Rear Spray:** Provides effective rear cleansing.
- **Soft Rear Spray:** Offers a gentle rear rinsing option.
- **Front Spray:** Delivers a soft stream for delicate areas.
- **Oscillating Spray:** The wand moves back and forth for a wider cleansing area.
- **Pulsating Spray:** Provides a rhythmic water flow for a massage-like effect.
- **Adjustable Wand Position:** Customize the wand's position for optimal cleansing.
- **Adjustable Water Pressure:** Control the intensity of the water spray.
- **Instantaneous Warm Water:** Enjoy a continuous stream of warm water without waiting.

ADJUSTABLE WATER SPRAY & PRESSURE

For a better clean



REAR SPRAY

Effective rear cleansing



SOFT REAR

Gentle rear rinsing



FRONT SPRAY

Soft stream for delicate areas



OSCILLATING SPRAY

Wand moves back and forth



ADJUSTABLE WAND

Find the perfect position

Image: Visual representation of the various adjustable water spray and pressure settings available on the WASHLET S7, including Rear, Soft Rear, Front, Oscillating, and Adjustable Wand.

3.2 Comfort Features

- **Heated Seat:** The SoftClose heated bidet seat provides consistent warmth across the entire surface.
- **Warm Air Dryer:** An adjustable warm air dryer provides a comfortable finish after cleansing.
- **Air Deodorizer:** Powerful air filters neutralize bathroom odors.
- **Nightlight:** A gentle nightlight illuminates the toilet bowl for convenience in low-light conditions.



Image: Features such as Gentle Close seat, continuous warm water, night light, and EWATER+ bowl cleaning are highlighted.



Image: Comfort features including the Warm Air Dryer, Heated Seat, Deodorizer, and AIR-IN WONDER-WAVE cleansing are shown.

3.3 Remote Control

The WASHLET S7 is operated by an illuminated touch button remote control. It features 4-user memory settings, allowing multiple users to save their preferred cleansing and comfort settings for quick access.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your TOTO WASHLET S7.

4.1 Wand Cleaning

The WASHLET features a self-cleaning wand with EWATER+ technology. EWATER+ mists the wand before and after each use, helping to maintain its cleanliness without harsh chemicals.



Image: Illustration of the self-cleaning wand with EWATER+ and the optimized wand angle to prevent splash-back.

4.2 Bowl Cleaning (PREMIST)

PREMIST wets the surface of the toilet bowl before each use, creating a slick surface that helps prevent waste from adhering, contributing to a cleaner bowl.

4.3 Quick Release for Cleaning

The WASHLET S7 features a quick-release button, allowing for effortless removal of the seat for simplified and thorough cleaning of both the bidet seat and the toilet fixture.

QUICK RELEASE

Easily remove your WASHLET
for simplified cleaning



Image: Demonstration of the quick release button for easy removal of the WASHLET S7 for cleaning.

4.4 Wand Door

All WASHLET models include a wand door that conceals the wand when not in use, protecting it from unwanted debris and maintaining hygiene.

WAND DOOR

PROTECTION FROM UNWANTED DEBRIS

All WASHLET models feature a door that conceals the wand when not in use, preventing unwanted debris from making contact. This feature is typically only found on higher end models of competitors.




Image: Close-up view of the wand door, which protects the wand from debris when not in use.

5. TROUBLESHOOTING

For detailed interactive 3D instructions and troubleshooting assistance, TOTO recommends using the BILT Intelligent Instructions app. This app provides step-by-step visual guidance for installation and common operational queries.



Image: Screenshot of the BILT app demonstrating interactive 3D instructions for WASHLET installation.

Video: BILT Install Demo for TOTO WASHLET. This video showcases the interactive 3D instructions available through the BILT app, guiding users through the installation process.

Common Questions:

- **Wand Not Extending:** The WASHLET features a seat sensor. The wand will only extend and spray when someone is seated. To test the spray function, press down on the rear left side of the seat with your hand, then activate the spray. Use your other hand to block the spray from the wand to avoid getting wet.
- **Water Pressure Too Soft:** The rear spray setting often has options for 'soft' and 'strong'. Press the pressure adjustment button once for a softer stream and twice for added pressure.

6. SPECIFICATIONS

Attribute	Detail
Brand	TOTO
Model Number	SW4726AT40#01

Color	Cotton White
Material	Plastic
Style	Contemporary Lid
Shape	Elongated (Oval)
Product Dimensions	21"L x 15"W
Item Weight	14.5 Pounds
Power Requirement	120V GFCI Outlet
UPC	739268436701



Image: Diagram showing the slim profile and dimensions (width, height, length) of the TOTO WASHLET S7.

WASHLET FIT GUIDE




Image: WASHLET fit guide illustrating measurements for elongated and round toilet compatibility.

7. SUPPORT AND WARRANTY

TOTO is committed to robust quality inspections and customer service. Every product undergoes testing for water and electrical functionality before shipment.

7.1 Customer Support

Full customer service support is available via phone, email, and chat. TOTO aims to answer over 90% of calls within 60 seconds.

- **Phone:** 1-888-583-4536
- **Email:** techsupport@toto.com
- **Hours:** 8am - 8pm EST, Monday - Friday



60
MILLION
UNITS
SOLD WORLDWIDE

Creating a better world for over 100 years, TOTO has sold more than 60 million WASHLET units globally since 1980.

Image: Information highlighting over 60 million WASHLET units sold worldwide, indicating product reliability.

Easy step-by-step
interactive 3D instructions
for this product can be found in



BILT® INTELLIGENT
INSTRUCTIONS



Available on most iOS and Android Devices

DOWNLOAD THE FREE APP

**TOTO .
washlet**

Image: Details on TOTO's commitment to quality and certification by the International Association of Plumbing and Mechanical Officials (IAPMO).

© 2023 TOTO. All rights reserved.