



Manuals.plus /

- › Spare Hardware Parts /
- › Spare Hardware Parts IKEA Assembly Screw C6S (Part #130915) Instruction Manual

## Spare Hardware Parts 130915

# Spare Hardware Parts IKEA Assembly Screw C6S (Part #130915) Instruction Manual

Brand: Spare Hardware Parts | Model: 130915

## INTRODUCTION

---

This instruction manual provides essential information for the proper use and installation of the Spare Hardware Parts replacement IKEA Assembly Screw C6S, Part #130915. This Conformat Hex Screw is designed as an exact-fit replacement for specific IKEA furniture components, ensuring secure and reliable assembly. Please read this manual thoroughly before proceeding with installation.

## PRODUCT OVERVIEW AND SPECIFICATIONS

---

The Spare Hardware Parts #130915 is a Conformat Hex Screw, meticulously crafted to match the original IKEA part. It is made from durable zinc-plated alloy steel for longevity and strength.



Image: A single Conformat hex screw, showcasing its design and material finish.

#### **Key Features:**

- **Exact Fit:** Designed as a direct replacement for IKEA Part #130915.
- **Material:** Crafted from zinc-plated alloy steel for enhanced durability and corrosion resistance.
- **Head Style:** Hex recess for secure driving with a 4mm hex key.
- **Quantity:** Available in a pack of 8 screws.

#### **Detailed Specifications:**

Specification	Detail
Part Number	#130915
Screw Type	Conformat Hex Screw
Dimensions	M7.0-2.4×35 / 30.5-33mm
Screw Diameter	7 mm (0.28 inch)
Screw Pitch	2.4 mm
Screw Length	35 mm (1.38 inch)
Threaded Length	30.5-33 mm
Hex Recess Size	4 mm
Material	Alloy Steel, Zinc Plated
Color	Silver
Number of Pieces	8
Item Weight (per pack)	2.39 ounces

# THE EXACT FIT

Precision engineered to replace Ikea Part #130915

**35 mm**  
**1.38 in**



**7 mm | 0.28 in**

Image: Visual representation of the screw's length and diameter.

# PACK OF 8

Contains 8 individual pieces for all your assembly needs!



Image: A pack of 8 screws, as supplied.

## COMPATIBILITY

---

This replacement screw is specifically designed for IKEA furniture that utilizes Part #130915. It is essential for various home improvement projects and is a tailor-made replacement for hardware items found in:

- IKEA Kyrre stools
- Other IKEA furniture requiring a 7mm diameter, 35mm length Conformat hex screw with a 4mm hex recess.

# Replacement for IKEA Part #130915

Identical fit to the original Ikea part




Image: Visual confirmation of compatibility with IKEA Part #130915, often found in items like the Kyrre stool.

# COMPATIBLE

This part works with multiple different Ikea products

- ✓ Used in Kyrre
- ✓ Screws for stool

## INSTALLATION

---

Follow these steps for proper installation of the Conformat Hex Screw:

1. **Identify the Correct Location:** Ensure you are replacing a screw in the correct pre-drilled hole designed for a Conformat screw of these dimensions.
2. **Prepare Tools:** You will need a 4mm hex key (Allen wrench) for installation.
3. **Insert the Screw:** Place the screw into the designated hole. Ensure it is aligned straight to prevent cross-threading.
4. **Tighten Gradually:** Using the 4mm hex key, turn the screw clockwise to tighten. Apply steady, even pressure.
5. **Avoid Overtightening:** Tighten until the screw head is flush with the surface of the furniture piece and feels secure. Overtightening can strip the wood or the screw head.
6. **Verify Stability:** After installation, gently test the assembled furniture part to ensure it is stable and secure.

## MAINTENANCE

---

Conformat screws generally require minimal maintenance. However, to ensure the longevity and stability of your furniture:

- **Periodic Checks:** Periodically inspect assembled furniture for any loose screws.
- **Retighten:** If a screw feels loose, gently retighten it with a 4mm hex key until snug. Avoid overtightening.
- **Cleaning:** If necessary, wipe the screws with a dry cloth to remove dust or debris. Avoid harsh chemicals that may damage the zinc plating.

## TROUBLESHOOTING

---

Most issues related to screws are straightforward to resolve:

- **Screw Not Tightening:**
  - Ensure you are using the correct 4mm hex key.
  - Check if the screw hole is stripped. If so, the hole may need repair (e.g., with wood filler) or the screw may need to be moved to an alternative, undamaged location if possible.
- **Screw Head Stripped:**
  - If the hex recess is stripped, the screw cannot be tightened or removed with a standard hex key. Specialized screw extractors may be required for removal. Replace with a new screw.
- **Screw Too Short/Long:**
  - Verify that the screw dimensions (7mm diameter, 35mm length) match the requirements of your furniture piece. Using an incorrect size can lead to instability or damage.

## WARRANTY AND SUPPORT

---

Spare Hardware Parts stands by the quality of its products. If this replacement part does not meet your expectations or solve your assembly needs, please contact us directly. We are committed to ensuring your satisfaction and will provide a refund for your order if our product does not perform as expected.

# IT WORKS OR WE MAKE IT RIGHT

If the replacement part doesn't solve your problem,  
let us know and we will fully refund your order.



SPARE  
HARDWARE  
PARTS

Image: Commitment to product satisfaction and support.

For further assistance or to explore our full range of replacement parts, please visit the [Spare Hardware Parts Store](#).