

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

### WILA930BLK

## Instruction Manual: Fits Pax A930 Portable Credit Card Terminal Silicone Case

Model: WILA930BLK | Brand: Generic

### 1. INTRODUCTION

This manual provides essential information for the proper use and care of your silicone protective cover designed specifically for the PAX A930 Credit Card Terminal. This cover is engineered to provide robust protection against drops and scratches, ensuring the longevity of your device. It is also static-free and fingerprint-resistant, maintaining a clean appearance.

### 2. PRODUCT FEATURES

- **Perfect Fit:** Designed for the stand-alone PAX A930 POS terminal handheld unit.
- **Enhanced Protection:** Offers superior protection against bumps, scratches, and accidental drops.
- **Durable Material:** Made from high-quality silicone, known for its durability and environmental friendliness compared to plastic.
- **Functional Design:** Allows for plug-in charging of the unit while the cover is installed.
- **Cleanliness:** Static-free and fingerprint-resistant surface.
- **Lightweight:** Weighs approximately 3.5 ounces.
- **Color:** Black.

### 3. PACKAGE CONTENTS

Your package should contain the following item:

- 1 x Silicone Protective Cover for PAX A930

*Note: The PAX A930 terminal itself is not included with this product.*

### 4. COMPATIBILITY AND LIMITATIONS

This silicone case is specifically designed for the **PAX A930** portable credit card terminal.

#### Important Limitations:

- Does **NOT** work with the PAX A920 PRO stand.

- Does **NOT** work with any charging bases or charging stations.
- Does **NOT** fit in the faux leather carrying case with shoulder strap if the silicone cover is on the terminal.
- This silicone case does **NOT** have a clear plastic cover over the terminal screen.

## 5. INSTALLATION GUIDE

To install the silicone protective cover on your PAX A930 terminal, follow these simple steps:

1. Ensure your PAX A930 terminal is clean and free of dust or debris.
2. Gently align the silicone cover with the top of your PAX A930 terminal, ensuring the cutouts for buttons and ports match.
3. Carefully stretch the silicone material over the terminal, working your way down to ensure a snug fit around the entire device.
4. Verify that all buttons (power, volume) and ports (charging port) are accessible and properly aligned with the cover's openings.





*Image 1: Front view of the silicone case, highlighting the main opening for the terminal screen and button cutouts.*





*Image 2: Back view of the silicone case, showing the cutout designed for the terminal's camera or scanner.*



*Image 3: Side profile of the silicone case, illustrating its ergonomic design and access points for side ports.*

## **6. USAGE**

Once installed, the silicone case provides continuous protection for your PAX A930 terminal during daily operation. The design ensures that all necessary functions, including screen visibility, button access, and charging via the plug-in chord, remain fully operational without needing to remove the cover.

## **7. CARE AND MAINTENANCE**

To keep your silicone case in optimal condition and maintain its protective qualities:

- **Cleaning:** Wipe the case regularly with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used. Rinse thoroughly and allow to air dry completely before re-installing on the terminal.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong chemicals, as these can damage the silicone material.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight and extreme temperatures.

## 8. TROUBLESHOOTING

If you encounter any issues with your silicone case, please review the following common points:

- **Case does not fit:** Ensure you have a PAX A930 terminal. This case is not compatible with other models like the PAX A920 PRO.
- **Cannot charge with case on:** Verify you are using a plug-in charging chord. This case is not designed for use with charging bases or stations.
- **Case feels loose:** Re-check the installation steps to ensure the case is properly stretched and aligned over the terminal.
- **Screen is not protected:** Please note that this silicone case does not include a clear plastic cover for the terminal screen. Screen protectors must be applied separately if desired.

## 9. PRODUCT SPECIFICATIONS

Attribute	Detail
Product Name	Silicone Protective Case for PAX A930
Model Number	WILA930BLK
Brand	Generic
Material	Silicone
Color	Black
Compatible Devices	PAX A930
Product Dimensions (L x W x H)	8 x 3.5 x 2.75 inches
Item Weight	3.5 ounces
Manufacturer	WIL
ASIN	B0C768S1F6
Date First Available	June 5, 2023

## 10. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. For any support inquiries or further assistance, please refer to the seller or manufacturer's contact information provided at the point of purchase.

© 2023 Generic. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.

Documents - WILA930BLK – WILA930BLK

no relevant documents