

[Manuals.plus](#) /

› [BXROIU](#) /

› BXROIU ES-LCL-088 Battery Operated Fairy String Lights User Manual

BXROIU ES-LCL-088

BXROIU ES-LCL-088 Battery Operated Fairy String Lights User Manual

Model: ES-LCL-088 | Brand: BXROIU

INTRODUCTION

Thank you for choosing BXROIU Battery Operated Fairy String Lights. This manual provides essential information for the safe and effective use of your new lighting product. Please read these instructions carefully before installation and operation, and retain them for future reference.

SAFETY INFORMATION

- Ensure batteries are inserted with correct polarity (+/-). Incorrect insertion can cause damage.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the product is not used for an extended period to prevent leakage.
- Keep batteries and small parts out of reach of children to prevent choking hazards.
- The string lights are waterproof (IP65 rated for the wire part), but the battery box should be protected from heavy rain or immersion in water.
- Do not attempt to modify or repair the product. Contact customer support if issues arise.

PACKAGE CONTENTS

- 4 x 5M (16.4ft) Silver Wire Fairy String Lights with 50 LEDs each
- 4 x Battery Boxes (requires 3 AAA batteries each, not included)
- 4 x Remote Controls (each with 1 Lithium Metal battery included)

SETUP

1. Battery Installation (Fairy Lights)

1. Open the battery compartment on each battery box.
2. Insert 3 new AAA batteries into each compartment, ensuring correct polarity.
3. Close the battery compartment securely.

2. Remote Control Battery

Each remote control comes with a pre-installed Lithium Metal button cell battery. Remove the plastic tab from the battery compartment before first use.



Image: A single set of BXROIU fairy lights, showing the coiled silver wire, the clear battery box, and the remote control. The battery box is open, revealing the battery slots.

OPERATING INSTRUCTIONS

1. Powering On/Off

- **On Battery Box:** Press the button on the battery box to cycle through modes and turn the lights On/Off.
- **Using Remote Control:** Press the 'ON' button (green) to turn the lights on, and the 'OFF' button (red) to turn them off.

2. Lighting Modes

Your fairy lights feature 8 distinct lighting modes. You can cycle through these modes using the button on the battery box or the 'MODE' button/numbered buttons (1-8) on the remote control.




Image: A detailed diagram of the remote control, highlighting buttons for Power On/Off, Timer, Mode selection (1-8), and Brightness adjustment.

1. Combination
2. In Waves
3. Sequential
4. Slow Glow
5. Chasing/Flash
6. Slow Fade
7. Twinkle/Flash
8. Steady On

3. Timer Function

To activate the timer, press the 'TIMER' button on the remote control. The lights will flicker once to confirm activation. Once set, the lights will automatically turn on for 6 hours and then turn off for 18 hours, repeating this cycle daily. To deactivate the timer, press the 'TIMER' button again.

4. Brightness Adjustment

Use the 'DIM -' and 'DIM +' buttons on the remote control to adjust the brightness level of the lights.

MAINTENANCE

1. Battery Replacement

When the lights dim or stop working, replace all 3 AAA batteries in the battery box with new ones. Ensure correct polarity.

2. Cleaning

Wipe the lights and battery box with a soft, dry cloth. Do not use abrasive cleaners or immerse the battery box in water.

3. Storage

When not in use, store the fairy lights in a cool, dry place, away from direct sunlight and moisture. Remove batteries if storing for an extended period.

TROUBLESHOOTING

- **Lights not turning on:** Check if batteries are inserted correctly and are not depleted. Ensure the remote control's plastic tab is removed and its battery is functional.
- **Remote not working:** Ensure there are no obstructions between the remote and the battery box. Check the remote's battery.
- **Lights flickering unexpectedly:** This may indicate low battery power. Replace batteries.

SPECIFICATIONS

Feature	Detail
Model Number	ES-LCL-088
Light Color	Warm White
Number of LEDs per String	50
String Length	5 Meters (16.4 feet)
Wire Material	Silver Wire
Power Source	3 x AAA Batteries (not included) per unit
Special Features	8 Lighting Modes, Remote Controlled, Timer (6H On/18H Off), Dimmable
Waterproof Rating	IP65 (for string lights, battery box is not fully waterproof)
Voltage	4.5 Volts
Wattage	3.5 Watts

WARRANTY & SUPPORT

For warranty information or technical support, please refer to the product packaging or contact BXROIU customer service directly. Keep your purchase receipt for any warranty claims.

USAGE EXAMPLES

These versatile fairy lights can be used for various decorative purposes, both indoors and outdoors (with proper battery box protection).



Image: A collage showing different applications of the fairy lights, such as wrapped around plants, placed inside glass cloches, forming a heart shape on a wall, and illuminating a bicycle-shaped decor item.

