

[Manuals.plus](#) /

› [EASYTONE](#) /

› EASYTONE X88 PRO 13 Android TV Box User Manual

EASYTONE X88 PRO 13

EASYTONE X88 PRO 13 Android TV Box User Manual

Model: X88 PRO 13

1. PRODUCT OVERVIEW

The EASYTONE X88 PRO 13 is an advanced Android TV Box designed to transform your television into a smart entertainment hub. It operates on the Android 13.0 OS, powered by a robust RK3528 Quad-Core chipset, offering enhanced performance and compatibility with modern applications. This device supports 8K Ultra HD resolution and HDR10+ decoding for superior visual quality. Connectivity features include WiFi 6 dual-band (2.4G/5.8G), Bluetooth 5.0, and USB 3.0 for high-speed data transfer. A mini wireless backlit keyboard is included for convenient navigation and input.

2024 Android 13 TV Box

5G Dual Band High Speed WIFI
Linkable 2.4G 5G WIFI

5G

WI FI 6

HDR10+

4GB+32GB

8K

Real Brightness
Ultra-clear picture quality

RK3528

RK3528 Quad-Core
64bit Cortex-A53

Image: The EASYTONE X88 PRO 13 Android TV Box, showcasing its compact design and included remote control.

2. PACKAGE CONTENTS

- EASYTONE X88 PRO 13 Android TV Box
- Remote Control
- Power Adapter (DC 5V/2A)
- HDMI Cable
- Mini Wireless Backlit Keyboard (with USB receiver)
- User Manual (this document)

3. SETUP GUIDE

Follow these steps to set up your EASYTONE X88 PRO 13 Android TV Box:

1. **Connect the HDMI Cable:** Insert one end of the HDMI cable into the HDMI port on the TV Box and the other end into an available HDMI input on your television. Note the HDMI input number (e.g., HDMI 1, HDMI 2) for later selection on your TV.
2. **Connect the Power Adapter:** Plug the DC 5V/2A power adapter into the power input port on the TV Box, then plug the adapter into a wall outlet. The device should power on automatically, or you may need to press the power button on the remote control.
3. **Connect to Network:** Once the device boots up, navigate to the network settings. You can connect via:
 - **Wi-Fi:** Select your Wi-Fi network from the list, enter the password, and connect. The device supports WiFi 6 dual-band (2.4G/5.8G) for fast and stable connections.
 - **Ethernet:** Connect an Ethernet cable from your router to the LAN port on the TV Box for a wired internet connection.

Easy To Set Up With 3 Steps



1. Connect the HDMI cable



2. Connect the power adapter



3. Connect to Wi-Fi or Ethernet and enjoy

Image: A visual representation of the three-step setup process: 1. Connect HDMI, 2. Connect power, 3. Connect to Wi-Fi or Ethernet.

4. OPERATING INSTRUCTIONS

4.1 Navigating the Interface

Use the provided remote control or the mini wireless keyboard to navigate the Android 13.0 interface. The home screen typically displays frequently used apps, settings, and media options. The mini wireless keyboard simplifies text input for searches and app logins.

4.2 Installing Applications

Access the pre-installed App Store or Google Play Store to download and install your preferred streaming services, games, and utility applications. Ensure you are logged into your Google account for full access to the Play Store.

4.3 Media Playback and Display

The X88 PRO 13 supports 8K Ultra HD video decoding and HDR10+ processing, delivering high-quality visuals. Ensure your television is 8K or 4K compatible to fully utilize these features. Adjust display settings in the system menu if needed.




Image: A split screen showing the visual improvement from standard definition to 8K decoding content on a television screen.

H.265 HDR10+ Processing Technology



AI SR Technology
Enhanced picture clarity



Smooth+ Technology
Keep detailed images



Tone Mapping Technology
Display stunning visuals



SDR



HDR10



Image: Diagram illustrating the benefits of H.265 HDR10+ processing technology, including enhanced picture clarity, detailed images, and stunning visuals compared to SDR.

4.4 Screen Mirroring

The device supports Airplay, DLNA, and Miracast protocols, allowing you to mirror content from compatible smartphones, tablets, or computers directly to your TV screen.

Mirror Your Likes Anytime



Image: A smartphone mirroring its display to a large television screen via the Android TV Box, illustrating Airplay, DLNA, and Miracast capabilities.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the TV Box. Avoid liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the TV Box is placed in a well-ventilated area to prevent overheating. Do not block ventilation openings.
- **Software Updates:** Periodically check for system updates in the device settings to ensure optimal performance and access to the latest features and security patches.
- **Storage:** Avoid storing the device in extreme temperatures or high humidity.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power/Device does not turn on	Power adapter not connected or faulty; Power outlet issue.	Ensure power adapter is securely connected to the device and a working power outlet. Try a different outlet.
No display on TV	HDMI cable loose or faulty; Incorrect TV input selected.	Check HDMI cable connections. Ensure your TV is set to the correct HDMI input source. Try a different HDMI cable or port.
No Wi-Fi connection	Incorrect Wi-Fi password; Router issues; Device too far from router.	Verify Wi-Fi password. Restart your router. Move the TV Box closer to the router or use an Ethernet cable.
Remote control not responding	Low batteries; Obstruction between remote and device.	Replace batteries in the remote control. Ensure no objects are blocking the signal path.
System freezes or lags	Too many apps running; Insufficient storage; Software issue.	Close unnecessary applications. Clear cache. Consider a factory reset if issues persist (back up data first).

7. SPECIFICATIONS

Feature	Detail
Brand	EASYTONE
Model	X88 PRO 13
Operating System	Android 13.0 OS
Processor	RK3528 Quad-Core 64bit
RAM	4 GB
Internal Storage	32 GB (Expandable via Micro SD card up to 64GB)
Video Output	8K Ultra HD, HDR10+
Wi-Fi	WiFi 6 Dual-Band (2.4G/5.8G)
Bluetooth	Bluetooth 5.0
Ethernet	100M
USB Ports	1x USB 3.0 (Type-A), 1x USB 2.0 (Type-A)
HDMI	HDMI 2.0
Power Source	DC 5V/2A
Special Features	Browser, DLNA, Miracast

Upgraded Various Interfaces

Simple and practical user interface, multiple useful ports connection




Image: Close-up view of the Android TV Box's various ports, including USB 3.0 and HDMI 2.1, highlighting its connectivity options.

Fast Wi-Fi 6 Technology

Wi-Fi 6



Image: Graphic illustrating the speed advantage of Wi-Fi 6 technology compared to Wi-Fi 5, showing the X88 PRO 13 device.

5G

2.4G+5G Dual Wi-Fi

Dual-frequency transmission with less buffering



Image: Visual representation of the 2.4G and 5G dual-band Wi-Fi capabilities, indicating dual-frequency transmission with less buffering.

8. TECHNICAL SUPPORT

For any technical assistance or inquiries regarding your EASYTONE X88 PRO 13 Android TV Box, please refer to the dedicated technical support provided by EASYTONE. Contact information can typically be found on the product packaging or the official EASYTONE website. Our team is committed to providing prompt and effective solutions to ensure your satisfaction.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question