

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Smoby](#) /

› [Smoby Little Activity Cube Instruction Manual](#)

Smoby 7600140306

Smoby Little Activity Cube Instruction Manual

Model: 7600140306

INTRODUCTION

This instruction manual provides essential information for the safe and effective use of your Smoby Little Activity Cube. Please read this manual thoroughly before assembly and use, and retain it for future reference. This activity cube is designed to support the development of motor skills and sensory exploration in toddlers.

SAFETY INFORMATION

- **Age Recommendation:** This product is not suitable for children under 12 months of age.
- **Adult Supervision:** Always ensure adult supervision during play to prevent accidents.
- **Inspection:** Before each use, inspect the activity cube for any damage or loose parts. Discontinue use if any damage is found.
- **Cleaning:** Clean the product regularly with a damp cloth. Do not immerse in water.
- **Placement:** Use the activity cube on a flat, stable surface.

PACKAGE CONTENTS

Verify that all components are present in the package:

- 1 x Smoby Little Activity Cube
- 4 x Shape Sorter Blocks



Image: The complete Smoby Little Activity Cube, showing its various interactive elements and the four accompanying shape sorter blocks.

SETUP

The Smoby Little Activity Cube requires minimal assembly. Follow these steps to prepare the cube for play:

1. Carefully remove all components from the packaging.
2. Ensure all protective films or ties are removed.
3. Attach any detachable elements, such as the bead maze or koala spinner, to their designated slots on the cube. Refer to the diagram for proper placement.
4. Confirm all parts are securely fastened before allowing a child to play.



Image: An overview of the activity cube highlighting its various interactive features and their locations, useful for assembly reference.

OPERATING THE ACTIVITY CUBE

The Smoby Little Activity Cube offers over 13 different activities across its five faces, designed to engage and develop your child's motor skills and cognitive abilities.

Key Activities:

- **Shape Sorter:** The cube includes four distinct shapes (square, triangle, hexagon, flower-like) and corresponding slots. Encourage your child to match each shape to its correct opening. The shapes can be stored inside the cube through a small door.



Image: A close-up view of the four unique shape sorter blocks, each with a different animal illustration.



Image: A child's hand demonstrating the insertion of a blue square shape into its corresponding slot on the activity cube.

- **Abacus:** A set of colorful beads on a wire track allows children to practice counting and develop fine

motor skills by sliding the beads.

- **Gears:** Interlocking gears can be turned, demonstrating cause and effect and improving hand-eye coordination.
- **Paddle Wheel:** A rotating paddle wheel provides tactile stimulation and encourages grasping.
- **Koala Spinner:** A small koala figure that can be turned, adding a playful element.
- **Hide-and-Seek Turtle:** A movable turtle shell that reveals a hidden image or texture underneath.
- **Butterfly Mirror:** A small mirror shaped like a butterfly for self-discovery.
- **Criccrac Flower and Ladybird:** Interactive elements that make sounds or movements when manipulated.



Image: A toddler engaging with the activity cube, specifically interacting with the side featuring the door and shape sorter openings.



Image: A toddler interacting with the top surface of the activity cube, concentrating on the bead maze and other top-mounted features.

MAINTENANCE

- **Cleaning:** Wipe the activity cube with a soft, damp cloth and mild soap if necessary. Rinse thoroughly with a clean damp cloth to remove soap residue. Do not use abrasive cleaners or solvents.
- **Drying:** Allow all parts to air dry completely before storing or allowing further use.
- **Storage:** Store the activity cube in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation.

TROUBLESHOOTING

If you encounter any issues with your Smoby Little Activity Cube, please refer to the following common solutions:

- **Loose Parts:** Regularly check all components for tightness. If any part becomes loose or detached, reattach it securely. If a part is broken or cannot be reattached, discontinue use and contact customer support.

- **Missing Parts:** If any parts were missing upon unboxing, please contact Smoby customer support immediately.
- **Difficulty with Activities:** Ensure the child is within the recommended age range (12 months - 3 years). Some activities may require more developed fine motor skills. Encourage exploration and provide guidance.

Note: Smoby offers a spares service for replacement parts. Contact customer support for more information.

SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	11.38 x 10.79 x 15.55 inches (approx. 29 x 27 x 39 cm)
Item Weight	2.11 pounds
Model Number	7600140306
Recommended Age	12 months - 3 years
Material	Durable Plastic
Manufacturer	SMOBY







Image: A technical drawing illustrating the dimensions of the Smoby Little Activity Cube.


WARRANTY AND SUPPORT

Smoby products are manufactured to high-quality standards. For information regarding warranty coverage, replacement parts, or customer support, please visit the official Smoby website or contact their customer service department directly. Keep your proof of purchase for any warranty claims.

For further assistance, please refer to the contact information provided on the product packaging or the official Smoby website.

Related Documents - 7600140306

	<p>Smoby Bercelonnette Assembly Instructions and Safety Guide</p> <p>Detailed assembly instructions and safety information for the Smoby Bercelonnette toy. Includes part identification, step-by-step assembly guides, and important warnings for safe use.</p>
	<p>Smoby Pushchair + Pram Assembly Instructions</p> <p>Step-by-step guide for assembling the Smoby Pushchair + Pram (Model 03291X0/15). Includes important safety information, part identification, and assembly procedures.</p>
	<p>Smoby Baby Nurse Toilet Assembly Instructions and Safety Guide</p> <p>Comprehensive assembly instructions and safety warnings for the Smoby Baby Nurse Toilet toy. Learn how to assemble the play toilet with clear steps and component identification.</p>
	<p>Smoby Baby Nurse Large Doll's Play Centre Assembly Instructions</p> <p>Detailed step-by-step assembly guide for the Smoby Baby Nurse Large Doll's Play Centre, including part identification and safety warnings. This manual helps users assemble the toy safely and correctly.</p>
	<p>Smoby Landau Calin Baby Doll Stroller Assembly Instructions</p> <p>This document provides comprehensive assembly instructions for the Smoby Landau Calin baby doll stroller. It details the parts included, offers step-by-step guidance for assembly, and highlights crucial safety warnings for safe usage.</p>



[Smoby Baby Nurse Electronic Doll Bath - Assembly Instructions and Safety Guide](#)

Comprehensive guide for assembling and safely using the Smoby Baby Nurse Electronic Doll Bath (Model AAP2330C), including parts list, step-by-step instructions, and important safety warnings for children.