

Fossil FS6008

Fossil Men's Carraway Quartz Stainless Steel Three-Hand Watch User Manual

Model: FS6008

1. PRODUCT OVERVIEW

The Fossil Carraway wristwatch is a classic men's timepiece featuring a sleek dial, a curved rectangular case, and a durable stainless steel bracelet. Its mineral crystal lens is designed to resist scratches, ensuring clarity. The watch utilizes a three-hand analog display for reliable timekeeping. It is water-resistant up to 50 meters (5 ATM), making it suitable for short periods of recreational swimming and showering, but not for diving or snorkeling. This watch is designed for everyday wear, combining timeless style with practical functionality.

Key Features:

- **Timeless Design:** Features a two-layered dial, curved case, and a 7-link stainless steel bracelet for comfort and classic appeal.
- **Durable Construction:** 32mm case with a hardened mineral crystal lens to resist scratches.
- **Accurate Timekeeping:** Quartz movement with a three-hand analog display.
- **Water Resistance:** Rated up to 50m (5 ATM), suitable for recreational swimming and showering.
- **Adjustable Bracelet:** Silver stainless steel bracelet with a fold-over clasp closure. Links can be removed for a customized fit.






Figure 1: Front view of the Fossil Carraway watch, showcasing the rectangular silver case, white dial with Roman numerals, and blue hands.

2. SETUP

2.1 Initial Setup

Your Fossil Carraway watch comes with a pre-installed battery. To activate the watch and set the time, follow the instructions below.

2.2 Setting the Time

1. Locate the crown on the right side of the watch case.

2. Gently pull the crown outwards until you feel a click. This is the time-setting position.
3. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
4. Once the time is set, push the crown back into its original position to engage the movement and start the watch.





Figure 2: Side view of the watch, highlighting the crown used for setting the time.

2.3 Adjusting the Bracelet

The stainless steel bracelet is designed to be adjustable for a comfortable fit. If the watch is too loose or too tight, links can be added or removed. This process typically requires specialized tools and is best performed by a professional jeweler to avoid damaging the bracelet or watch. The bracelet features a secure fold-over clasp closure.





Figure 3: Back view of the watch bracelet, showing the fold-over clasp with the Fossil logo.

3. OPERATING THE WATCH

The Fossil Carraway watch features a simple three-hand analog display. Once the time is set, the watch will continuously display the current hour, minute, and second.

- The **hour hand** (short hand) indicates the hour.
- The **minute hand** (long hand) indicates the minute.
- The **second hand** (thin, sweeping hand) indicates the seconds.

Ensure the crown is fully pushed in after setting the time to maintain water resistance and proper operation.

4. MAINTENANCE

4.1 Cleaning Your Watch

To maintain the appearance of your watch, regularly wipe the case and bracelet with a soft, dry cloth. For stainless steel, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

4.2 Water Resistance

This watch is water-resistant up to 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming and showering. However, it is **not** suitable for diving, snorkeling, or high-impact water sports. Always ensure the crown is fully pushed in before any contact with water. Exposure to hot water, steam, or chemicals (like soap or shampoo) can compromise the water resistance over time.

4.3 Battery Replacement

The watch is powered by a quartz movement and requires a 12V battery (included). When the battery runs low, the watch hands may stop or operate erratically. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

5. TROUBLESHOOTING

- **Watch Not Running:**
 - Check if the crown is fully pushed in. If it's pulled out, the watch will not run.
 - The battery may need replacement. Consult a professional watch technician.
- **Incorrect Time:**
 - Adjust the time as described in Section 2.2.
 - If the time consistently runs fast or slow after adjustment, the movement may require servicing.
- **Condensation Under Crystal:**
 - This indicates a breach in water resistance. Avoid further contact with water and seek immediate professional service to prevent internal damage.

6. SPECIFICATIONS

Model Number:	FS6008
Case Size:	32MM
Band Width:	22mm
Movement:	Quartz (Three-Hand Analog)
Water Resistance:	5 ATM (50 meters / 165 feet)
Crystal Type:	Mineral Crystal
Case Material:	Stainless Steel
Band Material:	Stainless Steel
Battery:	1 x 12V (included)



Figure 4: The Fossil Carraway watch worn on a wrist, illustrating its size and appearance in use.



Figure 5: Case Size Guide for watches, illustrating different diameters on a wrist for reference.

7. WARRANTY AND SUPPORT

Fossil watches are typically covered by a limited warranty that protects against defects in materials and workmanship under normal use. For specific warranty details, service, or support, please refer to the official Fossil website or contact their customer service. You can find more information and contact details on the official Fossil store page: [Fossil Watches Store](#).

