

[Manuals.plus](#) /

› [Benzara](#) /

› Benzara 19-inch Wood Dining Chair (Set of 2) Instruction Manual

Benzara BM296029

Benzara 19-inch Wood Dining Chair (Set of 2) Instruction Manual

Model: BM296029

INTRODUCTION

This manual provides essential information for the safe assembly, use, and maintenance of your Benzara 19-inch Wood Dining Chair set (Model BM296029). Please read all instructions carefully before assembly and retain this manual for future reference.



Front view of the Benjara 19-inch Wood Dining Chair.

SAFETY INFORMATION

Your safety is paramount. Please observe the following safety guidelines:

- Always ensure all components are securely fastened before using the chair.
- Do not stand on the chair. It is designed for seating only.
- Keep the chairs away from open flames, excessive heat sources, and prolonged direct sunlight.
- Avoid exposing the chairs to excessive moisture or humidity.

- Regularly inspect the chairs for any loose parts, damage, or wear. Tighten any loose fasteners immediately.
- Do not exceed the recommended weight capacity (specific weight capacity not provided, use with reasonable care).

PACKAGE CONTENTS

Your package should contain the following items:

- Two (2) Benjara 19-inch Wood Dining Chairs (disassembled).
- Assembly Hardware (bolts, washers, nuts, Allen wrench).
- Instruction Manual (this document).

Please verify all parts are present and undamaged before proceeding with assembly. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

SETUP AND ASSEMBLY

Follow these steps to assemble your Benjara dining chairs:

1. **Unpack Components:** Carefully unpack all components from the packaging. Lay them out on a clean, soft, non-abrasive surface (e.g., a carpet or blanket) to prevent scratches or damage during assembly.
2. **Identify Hardware:** Separate and identify all hardware pieces (bolts, washers, nuts) according to the included hardware list.
3. **Attach Legs to Seat Frame:** Securely attach the chair legs to the underside of the seat frame using the provided bolts and washers. Insert bolts through the designated holes and hand-tighten them initially. Do not fully tighten at this stage.
4. **Attach Backrest:** Connect the backrest to the seat frame and rear legs. Align the holes and insert the remaining bolts and washers. Hand-tighten these bolts as well.
5. **Final Tightening:** Once all components are loosely assembled, place the chair upright on a level surface. Gradually and evenly tighten all bolts using the provided Allen wrench until they are secure. Avoid overtightening, as this can damage the wood.
6. **Stability Check:** Ensure the chair is stable and level. If it wobbles, loosen the bolts slightly, press down on the seat to settle the frame, and then re-tighten the bolts.



Refer to dimensions during assembly for proper orientation.

OPERATING AND USAGE

The Benjara dining chairs are designed for comfortable seating at a dining table or similar surface. To ensure proper use and longevity:

- Always place the chair on a flat, stable surface to prevent tipping.
- Avoid leaning back excessively or rocking on the chair, as this can compromise its stability and structural integrity.
- Do not use the chair as a step stool or for any purpose other than seating.
- When moving the chair, lift it rather than dragging it to prevent damage to the legs and floor.

MAINTENANCE

Proper care will help maintain the appearance and extend the life of your dining chairs:

Cleaning

- **Wood Frame:** Wipe the wood frame with a soft, slightly damp cloth. For stubborn dirt, use a mild wood cleaner. Avoid abrasive cleaners or harsh chemicals, as they can damage the finish. Dry immediately with a clean cloth.
- **Upholstery:** For general cleaning, vacuum the upholstered areas regularly using a soft brush attachment to remove dust and debris. For spills, blot immediately with a clean, dry cloth. For spot cleaning, use a mild fabric cleaner specifically designed for upholstery. Always test the cleaner on an inconspicuous area first to ensure it does not cause discoloration or damage.

Care

- Protect the chairs from prolonged exposure to direct sunlight to prevent fading of the upholstery and wood finish.
- Keep chairs away from direct heat sources like radiators or fireplaces, which can cause wood to dry out and crack.
- Periodically check all fasteners (bolts, screws) and tighten them as needed to ensure the chair remains stable and secure.

TROUBLESHOOTING

If you encounter any issues with your dining chairs, refer to the following common solutions:

- **Wobbling Chair:** If the chair wobbles after assembly, ensure all bolts are tightened evenly. Sometimes, loosening all bolts slightly, sitting on the chair to settle the frame, and then re-tightening them can resolve the issue. If the floor is uneven, consider using furniture pads or glides under the legs.
- **Loose Parts:** If any screws or bolts become loose over time, re-tighten them immediately to prevent further damage or instability.
- **Squeaking:** Squeaking can sometimes be caused by loose joints. Try tightening all fasteners. If the issue persists, carefully disassemble and reassemble the affected joint, ensuring all parts are correctly aligned.

SPECIFICATIONS

Model Number	BM296029
Item Weight	34 pounds (for the set)
Product Dimensions	22.5 x 19 x 34 inches (Length x Width x Height)
Materials	Solid Wood, Fabric Upholstery, Plush Cushioning
Style	Modern, Transitional
Color	Beige Upholstery, Black Wood Frame

WARRANTY AND SUPPORT

For specific warranty information, terms, and conditions, please refer to the documentation included with your purchase or the retailer's website where you acquired this product. Keep your proof of purchase (receipt or order confirmation) as it may be required for any warranty claims or customer support inquiries. If you require assistance with assembly, have questions about product care, or need to report a

missing/damaged part, please contact the retailer or manufacturer's customer service department directly.

© 2023 Benzara. All rights reserved.