

VA-GS-V2421

Grey Shaker Sink Base Bathroom Vanity - Instruction Manual

Brand: Generic | Model: VA-GS-V2421

1. INTRODUCTION

Thank you for choosing the Grey Shaker Sink Base Bathroom Vanity. This manual provides essential information for the safe assembly, installation, operation, and maintenance of your new vanity. Please read all instructions carefully before beginning assembly or use to ensure proper function and longevity of the product.



Image 1.1: The Grey Shaker Sink Base Bathroom Vanity, showcasing its design and fit within a bathroom environment. Note that the sink, faucet, and handles are not included with the vanity base.

2. SAFETY INFORMATION

⚠ Always follow the assembly instructions carefully to avoid injury. Be cautious of fingers when closing doors to prevent pinching. Ensure the vanity is securely mounted to the wall to prevent tipping. Do not overload the vanity; it has a weight limit of 46 pounds.

- Keep all small parts and packaging materials away from children.
- Use appropriate tools and safety gear during assembly.
- Ensure the installation surface is level and capable of supporting the vanity's weight.
- Do not stand on or climb inside the vanity.

3. PRODUCT OVERVIEW

The Grey Shaker Sink Base Bathroom Vanity is designed with both aesthetics and durability in mind. It features a classic Shaker door style with a robust construction.

Key Features:

- **Solid Wood Doors & Drawer Front:** Crafted from solid wood birch with an MDF center core panel for enhanced quality and durability.
- **Plywood Box Construction:** The cabinet box is constructed entirely from plywood, providing exceptional sturdiness and longevity.
- **Soft Close Concealed Hinges:** Equipped with six-way adjustable concealed hinges that feature a soft-close function to prevent slamming and reduce wear.
- **Ready-To-Assemble (RTA):** Designed for convenient assembly.



Image 3.1: Internal construction details highlighting the plywood box, solid wood door with MDF core, and soft-closing adjustable concealed hinges.

4. COMPONENTS LIST

Before beginning assembly, ensure all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

Included Components:

- Vanity Base Cabinet (unassembled panels)
- Necessary Hardware (screws, hinges, etc.)
- Instruction Manual

Items NOT Included (Sold Separately):

- Sink
- Faucet
- Handles
- Vanity Top (Matching Stone Resin Vanity Top 25"W x 22"D available separately)



Image 4.1: Visual representation of included components (vanity base, hardware) and items not included (sink top, faucet, handles).

5. ASSEMBLY AND SETUP

This vanity is designed for Ready-To-Assemble (RTA) installation. Follow the detailed instructions provided in the included instruction manual for step-by-step assembly. Ensure you have adequate space and the necessary tools before starting.

General Assembly Steps:

1. **Unpack and Organize:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the assembly diagram.

2. **Assemble the Box:** Follow the instructions to connect the plywood side panels, back panel, and base using the provided hardware. Ensure all connections are secure.
3. **Install Doors:** Attach the solid wood doors using the soft-close concealed hinges. Adjust the hinges as needed for proper alignment and smooth operation.
4. **Install Vanity Top (Sold Separately):** Once the vanity base is assembled and in place, carefully install your chosen vanity top according to its specific instructions.
5. **Secure to Wall:** For stability and safety, it is highly recommended to secure the vanity to the wall using appropriate anchors and screws (not included).



Image 5.1: Dimensional drawing of the vanity, indicating its width (24"), depth (21"), and height (34.5").

6. OPERATION

The Grey Shaker Sink Base Bathroom Vanity is designed for straightforward use. Its primary operational features involve the doors and any installed drawers (if applicable to your specific model).

Soft-Close Hinges:

The vanity is equipped with soft-close concealed hinges. These hinges allow the doors to close gently and quietly, preventing slamming and reducing wear and tear. Simply push the door gently, and the soft-close mechanism will engage, slowly pulling the door shut.



Image 6.1: The vanity with its doors closed, demonstrating the clean lines of the Shaker design.



Image 6.2: The vanity with its doors open, showcasing the accessible storage area beneath the sink.

7. CARE AND MAINTENANCE

Proper care and maintenance will help preserve the beauty and functionality of your vanity for years to come.

Cleaning:

- For general cleaning, wipe surfaces with a soft, damp cloth.
- Use a mild, non-abrasive cleaner if necessary. Avoid harsh chemicals, ammonia-based cleaners, or abrasive pads, as these can damage the finish.
- Immediately wipe up any spills, especially water, to prevent moisture damage to the wood and finish.
- Dry all surfaces thoroughly after cleaning.

General Maintenance:

- Periodically check all screws and hardware to ensure they remain tight. Tighten if necessary.
- Inspect hinges for smooth operation. If doors become misaligned, adjust the six-way adjustable hinges as needed.
- Avoid placing excessively hot or cold items directly on the vanity surface without protection.

8. TROUBLESHOOTING

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Doors do not close properly or are misaligned.	Loose hinges; improper hinge adjustment.	Tighten hinge screws. Adjust the six-way adjustable hinges to align the doors.
Soft-close function is not working.	Hinge mechanism obstructed or damaged.	Check for obstructions. If damaged, contact customer support for replacement hinges.
Vanity feels wobbly.	Not securely fastened to the wall; uneven floor.	Ensure the vanity is securely anchored to wall studs. Use shims under the base if the floor is uneven.
Scratches or chips on the finish.	Impact or abrasive cleaning.	For minor scratches, touch-up paint may be available from the manufacturer. Prevent future damage by using soft cloths for cleaning and avoiding sharp objects.

9. SPECIFICATIONS

Attribute	Detail
Brand	Generic
Model Name	VA-GS-V2421
Color	Grey
Product Dimensions	21"D x 24"W x 34.5"H
Item Weight	46 Pounds
Mounting Type	Floor Mount
Installation Type	Freestanding
Room Type	Bathroom, Laundry Room
Door Style	Shaker
Frame Material	3/4" Thick solid wood semi-full overlay
Top Material Type	Plywood (for cabinet top, not vanity top)

Attribute	Detail
Back Material Type	Engineered Wood
Assembly Required	Yes
Number of Shelves	1
Base Type	Toe Kick
Finish Type	Painted

10. WARRANTY INFORMATION

Specific warranty details for this product are not provided in this manual. For information regarding warranty coverage, terms, and conditions, please refer to the product packaging, contact the seller (Vanity Atelier), or visit the manufacturer's official website.

11. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact the seller, Vanity Atelier, through the platform where the product was purchased. Please have your model number (VA-GS-V2421) and purchase details ready when contacting support.

© 2023 Generic. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C78B8WTV>

More documents and user manuals: <https://manuals.plus/>