

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GLOBE](#) /

› [GLOBE Electric Devo 2-Light Flush Mount Ceiling Light Instruction Manual](#)

GLOBE 66000081

GLOBE Electric Devo 2-Light Flush Mount Ceiling Light Instruction Manual

Model: 66000081



PRODUCT OVERVIEW

The GLOBE Electric Devo 2-Light Flush Mount Ceiling Light (Model 66000081) is designed to provide elegant and versatile lighting for various indoor spaces. This fixture features a matte brass finish and a tiered white milk glass shade, offering a sophisticated aesthetic. Its flush mount design is suitable for rooms with standard or lower ceilings, making it an ideal choice for bedrooms, dining rooms, hallways, and entryways. The light is compatible with two E12 base 40W bulbs (sold separately) and supports dimming with a compatible dimmer switch (also sold separately).



Image: Front view of the GLOBE Electric Devo 2-Light Flush Mount Ceiling Light, showcasing its matte brass band and tiered white milk glass shade.



Image: The light fixture installed on a ceiling in a modern living room setting, demonstrating its flush mount profile.

SAFETY INFORMATION

- Always turn off the main power supply at the circuit breaker before beginning installation or performing any maintenance.
- Consult a qualified electrician if you are unsure about the installation process.
- Use only E12 base bulbs with a maximum wattage of 40W per bulb.
- Ensure all electrical connections are secure and comply with local electrical codes.
- This fixture is designed for indoor use only and is not water resistant. Do not install in damp or wet locations.
- Handle glass components with care to prevent breakage.

INCLUDED COMPONENTS

Before beginning assembly, ensure all parts are present and undamaged. Refer to the included instruction sheet for a

detailed parts list.

- Flush Mount Ceiling Light Fixture (Matte Brass Finish)
- Tiered White Milk Glass Shade
- Mounting Hardware (screws, wire nuts, mounting bracket)
- Instruction Sheet

Note: E12 base 40W max bulbs and a compatible dimmer switch are **not** included and must be purchased separately.

SETUP AND INSTALLATION

Tools Required (Not Included):

- Phillips Head Screwdriver
- Wire Strippers
- Electrical Tape (optional)
- Ladder

Installation Steps:

1. **Turn Off Power:** Locate the circuit breaker controlling the light fixture's circuit and turn it off. Verify power is off using a voltage tester.
2. **Prepare Mounting Surface:** If replacing an existing fixture, carefully remove it. Ensure the junction box is securely mounted and capable of supporting the fixture's weight.
3. **Attach Mounting Bracket:** Secure the provided mounting bracket to the junction box using the screws provided. Ensure the bracket is flush and stable.
4. **Make Electrical Connections:**
 - Connect the fixture's black wire (live) to the black wire from the junction box using a wire nut.
 - Connect the fixture's white wire (neutral) to the white wire from the junction box using a wire nut.
 - Connect the fixture's ground wire (bare copper or green) to the ground wire from the junction box (or to the green ground screw on the mounting bracket).
 - Ensure all connections are tight and secure. Wrap wire nuts with electrical tape for added security if desired.
5. **Mount the Fixture:** Carefully tuck all wires into the junction box. Align the fixture with the mounting bracket and secure it using the provided screws.
6. **Install Glass Shade:** Gently attach the tiered white milk glass shade to the fixture according to the specific instructions in the included sheet. Ensure it is securely fastened.
7. **Install Bulbs:** Screw two E12 base 40W max bulbs (sold separately) into the sockets.
8. **Restore Power:** Turn the main power supply back on at the circuit breaker. Test the light fixture.




Image: Diagram showing the dimensions of the light fixture: 11.8 inches (30 cm) in diameter and 4.5 inches (11.5 cm) in height.

OPERATING INSTRUCTIONS

The GLOBE Electric Devo 2-Light Flush Mount Ceiling Light operates via a standard wall switch. For dimming functionality, ensure a compatible dimmer switch is installed.

- **Turning On/Off:** Use the wall switch connected to the fixture to turn the light on or off.
- **Dimming (Optional):** If a compatible dimmer switch is installed, adjust the dimmer control to achieve the desired light intensity. Ensure that the E12 bulbs used are also dimmable.

MAINTENANCE

• Cleaning:

Before cleaning, ensure the power to the fixture is turned off at the circuit breaker. Wipe the metal parts with a soft, dry cloth. For the glass shade, use a soft, damp cloth with a mild, non-abrasive cleaner if necessary, then dry thoroughly. Avoid using harsh chemicals or abrasive cleaners as they may damage the finish or glass.

• Bulb Replacement:

Turn off the power at the circuit breaker. Allow bulbs to cool completely before touching. Carefully unscrew the old E12 bulbs and screw in new E12 base 40W max bulbs. Do not overtighten. Restore power after replacement.

• Inspection:

Periodically inspect the fixture for any loose wires, damaged components, or signs of wear. If any issues are found, turn off power and consult a qualified electrician.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Bulbs are loose or burnt out. Incorrect wiring.	Check circuit breaker and wall switch. Ensure bulbs are screwed in tightly and replace if necessary. Turn off power and recheck wiring connections.
Light flickers.	Loose bulb. Incompatible dimmer switch or bulbs. Loose wiring connection.	Tighten bulbs. Ensure both dimmer and bulbs are compatible. Turn off power and check wiring connections.
Dimming does not work.	Non-dimmable bulbs installed. Non-dimmable wall switch.	Replace with dimmable E12 bulbs. Install a compatible dimmer switch.

SPECIFICATIONS

Feature	Detail
Brand	GLOBE Electric
Model Number	66000081
Product Name	Devo 2-Light Flush Mount Ceiling Light
Finish	Matte Brass
Shade Material	White Milk Glass
Fixture Material	Metal
Dimensions (L x W x H)	11.81" x 11.81" x 4.52" (30 cm x 30 cm x 11.5 cm)
Weight	4.1 Pounds (1.86 kg)
Bulb Base	E12 Candelabra
Number of Light Sources	2
Max Wattage per Bulb	40W
Voltage	120 Volts
Dimmable	Yes (with compatible dimmer switch and bulbs)
Installation Type	Flush Mount, Hardwired
Indoor/Outdoor Usage	Indoor Only
Water Resistance Level	Not Water Resistant
Assembly Required	Yes

WARRANTY AND SUPPORT





This product comes with **No Warranty** as per manufacturer specifications. For any questions regarding installation, operation, or troubleshooting that are not covered in this manual, please contact GLOBE Electric customer support.

GLOBE Electric Customer Support:

- Refer to the contact information provided on the product packaging or the official GLOBE Electric website for the most current support details.
- When contacting support, please have your model number (66000081) and purchase information ready.

© 2024 GLOBE Electric. All rights reserved.

Related Documents - 66000081

	<p><u>Globe SMART FLOOR LAMP User Manual and Setup Guide</u></p> <p>Comprehensive guide for the Globe SMART FLOOR LAMP, including safety instructions, features, specifications, assembly, and connecting to the Globe Suite app and voice assistants like Google Home and Amazon Alexa.</p>
	<p><u>Globe SMART 4 LIGHT TRACK BAR Installation and Safety Guide</u></p> <p>Comprehensive guide for the Globe SMART 4 LIGHT TRACK BAR, including safety instructions, electrical installation, features, specifications, and app connectivity for smart home integration. This document is primarily in English with supplementary French content.</p>
	<p><u>Globe Motion Activated Security Light Installation and Operation Guide</u></p> <p>Comprehensive guide for installing, operating, and troubleshooting the Globe Motion Activated Security Light. Features include specifications, safety precautions, step-by-step installation instructions, and maintenance tips.</p>
	<p><u>Globe Streamwatch Xtreme Prepaid User Manual and Setup Guide</u></p> <p>Comprehensive user manual for the Globe Streamwatch Xtreme Prepaid device. Learn how to connect to the internet, stream content on your TV, access apps via Google Play, and find troubleshooting solutions. Includes setup guides and device information.</p>
	<p><u>Globe Smart Switch User Guide</u></p> <p>User guide for the Globe Smart Switch, detailing installation, setup via the Globe Suite™ app, features like remote control, scheduling, and voice assistant integration. Learn how to enhance your home with smart lighting control.</p>



[Globe Running Boards Assembly Guide for Haul LT Bicycle](#)

Step-by-step instructions and safety information for assembling Globe Running Boards onto your Globe Haul LT bicycle, including parts lists, torque specifications, and weight limits.