Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ott-lite CSJ37G5W-CA

OttLite Clip-On LED Easel Lamp Instruction Manual

Model: CSJ37G5W-CA

Introduction

This manual provides instructions for the safe and effective use of your OttLite Clip-On LED Easel Lamp. This versatile lamp is designed to provide high-quality illumination for various tasks, including art, reading, and detailed work. Its flexible design allows for easy positioning and attachment to various surfaces.

The lamp features OttLite's exclusive ClearSun LED technology, engineered to reduce eyestrain by up to 51%. With a Color Rendering Index (CRI) of 95+, it ensures accurate color representation, which is beneficial for activities requiring precise color perception.

What's in the Box

Carefully unpack your OttLite Clip-On LED Easel Lamp and ensure all components are present:

- OttLite Clip-On LED Easel Lamp (integrated shade, flexible neck, and clip)
- Power Cable



Figure 1: OttLite Clip-On LED Easel Lamp overview.

Setup

1. **Choose a Location:** Select a stable surface such as an easel, desk, or shelf where you intend to use the lamp. Ensure the surface edge is suitable for clamping.
2. **Attach the Lamp:** Open the spring-loaded clip and securely attach it to the edge of your chosen surface. The clip is designed to provide a firm grip.



Figure 2: Securely attaching the lamp clip to a surface.

3. **Position the Light:** Adjust the flexible 16.6-inch (42.16 cm) neck to direct the 12.6-inch (32 cm) light shade precisely where illumination is needed. The neck will hold its position once adjusted.
4. **Connect Power:** Plug the power cable into a standard electrical outlet.

Operating Instructions

1. **Power On/Off:** Locate the on/off switch on the power cord. Press the switch to turn the lamp on or off.



Figure 3: On/off switch on the power cord.

2. **Adjusting Light Direction:** Gently bend and twist the flexible neck to reposition the light source as required for your task.

The OttLite ClearSun LED provides smooth, uniform light with a Color Rendering Index (CRI) of 95+, ensuring accurate color perception and reduced eyestrain during extended use.

Maintenance

- **Cleaning:** Ensure the lamp is unplugged before cleaning. Wipe the lamp and shade with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **LED Care:** The integrated LED light source is designed for long life and does not require replacement.
- **Storage:** When not in use for extended periods, store the lamp in a clean, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in. Power switch is off. No power from outlet.	Ensure power cable is securely plugged into a working outlet. Press the on/off switch on the cord to the 'on' position. Test the outlet with another device to confirm it has power.
Light flickers or is dim.	Loose connection. Power fluctuation.	Check all power connections. Ensure the lamp is connected to a stable power source.

Specifications

Feature	Detail
Model Number	CSJ37G5W-CA
Brand	Ott-lite
Light Source Type	LED (ClearSun Technology)
Color Rendering Index (CRI)	95+
Brightness	355 Lumens
Color Temperature	5000 Kelvin
Shade Length	12.6 inches (32 cm)
Flexible Neck Length	16.6 inches (42.16 cm)
Product Dimensions (Overall)	3"D x 4.5"W x 16.6"H
Item Weight	1.21 pounds
Power Source	Corded Electric
Switch Type	Toggle (on cord)
Material	Metal
Finish Type	Painted
Indoor/Outdoor Usage	Indoor

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact OttLite Technologies directly. Keep your purchase receipt as proof of purchase.

You can typically find contact information on the manufacturer's official website or by searching for "OttLite support".

© 2024 OttLite Technologies. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C797XNHN

More documents and user manuals: **https://manuals.plus/**