Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Samsung EF-DX810UBEGUJ

Samsung Galaxy Tab S9 FE+ Book Cover Keyboard Slim Instruction Manual

Model: EF-DX810UBEGUJ | Brand: Samsung

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Samsung Galaxy Tab S9 FE+ Book Cover Keyboard Slim. Designed for enhanced productivity and protection, this accessory transforms your tablet into a versatile workstation.

Product Features

- **Slim and Lightweight Design:** Offers protection without adding significant bulk to your tablet.
- **Magnetic Attachment:** Securely attaches to your tablet for easy installation and removal.
- **Integrated S Pen Holder:** Provides a dedicated compartment for your S Pen.
- **Full Keyboard Experience:** Enables efficient typing for emails and documents, enhancing productivity.
- **Wireless Keyboard Sharing:** Allows connection to compatible Galaxy devices for seamless typing and navigation.
- **Auto On/Off Functionality:** Automatically turns the tablet screen on when opened and off when closed, conserving battery.
- **Durable Material:** Constructed from a smooth, silicone-like material that is easy to clean.

Package Contents

Verify that all items are present in your package:

- Samsung Galaxy Tab S9 FE+ Book Cover Keyboard Slim
- Screen Protector

Setup

1. Attaching the Book Cover Keyboard Slim

1. Align the back of your Samsung Galaxy Tab S9 FE+ or S9+ tablet with the magnetic back panel of the Book Cover

Keyboard Slim. The magnets will securely snap the tablet into place.

2. Ensure the tablet's POGO pin connectors on the side align with the corresponding connectors on the keyboard for power and data transfer. The keyboard does not require separate charging as it draws power directly from the tablet.
3. Place the S Pen into its designated storage compartment on the back cover for secure keeping.



Front view of the Samsung Galaxy Tab S9 FE+ Book Cover Keyboard Slim. The tablet is securely attached to the keyboard cover.




Image illustrating the magnetic attachment of the tablet to the cover and the integrated S Pen holder.

Operating Instructions

1. Using the Keyboard

- To use the keyboard, simply open the cover and position the tablet in the upright viewing angle. The keyboard will automatically activate.
- The keyboard provides a tactile typing experience for efficient document creation, email writing, and other tasks.
- When combined with Samsung DeX Mode, the keyboard offers a PC-like experience for enhanced productivity.



The Samsung Galaxy Tab S9 FE+ with the Book Cover Keyboard Slim attached and ready for use.




Illustration of the full keyboard experience provided by the Book Cover Keyboard Slim.

2. Wireless Keyboard Sharing

- The Wireless Keyboard Sharing feature allows you to connect the Book Cover Keyboard to other compatible Galaxy devices (smartphones running One UI 3.1 or above, and other Galaxy tablets).
- To enable this feature, both devices must be logged in to the same Samsung account. Up to 3 mobile devices can be connected for Wireless Keyboard Sharing.



Demonstration of Wireless Keyboard Sharing between a tablet and a smartphone.

3. Auto On/Off Function

- Opening the Book Cover Keyboard Slim will automatically wake your tablet's screen.
- Closing the cover will automatically turn off your tablet's screen, helping to conserve battery life.

4. Fixed Viewing Angle

The Book Cover Keyboard Slim is designed with a single, ergonomically optimized viewing angle. This fixed angle is intended to promote comfortable posture when using the tablet on a raised surface, such as a desk or table. Please note that the viewing angle is not adjustable.

Maintenance

- **Cleaning:** The cover material is easy to clean. Use a soft, damp cloth to wipe down the surface. Avoid harsh chemicals or abrasive materials.
- **S Pen Storage:** Always store your S Pen in its dedicated compartment to prevent loss or damage.
- **General Care:** Avoid exposing the keyboard cover to extreme temperatures or direct sunlight for prolonged periods.

Troubleshooting

- **Keyboard Not Responding:**
  - Ensure the tablet is correctly aligned and securely attached to the magnetic back panel, ensuring the POGO pins are fully connected.
  - Restart your tablet.
- **Tablet Screen Not Turning On/Off Automatically:**
  - Verify that the cover is properly closed or opened.
  - Check for any obstructions preventing the cover from fully closing or opening.
- **Wireless Keyboard Sharing Issues:**
  - Confirm both devices are logged into the same Samsung account.
  - Ensure both devices have Wireless Keyboard Sharing enabled in their settings.
  - Check that both devices are within close proximity.

Specifications

Brand	Samsung
Model Number	EF-DX810UBEGUJ
Compatible Devices	Galaxy Tab S9+ / S9 FE+
Color	Black
Material	Leather
Water Resistance Level	Not Water Resistant
Item Dimensions (LxWxH)	11.26 x 7.38 x 0.58 inches
Item Weight	0.35 Kilograms
Additional Features	Lightweight

Warranty and Support

This product is listed with "No Warranty" in its specifications. For any product-related inquiries, technical support, or further assistance, please contact Samsung customer service directly.
You can find contact information on the official Samsung website or through your product's packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C79JFNDT

More documents and user manuals: **https://manuals.plus/**