Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Crucial /
- Crucial 96GB DDR5 RAM (CT2K48G56C46S5) Laptop Memory Kit Instruction Manual

Crucial CT2K48G56C46S5

Crucial 96GB DDR5 RAM (CT2K48G56C46S5) Laptop Memory Kit Instruction Manual

Model: CT2K48G56C46S5 | Brand: Crucial

1. Introduction

This document provides comprehensive instructions for the installation, operation, and maintenance of your Crucial 96GB DDR5 RAM Laptop Memory Kit (CT2K48G56C46S5). This memory kit is designed to enhance the performance of compatible laptops by providing increased speed and capacity for demanding applications.

2. PRODUCT OVERVIEW

The Crucial 96GB DDR5 RAM Laptop Memory Kit consists of two 48GB DDR5 SODIMM modules, offering a total of 96GB capacity. These modules operate at speeds up to 5600MHz, with backward compatibility for 5200MHz and 4800MHz, ensuring improved multitasking and system responsiveness. Designed for compatibility with 12th and 13th Gen Intel Core processors and AMD Ryzen 7000 Series CPUs, this memory supports Intel XMP 3.0 and AMD EXPO for optimized performance. Each module features on-die ECC for enhanced stability and a Power Management Integrated Circuit (PMIC) for efficient power delivery.



Image: A single Crucial DDR5 SODIMM module, highlighting its compact form factor.



Image: Two Crucial DDR5 SODIMM modules, emphasizing reliable performance for DDR5 systems.



Image: A person using a laptop, illustrating the powerful upgrades for laptops provided by Crucial RAM.

3. SAFETY INFORMATION

Always observe the following safety precautions when handling computer components:

- Disconnect the laptop from all power sources and remove the battery before installation.
- Discharge static electricity by touching a grounded metal object (e.g., an unpainted metal surface on the laptop chassis) before handling memory modules.
- Handle memory modules by their edges to avoid touching the gold contacts or integrated circuits.
- Refer to your laptop's manufacturer manual for specific safety guidelines and disassembly instructions.

4. COMPATIBILITY

This Crucial DDR5 SODIMM kit is compatible with laptops featuring 12th and 13th Gen Intel Core processors and AMD Ryzen 7000 Series CPUs that support DDR5 memory. Always verify your laptop's memory specifications and maximum supported capacity before installation.

5. Installation Guide

Follow these steps to install your new Crucial DDR5 RAM modules:

- 1. **Preparation:** Gather necessary tools (e.g., small Phillips head screwdriver, plastic pry tool). Ensure your workspace is clean and well-lit.
- 2. **Power Down:** Shut down your laptop completely, disconnect the power adapter, and remove the battery (if removable).
- 3. **Access Memory Slots:** Carefully open the laptop's bottom panel. Refer to your laptop's service manual for exact instructions on how to access the memory slots.
- 4. Remove Existing Modules (if applicable): If replacing existing RAM, gently push apart the small metal

clips on either side of the SODIMM module. The module will pop up at an angle. Carefully slide it out of the slot.

- 5. **Install New Modules:** Align the notch on the new Crucial DDR5 SODIMM module with the key in the memory slot. Slide the module into the slot at a 45-degree angle. Once fully seated, push down firmly on the module until the metal clips snap into place, securing it horizontally.
- 6. **Reassemble:** Replace the bottom panel and secure it with screws. Reinstall the battery and reconnect the power adapter.

Your browser does not support the video tag.

Video: A demonstration of installing RAM into a laptop, including removing existing modules and inserting new ones. This video also shows how to check the RAM in Task Manager after installation.



Image: A hand carefully installing a Crucial DDR5 SODIMM module into a laptop's memory slot.

6. OPERATION AND VERIFICATION

After installation, power on your laptop. The system may take a moment longer than usual for the first boot as it recognizes the new memory. Once the operating system loads, you can verify the installation:

- Windows: Right-click on the Taskbar, select 'Task Manager', then go to the 'Performance' tab and click on 'Memory'. You should see the total installed RAM (96.0 GB) and its speed (e.g., 5600 MHz).
- macOS: Click the Apple menu, select 'About This Mac', then 'More Info...' or 'System Report'. Under 'Memory', you will find details about the installed RAM.



Image: A Crucial DDR5 SODIMM module resting on a laptop keyboard, symbolizing future-ready performance.

7. MAINTENANCE

Crucial DDR5 RAM modules are designed for long-term reliability. Minimal maintenance is required:

• Keep the memory slots and surrounding areas free of dust using compressed air.

- Avoid touching the gold contacts on the modules.
- · Store unused modules in anti-static packaging.

8. TROUBLESHOOTING

If you encounter issues after installing your RAM, consider the following:

- System Not Booting/No Display: Ensure modules are fully seated in their slots. Re-seat them firmly. Verify compatibility with your laptop model.
- Incorrect RAM Capacity/Speed: Check your system's BIOS/UEFI settings to confirm the RAM is recognized correctly. Ensure XMP/EXPO profiles are enabled if your system and CPU support them for optimal speeds.
- System Instability/Crashes: Run a memory diagnostic tool (e.g., Windows Memory Diagnostic) to check for errors. Ensure your laptop's BIOS/UEFI is updated to the latest version.

9. SPECIFICATIONS

Feature	Detail
Total Capacity	96GB (2x48GB)
Memory Type	DDR5 SDRAM
Form Factor	SODIMM (262-Pin)
Memory Speed	5600 MHz (PC5-44800)
Voltage	1.1V
ECC Type	Non-ECC (On-Die ECC for stability)
Compatibility	12th/13th Gen Intel Core, AMD Ryzen 7000 Series
Features	Intel XMP 3.0 & AMD EXPO Support, PMIC
Manufacturer	Micron

10. WARRANTY AND SUPPORT

This Crucial memory kit is backed by Micron's extensive memory expertise and rigorous testing, ensuring top performance and reliability. For specific warranty details and technical support, please visit the official Crucial website or contact their customer service. Keep your proof of purchase for warranty claims.

Related Documents - CT2K48G56C46S5



How to Install Crucial DDR5 Pro Overclocking Memory - Step-by-Step Guide

Learn how to easily install your Crucial DDR5 Pro Overclocking Memory with this comprehensive, step-by-step guide. Includes pre-installation warnings, installation steps, and troubleshooting tips for optimal performance.



Crucial Memory Module Installation Guide

A comprehensive guide from Crucial by Micron on how to install memory modules (DIMMs and SODIMMs) into computers, including equipment needed, step-by-step installation process, and troubleshooting tips.



Crucial NVMe SSD Installation Guide: Laptop & Desktop

Learn how to install your new Crucial NVMe SSD in a laptop or desktop with this comprehensive guide from Crucial by Micron. Follow step-by-step instructions to ensure compatibility, prepare your workspace, and successfully upgrade your computer's storage.



How to Install a Crucial NVMe PCIe M.2 SSD in Your Computer

A step-by-step guide on how to install a Crucial NVMe PCIe M.2 SSD into your computer, including preparation, installation, data cloning, and software setup for optimal performance.



Crucial Client SSD Firmware Update Instructions

Comprehensive guide on how to update the firmware for Crucial Client SSDs using two methods: Crucial Storage Executive software or a bootable ISO image. Includes step-by-step instructions for Windows users.



Crucial NVMe SSD Installation Guide for Laptops, Desktops, and PS5

Comprehensive guide on how to install your Crucial NVMe SSD in laptops, desktops, and PlayStation 5 consoles. Includes steps for installation with and without heatsinks, cloning data, and using Crucial Storage Executive.