

Samsung EF-DX710UBEGUJ

SAMSUNG Galaxy Tab S9 FE Book Cover Keyboard Slim User Manual

Model: EF-DX710UBEGUJ

INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your SAMSUNG Galaxy Tab S9 FE Book Cover Keyboard Slim. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

The Samsung Galaxy Tab S9 FE Book Cover Keyboard Slim is designed to enhance your tablet experience by providing a protective cover and a functional keyboard, transforming your tablet into a portable workstation. Its lightweight and slim design ensures portability without compromising protection.

SETUP

Attaching the Book Cover Keyboard Slim

The Book Cover Keyboard Slim is designed for easy attachment using magnets. Simply align your Galaxy Tab S9 FE or Tab S9 with the cover, and the magnets will securely hold it in place. Ensure the tablet's camera aligns with the cutout on the cover.



Image: The Samsung Galaxy Tab S9 FE Book Cover Keyboard Slim attached to a tablet, showcasing its sleek front profile.

S Pen Storage

The Book Cover Keyboard Slim includes a dedicated compartment for your S Pen. This ensures your S Pen is always secure and readily accessible when you need it.



Image: A side view of the Book Cover Keyboard Slim, highlighting the integrated storage slot for the S Pen.

OPERATING INSTRUCTIONS

Using the Keyboard

Once attached, the keyboard connects automatically to your tablet via the POGO pins. You can immediately begin typing emails, drafting documents, or navigating your tablet with ease. The keyboard provides a tactile typing experience similar to a traditional laptop keyboard.



Image: The Samsung Galaxy Tab S9 FE tablet propped up by its Book Cover Keyboard Slim, ready for use.

DeX Mode Integration

For a PC-like experience, activate DeX Mode on your Galaxy Tab. The Book Cover Keyboard Slim seamlessly integrates with DeX Mode, allowing for a more desktop-oriented interface, enhanced multitasking, and efficient workflow.



Image: A side view of the tablet in DeX Mode, demonstrating the ergonomic angle provided by the keyboard cover.

Wireless Keyboard Sharing

The Wireless Keyboard Sharing feature allows you to connect to compatible Galaxy devices (smartphones running One UI 3.1 or above) and use the Book Cover Keyboard Slim to type or navigate on them. Both devices must be logged in to the same Samsung account. Up to 3 mobile devices can be connected for Wireless Keyboard Sharing. To enable Wireless Keyboard Sharing:

1. Ensure your tablet and the target Galaxy device are logged into the same Samsung account.
2. On your tablet, navigate to Settings > Connected devices > Wireless Keyboard Sharing.
3. Follow the on-screen prompts to connect to your desired device.

phone and using it the same way as would your tablet.^^




Image: An illustration demonstrating the Wireless Keyboard Sharing feature, allowing seamless typing across multiple Samsung Galaxy devices.

MAINTENANCE

Cleaning the Keyboard and Cover

To maintain the appearance and functionality of your Book Cover Keyboard Slim, regularly clean it with a soft, dry, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the surface.

Storage

When not in use, store the Book Cover Keyboard Slim in a cool, dry place away from direct sunlight and extreme temperatures. Ensure no heavy objects are placed on top of it to prevent damage to the keys or cover.

TROUBLESHOOTING

Keyboard Not Responding

- Ensure the tablet is correctly seated in the cover and the POGO pins are making proper contact.
- Restart your tablet.
- Check for any physical obstructions between the POGO pins and the tablet's connector.

Wireless Keyboard Sharing Issues

- Verify both devices are logged into the same Samsung account.
- Ensure Bluetooth is enabled on both devices.
- Try unpairing and re-pairing the devices through the Wireless Keyboard Sharing settings.

SPECIFICATIONS

Feature	Detail
Brand	Samsung

Model Number	EF-DX710UBEGUJ
Compatible Devices	Samsung Galaxy Tab S9 FE, Samsung Galaxy Tab S9
Connectivity Technology	POGO Pin (for keyboard), Wireless (for sharing)
Color	Black
Item Weight	14.6 ounces
Product Dimensions	10 x 6.61 x 0.58 inches
Number of Keys	80

WARRANTY AND SUPPORT

Warranty Information

This product is covered by Samsung's standard limited warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the warranty card included with your product or visit the official Samsung website.

Customer Support

For technical assistance, troubleshooting, or service inquiries, please contact Samsung Customer Support. You can find contact information, including phone numbers and online support resources, on the official Samsung website or within your tablet's support section.

Official Samsung Website: www.samsung.com