

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [BGOVERSS](#) /
- › [BGOVERSS White Noise Sound Machine Charger Instruction Manual](#)

BGOVERSS BGOVERSSCH

BGOVERSS White Noise Sound Machine Charger Instruction Manual

Model: BGOVERSSCH

INTRODUCTION

This manual provides essential information for the safe and effective use of your BGOVERSS White Noise Sound Machine Charger. This portable replacement power supply cord is designed to provide reliable power to compatible BGOVERSS sound machines.

PRODUCT OVERVIEW

What's in the Box

- 1 x BGOVERSS White Noise Sound Machine Charger (Charge Cable)

Key Features

- Input: 100-240V ~50/60Hz 250mA MAX
- Output: DC 5V-1A
- US Plug Type
- Portable and compact design



Image: The BGOVERSS White Noise Sound Machine Charger, showing the power adapter block and the attached DC cable with its connector.

COMPATIBILITY

This charger is specifically designed for use with the following BGOVERSS Sleep Sound Machine models:

- BGOVERSS SF407
- BGOVERSS T126L
- BGOVERSS TP2
- BGOVERSS TP1

It is crucial to verify that the specifications of this AC adapter match those of your original adapter to ensure proper functionality and prevent damage to your device. Refer to the input and output specifications provided on your

More Compatibility



Image: The BGOVERSS charger displayed alongside three different BGOVERSS sound machine models, illustrating its compatibility.

SETUP AND OPERATION

1. **Inspect the Charger:** Before use, visually inspect the charger and cable for any signs of damage, such as frayed wires or bent pins. Do not use if damaged.
2. **Connect to Device:** Insert the DC connector end of the charger cable firmly into the power input port of your compatible BGOVERSS White Noise Sound Machine.
3. **Connect to Power Outlet:** Plug the AC adapter block into a standard US wall power outlet (100-240V).
4. **Verify Power:** Once connected, your sound machine should begin charging or power on, depending on its design. Refer to your sound machine's manual for specific power indicators.
5. **Disconnecting:** To disconnect, first unplug the AC adapter from the wall outlet, then gently remove the DC connector from your sound machine.



Image: The BGOVERSS charger plugged into a wall outlet, providing power to a wooden BGOVERSS sound machine on a bedside table.



Image: The BGOVERSS charger plugged into a wall outlet, providing power to a yellow BGOVERSS sound machine on a bedside table.

SPECIFICATIONS

Model Number	BGOVERSSCH
Input Voltage	100-240V AC, 50/60Hz, 250mA MAX
Output Voltage/Current	DC 5V, 1A
Wattage	5 Watts
Connector Type	DC Barrel Connector (Cable)
Plug Type	US Plug
Cable Length	150cm (59 inches)
Adapter Dimensions (L x W x H)	56mm (2.2in) x 28mm (1.1in) x 42mm (1.65in)
Item Weight	3.52 ounces
Color	White

Compact Design




Image: Detailed diagram showing the compact design and dimensions of the BGOVERSS charger, including the adapter block size and cable length.

MAINTENANCE

- Keep the charger clean and dry. Avoid exposure to moisture or extreme temperatures.
- Do not bend or crimp the cable excessively, as this can damage the internal wires.
- Store the charger in a cool, dry place when not in use.
- Regularly check the cable and connector for any signs of wear or damage. Replace the charger if any damage is observed.

TROUBLESHOOTING

Common Issues and Solutions

- **Device not powering on/charging:**
 - Ensure the charger is fully plugged into both the wall outlet and the sound machine.
 - Verify that the wall outlet is functional by testing it with another device.
 - Confirm that the charger's specifications (INPUT/OUTPUT) match those required by your sound machine. Incompatible chargers may not work or could damage the device.
 - Check the charger cable and connector for any visible damage. If damaged, discontinue use and

replace.

- **Charger feels warm during use:**

- It is normal for power adapters to become slightly warm during operation. However, if it becomes excessively hot or emits a burning smell, immediately unplug it from the wall outlet and discontinue use.

WARRANTY AND SUPPORT

BGOVERSS provides warranty service for this product. For any questions, concerns, or to inquire about warranty service, please contact BGOVERSS customer support. Refer to your purchase documentation or the official BGOVERSS website for contact information.

Please note that the warranty may not cover damage caused by improper use, unauthorized modifications, or failure to follow the instructions in this manual.