

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [JoyGeek](#) /

› [JoyGeek 3-in-1 Wireless Charging Station \(Model GY-Z8-1\) Instruction Manual](#)

JoyGeek GY-Z8-1

JoyGeek 3-in-1 Wireless Charging Station (Model GY-Z8-1) Instruction Manual

FOR SAMSUNG GALAXY PHONES, WATCHES, AND EARBUDS

Product Overview

The JoyGeek 3-in-1 Wireless Charging Station is designed to simultaneously charge your compatible Samsung Galaxy phone, smartwatch, and earbuds. This device aims to provide a convenient and organized charging solution, reducing cable clutter.

Key features include:

- Simultaneous charging for three devices.
- Dedicated charging areas for phone, watch, and earbuds.
- Dual-coil design for flexible phone placement (vertical or horizontal).
- Integrated safety protections against over-current, over-voltage, short-circuit, overcharge, and over-temperature.
- Efficient heat dissipation system.
- Adjustable LED indicator light for nightstand use.

Package Contents

Please ensure all items are present in the package:

- JoyGeek 3-in-1 Wireless Charging Station
- USB Type-C Charging Cable
- User Manual (this document)

Case-Friendly Design

No more phone case removal headaches!
(Thickness < 5mm / 0.2in)



Figure 1: Included components of the JoyGeek 3-in-1 Wireless Charging Station.

Setup Instructions

1. **Connect Power:** Insert the provided USB Type-C charging cable into the port on the back of the charging station. Connect the other end of the cable to a compatible power adapter (not always included, refer to package contents). For optimal performance, use a Quick Charge 3.0 (QC3.0) adapter.
2. **Placement:** Place the charging station on a flat, stable surface.
3. **Initial Indicator:** Upon connecting power, the LED indicator light around the base will illuminate, typically

green, indicating standby mode.

Your browser does not support the video tag.

Video: Demonstrates the setup and use of the JoyGeek 3-in-1 Wireless Charging Station for Samsung devices, showing how to place a phone, watch, and earbuds for charging.

Operating Instructions

This charging station allows for simultaneous wireless charging of your compatible devices.

1. **Charging Your Phone:** Place your compatible Samsung Galaxy phone on the upright charging pad. The dual-coil design supports both vertical and horizontal placement. Ensure the phone is centered on the charging area for optimal connection. The LED indicator will change to a breathing blue light when charging is active.

Efficient Heat Dissipation


Charge smarter, charge safer
for total peace of mind



Figure 2: Vertical phone charging on the station.

Your Perfect Bedside Companion

Upgraded powerful magnets
ensure perfect alignment and secure hold.



Turn on/ off the nightlight

Figure 3: Horizontal phone charging for media viewing.

2. **Charging Your Smartwatch:** Place your compatible Samsung Galaxy Watch on the magnetic charging module located at the top of the stand. The watch will magnetically align and begin charging.



Embrace a Clutter-Free Lifestyle



Figure 4: Smartwatch charging on the station.

- 3. Charging Your Earbuds:** Place your compatible Samsung Galaxy Buds case on the flat charging pad at the base of the station. Ensure the case is centered. The LED indicator will change to a breathing blue light when charging is active.



Figure 5: Earbuds charging on the station.

- 4. Controlling the LED Indicator Light:** The charging station features an LED light around its base. To turn the light on or off, gently touch the light icon button located on the base. This feature is useful for minimizing light disturbance in dark environments like a bedroom.

Stable & Safe Charging

Dual charging coils and multiple protection



Over-Current
Protection



Over-Voltage
Protection



Short-Circuit
Protection



Overcharge
Protection



Over-Temperature
Protection



Figure 6: LED indicator light control.

Your browser does not support the video tag.

Video: A user demonstrates charging a Samsung phone, watch, and earbuds simultaneously on the JoyGeek 3-in-1 Wireless Charging Station, highlighting the LED light functionality.

Maintenance

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the surface of the charging station. Avoid using abrasive cleaners or solvents.
- **Heat Dissipation:** The charging station is designed with multiple ventilation holes to ensure efficient heat dissipation during charging. Do not block these vents.




Figure 7: Heat dissipation features.

- **Safety Features:** The device incorporates multiple safety protections including over-current, over-voltage, short-circuit, overcharge, and over-temperature protection to ensure safe charging overnight.

Troubleshooting

- **Device Not Charging:**
 - Ensure the charging station is properly connected to a power source and the LED indicator is on.
 - Verify your device is compatible with wireless charging and is correctly aligned on the charging area.
 - Remove any thick phone cases (>5mm), metal attachments, magnets, or credit cards from your phone case, as these can interfere with wireless charging.

- Try restarting the charging station by unplugging and re-plugging the power cable.

- **Slow Charging:**

- Ensure you are using a QC3.0 compatible power adapter for fast charging.
- Check for proper alignment of your device on the charging pad.

- **LED Indicator Flashing Blue and Green:** This indicates that a foreign object (FOD) has been detected on the charging pad. Remove any metallic objects, magnets, or cards.

- **Watch Not Charging:** Ensure your watch is a compatible Samsung Galaxy Watch model and is correctly placed on the magnetic charging module.

Specifications

Feature	Detail
Model Number	GY-Z8-1
Input Voltage	9 Volts
Total USB Ports	1 (USB Type C)
Wattage	18 Watts (Max)
Compatible Phone Models	Samsung Galaxy S Series (S25 Ultra/S25+/S25/S24 Ultra/S24+/S24/S23 Ultra/S23+/S23/S22 Ultra/S22+/S22/S21 Ultra/S21+/S21/S21 FE/S20 Ultra/S20+/S20/S20 FE/S10+/S10/S10e/S9+/S9/S8+/S8/S7 Edge/S7), Z Flip Series (Z Flip6/Flip5/Flip4/Flip3/Flip2/Flip), Z Fold Series (Fold6/Fold5/Fold4/Fold3/Fold2/Fold), Note Series (Note 20 Ultra/Note 20/Note 10+/Note 10/Note 9/Note 8)
Compatible Watch Models	Samsung Galaxy Watch Ultra/7/6/6 Classic/5 Pro/5/4/4 Classic/3/Active 2/Active
Compatible Earbud Models	Samsung Galaxy Buds Pro/Buds 3/Buds 2 Pro/Buds 2/Buds Pro/Buds plus/Buds Live
Item Weight	10.8 ounces
Dimensions	5.31 x 5.16 x 3.31 inches

Warranty and Support

JoyGeek offers a 30-day refund policy and a 24-month replacement warranty for this product.

For any questions or support, please contact JoyGeek direct through the Amazon platform by navigating to the product page and selecting 'Ask a question' under the seller information.

