Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TOTO MW6044736CEFGA

TOTO WASHLET+ UltraMax II One-Piece Elongated Toilet with S7A Contemporary Bidet Seat Instruction Manual

Model: MW6044736CEFGA

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your TOTO WASHLET+ UltraMax II One-Piece Elongated 1.28 GPF Toilet and S7A Contemporary Bidet Seat. Please read this manual thoroughly before installation and use to ensure proper function and longevity of the product. Keep this manual for future reference.

2. Product Overview

The TOTO WASHLET+ UltraMax II is a comprehensive toilet system integrating a high-efficiency toilet with an advanced bidet seat. This one-piece, elongated toilet features a 1.28 gallons per flush (GPF) design for water conservation. The WASHLET+ system is specifically engineered to conceal the bidet seat's power cord and water supply hose, providing a clean and integrated appearance. The S7A Contemporary Bidet Seat offers a range of personal cleansing functions and comfort features.



Image 2.1: Front view of the TOTO WASHLET+ UltraMax II Toilet with S7A Bidet Seat.

3. Key Features

- **WASHLET+ Design:** Integrates the bidet seat with the toilet, concealing the water supply and power cord for a streamlined look.
- **TORNADO FLUSH®:** A powerful, hole-free rim design with dual nozzles that create a centrifugal washing action, efficiently

rinsing the bowl.

- **CEFIONTECT® Ceramic Glaze:** An ultra-smooth, ion-barrier surface that minimizes waste from sticking to ceramic surfaces, promoting easier cleaning.
- **EWATER+® System:** Electrolyzed water mists the wand and toilet bowl, reducing the need for harsh cleaning chemicals and maintaining hygiene.
- **Auto Flush:** Provides a hands-free automatic flush after each use, enhancing hygiene and convenience.
- **PREMIST®:** Wets the toilet bowl surface before each use, aiding in waste removal and contributing to a cleaner bowl.
- **Personal Cleansing Functions:** Features front and rear warm water washing with five adjustable temperature and pressure controls. Options include oscillating and pulsing streams.
- **Comfort Features:** Includes an auto open/close lid, heated seat with adjustable temperature, automatic air deodorizer, nightlight, and warm air dryer with five adjustable temperatures.



Image 3.1: Diagram illustrating the Clean Synergy of TOTO technologies: TORNADO FLUSH, EWATER+, and CEFIONTECT.



Image 3.2: View of the TORNADO FLUSH system, showing 360-degree cleaning action within the toilet bowl.



Image 3.3: Comparison showing how CEFIONTECT ceramic glaze minimizes waste adhesion compared to non-CEFIONTECT surfaces.




Image 3.4: Illustration of EWATER+ misting the toilet bowl and cleansing wand for enhanced hygiene.

4. Setup and Installation

4.1. Included Components

- WASHLET S7A Bidet Seat with water supply adapter
- UltraMax II One-Piece Toilet bowl and tank set
- Mounting hardware
- Toilet bolt caps

4.2. Items Needed for Installation (Purchased Separately)

- Wax ring
- Toilet mounting bolts
- Toilet water supply lines

4.3. Installation Notes

The WASHLET+ system is designed for a seamless installation where the bidet seat's power cord and water supply hose are concealed within the toilet base. This product is compatible only with T40 WASHLET+ toilet bowl components. Refer to the detailed installation guide provided with your product for step-by-step instructions. Ensure all local plumbing and electrical codes are followed during installation.



Image 4.1: Diagram illustrating the concealed supply connection of the WASHLET+ system compared to conventional installations.

5. Operating Instructions

The TOTO WASHLET S7A is operated using an illuminated remote control. Familiarize yourself with the remote's buttons and functions for optimal use.

5.1. Remote Control Functions




Image 5.1: Detailed diagram of the WASHLET S7A remote control, showing button layout and functions.

- **STOP:** Stops washing or drying.
- **FRONT/WIDE:** Activates front cleansing. Press once for a delicate stream, twice for a wider area and light pressure.
- **REAR/SOFT:** Activates rear cleansing. Press to toggle between a soft stream or added pressure.
- **DRYER:** Initiates warm air drying.
- **USER:** Allows for two-user personal memory settings.
- **SELF CLEANING WAND:** Cleans the entire wand with EWATER+ before and after each use.
- **PRESSURE:** Adjusts the water pressure of the stream (left/right buttons).
- **POSITION:** Adjusts the wand position (left/right buttons for forward/backward).
- **PULSATING:** Varies the water pressure for a massage effect.
- **OSCILLATING:** Moves the wand back and forth for a wider cleansing area.
- **DEODORIZER:** Removes odors from the air.

- **FLUSHES THE TOILET:** (TOTO Auto flush models only) Initiates a flush.
- **RAISES THE SEAT OR LID:** (S7A model only) Automatically opens or closes the seat and lid.

5.2. Automatic Functions

- **Auto Open/Close Lid:** The lid automatically opens when approached and closes after use.
- **Heated Seat:** The seat maintains a comfortable temperature, adjustable via the remote.
- **Nightlight:** Provides subtle illumination for nighttime use.
- **Continuous Warm Water:** Ensures a consistent supply of warm water for cleansing.



Image 5.2: Visual representation of key WASHLET S7A comfort features including auto open seat, continuous warm water, night light, and EWATER+.



Image 5.3: Illustration of additional WASHLET S7A features such as heated seat, warm air dryer, deodorizer, and Air-In Wonder-Wave cleansing.

6. Maintenance

Regular maintenance ensures the optimal performance and hygiene of your TOTO WASHLET+ system.

6.1. Cleaning the Toilet Bowl

- The CEFIONTECT ceramic glaze and TORNADO FLUSH system are designed to minimize waste adhesion and reduce cleaning frequency.
- For cleaning, use a soft cloth and mild, non-abrasive cleaners. Avoid harsh chemicals that can damage the CEFIONTECT surface.
- The PREMIST function helps keep the bowl clean by wetting the surface before use.

6.2. Cleaning the Bidet Wand

- The bidet wand features a self-cleaning function with EWATER+ before and after each use.

- For manual cleaning, gently wipe the wand with a soft, damp cloth. Do not use abrasive cleaners or brushes.



Image 6.1: Details of the self-cleaning wand with EWATER+ and the optimized wand angle to prevent splash-back.

7. Troubleshooting

If you encounter issues with your TOTO WASHLET+ system, refer to the following basic troubleshooting steps. For more complex problems, consult the full product manual or contact TOTO customer support.

- **No Power to WASHLET:** Ensure the power cord is securely plugged into a functional electrical outlet. Check the circuit breaker.
- **No Water from Wand:** Verify that the water supply valve is fully open. Check for any kinks in the water supply hose.
- **Weak Water Pressure:** Adjust the water pressure setting on the remote control. Ensure the water supply valve is fully open.
- **Lid/Seat Not Opening/Closing Automatically:** Check for obstructions around the sensor area. Ensure the auto open/close feature is enabled in settings (if applicable).

- **Toilet Not Flushing:** For auto-flush models, ensure the sensor is clear. If manual flush is available, try that. Check water supply to the tank.

8. Specifications

Feature	Specification
Model Number	MW6044736CEFGA
Brand	TOTO
Color	Cotton White
Product Dimensions (D x W x H)	28.38" x 16.63" x 28.75" (721mm x 422mm x 730mm)
Material	Ceramic, Plastic
Installation Type	Floor Mounted
Shape	Elongated (Oval)
Flush Volume	1.28 GPF (Gallons Per Flush)
Item Weight	94.8 pounds
UPC	739268445352



Image 8.1: Dimensional drawing of the TOTO WASHLET+ UltraMax II Toilet, showing height, width, length, and rough-in measurements.

9. Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official TOTO website. For technical support, replacement parts, or service inquiries, please contact TOTO customer service directly. Contact information can typically be found on the TOTO website or in the documentation provided with your purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C7CXFG82

More documents and user manuals: **https://manuals.plus/**