

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [TOTO](#) /

› [TOTO Drake WASHLET+ Two-Piece Elongated Toilet and S7 Bidet Seat User Manual](#)

TOTO MW7764726CSFGA.10#01

TOTO Drake WASHLET+ Two-Piece Elongated Toilet and S7 Bidet Seat User Manual

Model: MW7764726CSFGA.10#01

INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your TOTO Drake WASHLET+ Two-Piece Elongated Toilet and S7 Contemporary Bidet Seat. This system combines a high-efficiency toilet with an advanced bidet seat, designed for enhanced hygiene and comfort. Please read these instructions thoroughly before installation and use to ensure safe and optimal performance.



Image: The TOTO Drake WASHLET+ Two-Piece Elongated Toilet and S7 Bidet Seat in Cotton White. This image provides a general overview of the product's appearance.

SAFETY INFORMATION

Always observe the following safety precautions to reduce the risk of injury or property damage:

- Ensure all electrical connections are made by a qualified electrician and comply with local codes.
- Do not immerse the bidet seat or its electrical components in water.
- Disconnect power before performing any maintenance or cleaning.
- Do not use abrasive cleaners or harsh chemicals on any part of the toilet or bidet seat.
- Keep children and individuals with reduced physical, sensory, or mental capabilities away from the product unless supervised.

SETUP AND INSTALLATION

The TOTO Drake WASHLET+ system is designed for a seamless installation, concealing the WASHLET power cord and water supply hose. This model features a 10-inch rough-in and Universal Height for comfortable use.

Pre-Installation Checks:

- Verify rough-in dimensions match your plumbing.
- Ensure a grounded electrical outlet is available near the toilet for the WASHLET.
- Confirm all necessary additional items are acquired: wax ring, toilet mounting bolts, and toilet water supply lines.

Installation Steps:

1. Prepare the floor flange and install the mounting bolts.
2. Install the wax ring onto the toilet bowl outlet.
3. Carefully set the toilet bowl onto the mounting bolts and secure it.
4. Connect the water supply line to the toilet tank.
5. Install the WASHLET S7 bidet seat according to its specific instructions, ensuring the concealed connections are properly routed.
6. Connect the WASHLET power cord to the grounded electrical outlet.



Image: Detailed dimensional drawing of the TOTO Drake WASHLET+ toilet, showing width, height, length, rough-in, and seat height measurements. This is crucial for proper installation planning.

OPERATING INSTRUCTIONS

The WASHLET S7 offers a range of features for personalized comfort and hygiene, controlled via an illuminated remote.

WASHLET Functions:

- **Rear and Front Cleansing:** Gentle yet powerful warm water spray with adjustable temperature and pressure settings.
- **Oscillating and Pulsating:** Options to enhance the cleansing experience.
- **Heated Seat:** Provides consistent warmth across the entire seat surface.
- **Warm Air Dryer:** For comfortable drying after cleansing.
- **Air Deodorizer:** Neutralizes odors using powerful filters.
- **Continuous Warm Water:** Instantaneous water heating ensures warm water for the duration of use.
- **Auto Flush:** Provides a touchless, hands-free automatic flush after every use.



Image: Illustrates key WASHLET S7 features including the SoftClose heated seat, continuous warm water supply, night light function, and EWATER+ for exclusive cleaning.



Image: Highlights additional WASHLET S7 features such as the warm air dryer, deodorizer for odor elimination, and the Air-In Wonder-Wave cleansing technology.

Remote Control Operation:

The WASHLET S7 is operated using an intuitive, illuminated remote control. Refer to the diagram below for button functions:

HOW THE REMOTE CONTROL WORKS

Easy and Convenient to Use




Image: Diagram of the WASHLET S7 remote control, detailing buttons for Stop, Rear/Soft cleansing, Front/Wide cleansing, Dryer, User memory settings, Self-Cleaning Wand, Pressure adjustment, Position adjustment, Deodorizer, Pulsating, and Oscillating functions. Also shows flush and lid raise buttons.

- **STOP:** Stops washing or drying.
- **REAR/SOFT:** Initiates rear cleansing. Press to toggle between soft stream or added pressure.
- **FRONT/WIDE:** Initiates front cleansing. Press once for delicate areas, twice for wider areas and light pressure.
- **DRYER:** Activates warm air for drying.
- **USER:** Allows setting and recalling of 2-user personal memory settings.
- **SELF CLEANING WAND:** Cleans the entire wand with EWATER+ before and after each use.
- **PRESSURE:** Adjusts water pressure.
- **POSITION:** Adjusts wand position forward or backward.
- **DEODORIZER:** Activates air deodorizer.
- **PULSATING:** Varies water pressure for a massage effect.
- **OSCILLATING:** Moves the wand back and forth.

The TOTO Drake WASHLET+ system incorporates several technologies to minimize cleaning frequency and simplify maintenance.

Bowl Cleaning Technologies:

- **TORNADO FLUSH:** A rimless, hole-free design with dual-nozzles creates a centrifugal washing action that efficiently rinses the entire bowl surface.



Image: Overhead view of a toilet bowl demonstrating the TORNADO FLUSH action, showing 360-degrees of cleaning power that reaches every spot.

- **CEFIONTECT:** An exceptionally smooth glaze that minimizes waste from sticking to the ceramic surface, making cleaning easier.



CONVENTIONAL

VS




CONCEALED

WASHLET® +

WASHLET+ offers a concealed supply connection for seamless installation

Image: Comparison showing how CEFIONTECT ceramic glaze minimizes waste from sticking to porous ceramic surfaces, illustrating a clean surface versus a non-CEFIONTECT surface with residue.

- **PREMIST:** Wets the surface of the toilet bowl before each use, aiding in the removal of waste and contributing to a cleaner bowl.
- **EWATER+:** Electrolyzed water that mists the wand and toilet bowl, reducing the need for harsh cleaning chemicals.



EWATER+

EWATER+® mists the wand and toilet bowl, reducing the need for harsh cleaning chemicals

Image: Illustrates EWATER+ technology, showing how electrolyzed water mists the toilet bowl and wand, reducing the need for harsh cleaning chemicals.

Wand Cleaning:

- The WASHLET wand is self-cleaning, automatically rinsing with EWATER+ before and after each use.
- The wand is made with a special TOTO resin for a perfectly clean surface.



Image: Shows the self-cleaning wand with EWATER+ and highlights the careful consideration in wand angle to prevent splash-back, ensuring peace of mind.

General Cleaning:

- For external surfaces, wipe with a soft, damp cloth and mild, non-abrasive soap.
- Do not use harsh detergents, abrasive cleaners, or chemical sprays directly on the bidet seat or electronic components.

TROUBLESHOOTING

If you encounter issues with your TOTO Drake WASHLET+ system, please refer to the following common solutions:

- **No Power to WASHLET:** Check if the power cord is securely plugged into a grounded outlet. Verify the circuit breaker has not tripped.
- **No Water Spray:** Ensure the water supply valve to the toilet is fully open. Check for any kinks in the water supply hose.
- **Weak Spray Pressure:** Adjust the water pressure setting on the remote control. Clean the wand nozzle if it appears clogged.

- **Toilet Not Flushing:** For auto-flush models, ensure the sensor is clean and unobstructed. Manually flush if the auto-flush is unresponsive.
- **Unusual Noises:** Minor sounds during operation (e.g., water heating, fan) are normal. If loud or persistent, contact customer support.

For issues not resolved by these steps, please contact TOTO customer support.

SPECIFICATIONS

Feature	Specification
Model Number	MW7764726CSFGA.10#01
Color	Cotton White
Product Dimensions (D x W x H)	28.38" x 17.19" x 30.13"
Material	Ceramic, Plastic
Item Weight	94 Pounds
Installation Type	Floor Mounted
Shape	Elongated Oval
Rough-In	10 Inch
Flush Type	TORNADO FLUSH (1.6 GPF)
Included Components	Toilet, Electronic Bidet Toilet Seat
UPC	739268446328

WARRANTY AND SUPPORT

TOTO products are manufactured to the highest quality standards. For specific warranty details, please refer to the warranty documentation included with your purchase or visit the official TOTO website. For technical assistance, replacement parts, or any other inquiries, please contact TOTO customer support directly.

TOTO Customer Support: Please visit [the official TOTO store page](#) or consult your product packaging for contact information.