TOTO MW7764736CEFG

TOTO Drake WASHLET+ S7A Toilet System Instruction Manual

Model: MW7764736CEFG
Brand: TOTO

1. Product Overview

This manual provides detailed instructions for the installation, operation, and maintenance of your TOTO Drake WASHLET+ Two-Piece Elongated Toilet with S7A Bidet Seat. This system combines a high-efficiency toilet with an advanced bidet seat for enhanced hygiene and comfort.

Key features include:

- **WASHLET+ Concealed Connection:** Designed for a seamless installation, hiding the power cord and water supply hose.
- **EWATER+ System:** Mists the wand and toilet bowl with electrolyzed water, reducing the need for harsh cleaning chemicals.
- **PREMIST:** Wets the toilet bowl surface before use to aid in waste removal.
- **TORNADO FLUSH:** A powerful, rimless flushing system that creates a centrifugal washing action for efficient bowl cleaning.
- **CEFIONTECT Glaze:** An ultra-smooth ceramic glaze that minimizes waste from sticking to the bowl.
- **S7A Bidet Seat Features:** Includes an illuminated remote control, 5 spray settings, auto open/close lid, heated seat, nightlight, and instantaneous warm water.
- **Universal Height:** Provides a comfortable seating position for a wide range of users.



Figure 1: The TOTO Drake WASHLET+ S7A Toilet System. This image displays the complete two-piece toilet unit with the integrated bidet seat and a remote control unit.

2. Setup and Installation

Proper installation is crucial for the optimal performance of your TOTO Drake WASHLET+ system. It is recommended that installation be performed by a qualified plumber.

2.1 Pre-Installation Checklist

- Ensure all components are present: Drake bowl, tank set with hardware, S7A WASHLET bidet seat, and toilet bolt caps.
- Verify you have purchased additional necessary items: wax ring, toilet mounting bolts, and toilet water supply lines.
- Confirm water supply and electrical outlet are available near the installation area.

2.2 Installation Steps (Summary)

1. Prepare the installation area by removing the old toilet and cleaning the flange.
2. Install the wax ring and set the toilet bowl onto the flange, securing it with mounting bolts.
3. Attach the tank to the bowl, ensuring a watertight seal.
4. Connect the water supply line to the tank fill valve.
5. Install the WASHLET S7A bidet seat. The WASHLET+ design features a concealed connection for the power cord and water supply hose, providing a clean aesthetic.
6. Connect the WASHLET to the water supply and electrical outlet.
7. Test for leaks and proper flushing operation.



Figure 2: WASHLET+ concealed supply connection. This diagram illustrates how the WASHLET+ system integrates the water and electrical connections discreetly, contrasting with conventional exposed connections.



Figure 3: Product dimensions for the TOTO Drake WASHLET+ system. This image provides detailed measurements including height (30.125 inches), width (17.1875 inches), length (28.375 inches), rough-in (12 inches), and seat height (17.1875 inches).

3. Operating Instructions

The WASHLET S7A bidet seat offers a range of automated and customizable functions for personal hygiene and comfort, controlled via the included remote.

3.1 Basic Operation

- **Auto Open/Close Lid:** The lid automatically opens when a user approaches and closes upon departure, providing a hands-free experience.
- **Heated Seat:** The seat maintains a comfortable temperature, adjustable via the remote control.
- **Nightlight:** A gentle nightlight illuminates the bowl for convenience in low-light conditions.
- **Instantaneous Warm Water:** Provides a continuous stream of warm water for cleansing without waiting for heating.

3.2 Remote Control Functions

The illuminated remote control allows for precise adjustment of all WASHLET functions:

- **Rear/Soft Cleansing:** Provides a gentle yet effective rear wash.
- **Front/Wide Cleansing:** Offers a wider spray for feminine wash.
- **Water Pressure & Temperature:** Adjustable settings for personalized comfort.
- **Wand Position:** Adjust the wand's position forward or backward.
- **Oscillating & Pulsating Spray:** Enhances the cleansing experience.
- **Warm Air Dryer:** Provides a comfortable drying experience after cleansing.
- **Deodorizer:** Activates to minimize odors.
- **User Memory Settings:** Store up to two personalized user profiles.




Figure 4: Diagram of the WASHLET S7A remote control. This image details the various buttons and their functions for controlling the bidet seat's features, including spray settings, temperature, and drying.



Figure 5: WASHLET S7A comfort features. This image highlights the auto-open seat, continuous warm water supply, night light, and EWATER+ bowl misting capabilities.



Figure 6: WASHLET S7A advanced features. This image showcases the heated seat, warm air dryer, deodorizer, and Air-In Wonder-Wave spray technology.

4. Maintenance

Regular maintenance ensures the longevity and hygienic performance of your TOTO Drake WASHLET+ system. The system incorporates several self-cleaning technologies to minimize manual cleaning.

4.1 Self-Cleaning Technologies

- **EWATER+ Wand Cleaning:** The bidet wand is automatically cleaned with EWATER+ before and after each use.
- **PREMIST Bowl Cleaning:** The bowl is misted with water before each use to prevent waste adhesion.
- **TORNADO FLUSH:** The powerful flush action helps keep the bowl clean with each use.
- **CEFIONTECT Glaze:** The ultra-smooth, non-porous surface of the bowl resists waste and mold buildup, making cleaning easier.



Figure 7: WASHLET S7A self-cleaning wand and design. This image illustrates the self-cleaning function of the wand with EWATER+ and the thoughtful wand angle designed to prevent splash-back.




Figure 8: EWATER+ bowl misting. This image shows the EWATER+ system misting the toilet bowl, which helps reduce the need for harsh cleaning chemicals and maintains hygiene.



Figure 9: TORNADO FLUSH technology. This image demonstrates the powerful 360-degree cleaning action of the TORNADO FLUSH, designed to thoroughly wash the entire bowl surface.



Figure 10: CEFIONTECT glaze. This image illustrates how the ceramic glaze minimizes waste from sticking to porous ceramic surfaces, comparing a non-CEFIONTECT surface with a CEFIONTECT surface.

4.2 General Cleaning

- Use a soft cloth and mild, non-abrasive cleaner for external surfaces.
- Avoid harsh chemicals or abrasive pads, as these can damage the finish and glaze.
- Regularly wipe down the remote control with a damp cloth.

5. Troubleshooting

This section provides solutions to common issues you might encounter with your TOTO Drake WASHLET+ system. For problems not listed here, please contact TOTO customer support.

5.1 Common Issues and Solutions

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No power to WASHLET	Power cord unplugged, circuit breaker tripped, or power outage.	Ensure power cord is securely plugged in. Check circuit breaker. Verify power supply.
Water spray not working	Water supply valve closed, water filter clogged, or wand blocked.	Open water supply valve. Clean or replace water filter. Check for obstructions around the wand.
Lid not opening/closing automatically	Sensor obstructed or disabled.	Ensure the sensor area is clean and unobstructed. Check remote settings to ensure auto open/close is enabled.
Toilet not flushing properly	Water level in tank too low, flush valve issue, or partial clog.	Adjust water level in tank. Inspect flush valve for proper seating. Clear any clogs.

6. Specifications

Feature	Specification
Model Number	MW7764736CEFG#01
Color	Cotton White
Product Dimensions (D x W x H)	28.38" x 17.19" x 30.13" (721mm x 437mm x 765mm)
Material	Ceramic, Plastic
Item Weight	94 Pounds (42.6 kg)
Installation Type	Floor Mounted
Shape	Elongated Oval
Flush Type	TORNADO FLUSH (1.28 GPF)
Included Components	Toilet bowl, Tank, Electronic Bidet Toilet Seat (WASHLET S7A)
UPC	739268446458

7. Warranty and Support

For warranty information, product registration, or technical assistance, please refer to the official TOTO website or contact TOTO customer support directly. Keep your purchase receipt as proof of purchase for warranty claims.

TOTO Customer Support: Please visit www.totousa.com for contact details and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question