

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOTO](#) /

› **TOTO Drake WASHLET+ Two-Piece Elongated Toilet and S7A Bidet Seat Instruction Manual**

TOTO MW7764736CEFGA#01

TOTO Drake WASHLET+ Two-Piece Elongated Toilet and S7A Bidet Seat Instruction Manual

Model: MW7764736CEFGA#01

1. PRODUCT OVERVIEW

This manual provides essential information for the installation, operation, and maintenance of your TOTO Drake WASHLET+ Two-Piece Elongated 1.28 GPF Universal Height TORNADO FLUSH Toilet and S7A Contemporary Bidet Seat with Auto Flush. This integrated system offers advanced hygiene and comfort features designed for a superior bathroom experience.



Image 1.1: The TOTO Drake WASHLET+ Two-Piece Elongated Toilet, showcasing its modern design and integrated bidet seat.

Key Features:

- **WASHLET S7A Bidet Seat:** Offers gentle yet powerful warm water cleansing with adjustable temperature and pressure, oscillating and pulsating options, and a concealed connection for a seamless look.
- **TORNADO FLUSH:** A rimless, hole-free design with dual-nozzles that creates a centrifugal washing action for efficient bowl cleaning.
- **CEFIONTECT Glaze:** An exceptionally smooth ceramic glaze that minimizes waste from sticking to the bowl surface.
- **EWATER+:** Electrolyzed water system that mists the wand and toilet bowl, reducing the need for harsh cleaning chemicals.
- **PREMIST:** Wets the toilet bowl surface before each use, aiding in waste removal.
- **Auto Flush:** Provides a touchless, hands-free automatic flush after every use.
- **Universal Height:** Taller than standard toilets, providing a more comfortable seating position.
- **Comfort Features:** Includes auto open/close lid, heated seat, instantaneous warm water, night light, warm air dryer, and deodorizer.

2. SETUP AND INSTALLATION

Proper installation is crucial for the optimal performance and longevity of your TOTO Drake WASHLET+ system. It is recommended that installation be performed by a qualified plumber.

2.1 Pre-Installation Checklist:

- Ensure all components are present: toilet bowl, tank, WASHLET S7A bidet seat, and hardware.
- Verify rough-in dimensions match your bathroom plumbing.
- Confirm availability of a standard electrical outlet (120V AC) near the toilet for the WASHLET.

2.2 Required Additional Items (Not Included):

- Wax ring or equivalent toilet seal.
- Toilet mounting bolts.
- Toilet water supply lines.

2.3 Installation Steps (Summary):

1. **Prepare the Area:** Turn off water supply and remove the old toilet if applicable. Clean the flange area.
2. **Install Toilet Bowl:** Secure the toilet bowl to the floor flange using mounting bolts and the wax ring.
3. **Install Tank:** Attach the tank to the toilet bowl, ensuring a tight seal.
4. **Connect Water Supply:** Connect the water supply line to the tank fill valve.
5. **Install WASHLET S7A:** The WASHLET+ design features a concealed connection. Follow the specific instructions provided with the WASHLET for mounting and connecting the power cord and water supply hose discreetly.
6. **Power Connection:** Plug the WASHLET into a grounded electrical outlet.
7. **Test Functionality:** Turn on the water supply, check for leaks, and test all toilet and WASHLET functions.



CONVENTIONAL

VS



CONCEALED

washlet[®]+

WASHLET+ offers a concealed supply connection for seamless installation

Image 2.1: Diagram illustrating the WASHLET+ concealed supply connection for a clean, integrated appearance.

3. OPERATING INSTRUCTIONS

Your TOTO Drake WASHLET+ system is designed for intuitive operation, offering a range of automated and customizable features.

3.1 Basic Toilet Operation:

- **Auto Open/Close Lid:** The lid automatically opens when a user approaches and closes upon departure. This feature can be enabled or disabled via the remote control settings.
- **Auto Flush:** The toilet automatically flushes after each use. This hands-free function ensures hygiene and convenience.
- **TORNADO FLUSH:** This powerful flush system efficiently cleans the bowl with a dynamic, swirling action.

3.2 WASHLET S7A Remote Control Functions:

The illuminated remote control provides access to all WASHLET functions. Familiarize yourself with the button layout for

optimal use.




Image 3.1: Detailed layout of the WASHLET S7A remote control, showing various cleansing and comfort functions.

- **STOP:** Stops washing or drying.
- **REAR/SOFT:** Initiates rear cleansing. Press once for a soft stream, twice for a stronger stream.
- **FRONT/WIDE:** Initiates front cleansing. Press once for a delicate area, twice for a wider area.
- **PRESSURE:** Adjusts water pressure (up/down arrows).
- **POSITION:** Adjusts wand position (left/right arrows).
- **PULSATING:** Varies water pressure for a massage effect.
- **OSCILLATING:** Moves the wand back and forth for a wider cleansing area.
- **DRYER:** Activates the warm air dryer.
- **HEATED SEAT:** Adjusts seat temperature.
- **DEODORIZER:** Activates the air deodorizer to remove odors.
- **USER SETTINGS:** Allows for saving two personal user preferences.



Image 3.2: Visual representation of the WASHLET's auto-open seat, continuous warm water supply, night light, and EWATER+ features.



Image 3.3: Illustration of the WASHLET's heated seat, warm air dryer, deodorizer, and Air-In Wonder-Wave cleansing technology.

4. MAINTENANCE

Regular maintenance ensures the hygiene and optimal performance of your TOTO WASHLET+ system. The system incorporates several self-cleaning technologies to minimize manual cleaning.

4.1 Self-Cleaning Technologies:

- **PREMIST:** Before each use, the toilet bowl is misted with water to help prevent waste from adhering to the ceramic surface, making subsequent cleaning easier.
- **CEFIONTECT:** This ultra-smooth, ion-barrier glaze prevents particles from adhering to the porous ceramic surface, significantly reducing the buildup of mold and grime.
- **EWATER+:** After each use, the WASHLET wand automatically cleanses itself with EWATER+, a safe and powerful disinfectant. EWATER+ also mists the toilet bowl periodically to maintain cleanliness.

CEFIONTECT®

Ceramic glaze minimizes waste from
sticking to porous ceramic surfaces



Image 4.1: Comparison illustrating how CEFIONTECT ceramic glaze minimizes waste from sticking to the toilet bowl surface.




Image 4.2: Visual explanation of EWATER+ technology, showing it misting the wand and toilet bowl for enhanced hygiene.

4.2 General Cleaning:

- **Exterior Surfaces:** Wipe down the exterior of the toilet and WASHLET seat with a soft, damp cloth and mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive pads, which can damage the finish.
- **Nozzle Cleaning:** While the wand is self-cleaning, you can manually clean the nozzle tip if necessary. Refer to the WASHLET user guide for specific instructions on extending the wand for manual cleaning.
- **Filter Cleaning:** Periodically check and clean the water filter located at the water supply connection to the WASHLET. This prevents debris from affecting water flow and spray performance.

5. TROUBLESHOOTING

If you encounter issues with your TOTO Drake WASHLET+ system, refer to the following common troubleshooting tips. For more detailed diagnostics, consult the comprehensive user manual provided with your product or contact TOTO customer support.

Common Issues and Solutions:

- **No Power to WASHLET:**

- Check if the power cord is securely plugged into a functional electrical outlet.
- Verify that the circuit breaker for the bathroom outlet has not tripped.

- **No Water Spray/Weak Spray:**

- Ensure the water supply valve to the toilet is fully open.
- Check the WASHLET water filter for clogs and clean if necessary.
- Confirm water pressure settings on the remote control.

- **Auto Flush Not Working:**

- Ensure the auto flush feature is enabled in the WASHLET settings (refer to the WASHLET manual).
- Check for any obstructions around the sensor.

- **Heated Seat Not Warming:**

- Verify the heated seat function is turned on and the temperature is set correctly via the remote control.

- **Leaks:**

- Immediately turn off the water supply to the toilet.
- Inspect all connections (tank to bowl, water supply line to tank, WASHLET water connection) for loose fittings or damaged seals. Tighten or replace as needed. If the leak persists, contact a plumber.

6. SPECIFICATIONS

Detailed technical specifications for the TOTO Drake WASHLET+ Two-Piece Elongated Toilet and S7A Bidet Seat.



Image 6.1: Dimensional drawing of the TOTO Drake WASHLET+ toilet, including height, width, length, rough-in, and seat height measurements.

Feature	Specification
Model Number	MW7764736CEFGA#01
Brand	TOTO
Color	Cotton White
Product Dimensions (D x W x H)	28.38" x 17.19" x 30.13"
Material	Ceramic, Plastic
Item Weight	94 Pounds
Installation Type	Floor Mounted
Shape	Elongated (Oval)
Flush Volume	1.28 Gallons Per Flush (GPF)

Feature	Specification
Height Type	Universal Height
Included Components	Toilet, Electronic Bidet Toilet Seat
UPC	739268446397

7. WARRANTY AND SUPPORT

TOTO stands behind the quality of its products. For specific warranty details regarding your TOTO Drake WASHLET+ system, please refer to the warranty documentation included with your purchase or visit the official TOTO website.

Customer Support:

If you require assistance with installation, operation, troubleshooting, or warranty claims, please contact TOTO customer support. Have your model number (MW7764736CEFGA#01) and date of purchase ready when contacting support. You can find more information and contact details on the [Official TOTO Store on Amazon](#).