

[Manuals.plus](#) /

› [AGM](#) /

› AGM PAD P1 Rugged Android Tablet User Manual

AGM AGM PAD P1

AGM PAD P1 Rugged Android Tablet User Manual

INTRODUCTION

This manual provides essential information for the proper use and maintenance of your AGM PAD P1 Rugged Android Tablet. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity. The AGM PAD P1 is designed for durability, featuring waterproof, dustproof, and drop-proof capabilities, making it suitable for various environments.

WHAT'S IN THE BOX

Upon unboxing your AGM PAD P1, verify that all the following items are included:

- AGM PAD P1 Rugged Android Tablet
- USB Cable
- Power Adapter
- Protective Case
- User Manual (this document)
- AGM Stickers

PRODUCT OVERVIEW

The AGM PAD P1 features a robust design with a 10.36-inch display and integrated cameras. Familiarize yourself with the device's physical components.



Image: The AGM PAD P1 tablet highlighting its waterproof and drop-proof design, shown submerged in water and on rough terrain with its protective case.

The tablet is equipped with an 8MP main camera on the rear and a 5MP front camera for video calls and selfies.



Image: Close-up view of the AGM PAD P1's rear 8MP main camera with autofocus and the 5MP front camera.

SETUP

1. Charging the Device

Before initial use, fully charge the AGM PAD P1 using the provided USB cable and power adapter. Connect the USB cable to the tablet's charging port and the adapter to a power outlet. The battery indicator on the screen will show charging progress.

2. Powering On/Off

- **To Power On:** Press and hold the Power button until the AGM logo appears on the screen.
- **To Power Off:** Press and hold the Power button until the power options menu appears. Select "Power off" and confirm.

3. Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup process. This includes selecting your language, connecting to a Wi-Fi network, setting up your Google account, and configuring basic device settings.

4. Inserting a microSD Card

The AGM PAD P1 supports expandable storage via a microSD card (up to 2TB). Locate the card slot on the side of the tablet, open the protective cover, and carefully insert the microSD card with the gold contacts facing down until it clicks into place. Close the protective cover securely to maintain water and dust resistance.

OPERATING INSTRUCTIONS

Display and Interface

The tablet features a 10.36-inch 2K (1200 x 2000 pixels) display with a 120Hz refresh rate, providing a clear and smooth visual experience. Navigate the Android 13 operating system using touch gestures.



Image: The AGM PAD P1 tablet displaying vibrant content on its 10.36-inch 2K screen.

Performance

Powered by the MediaTek G99 Octa-core processor (up to 2.2 GHz) and 8GB of RAM, the AGM PAD P1 delivers efficient performance for multitasking, gaming, and media consumption. It runs on Android 13, offering the latest features and security updates.



PERFORMANCE BEAST

Mediatek Helio G99

Octa-core

2.5GHz

6nm




Image: The AGM PAD P1 tablet showcasing its MediaTek Helio G99 processor for high performance.

Storage

The tablet comes with 256GB of internal storage, which can be expanded up to 2TB using a microSD card. This provides ample space for applications, photos, videos, and documents.

Room for everything

A hand holds an AGM PAD P1 tablet displaying a basketball game. The background is a collage of various images including a butterfly, mountains, and a forest. Below the tablet, two dark blue boxes highlight storage options.

256GB
Built-in memory
up to 256GB

SD CARD
Expand your storage
up to 2TB.

Image: The AGM PAD P1 tablet illustrating its 256GB built-in memory and the option to expand storage up to 2TB with an SD card.

Battery Life

Equipped with a 7000mAh Lithium-Ion battery, the AGM PAD P1 offers extended usage time. Battery life varies based on usage patterns and settings.

More Endurance than you



7000mAh
Battery



Long standing
Standby time

7000mAh




Image: The AGM PAD P1 tablet connected to a charger, indicating its 7000mAh battery capacity and long standby time.

Audio

Experience immersive sound with the dual box stereo speakers. The tablet supports various audio formats including MP3, AAC, WAV, and OPUS.

Connectivity

The AGM PAD P1 supports Wi-Fi (802.11a/b/g), Bluetooth, and 4G cellular technology for internet access and peripheral connections. It also includes GPS for navigation.

DURABILITY FEATURES

The AGM PAD P1 is built to withstand challenging environments with its rugged design and IP68/IP69K ratings.

- **Waterproof (IP68/IP69K):** The tablet is protected against continuous immersion in water up to 1.5 meters for 30 minutes (IP68) and against high-pressure, high-temperature water jets (IP69K). Ensure all port covers are securely closed before exposure to water.
- **Drop-Proof:** Designed to endure accidental drops, the tablet's robust construction and included protective

case offer enhanced shock resistance.

- **Dustproof:** The device is fully protected against dust ingress, making it suitable for dusty environments.

Video: An underwater unboxing of the AGM PAD P1, demonstrating its waterproof capabilities and initial boot-up sequence while submerged.

Video: A demonstration of the AGM PAD P1's ruggedness and waterproof features, showcasing its suitability for outdoor and challenging conditions.

MAINTENANCE

- **Cleaning:** Use a soft, damp cloth to clean the tablet's surface. Avoid harsh chemicals or abrasive materials. Ensure all port covers are sealed before cleaning with liquids.
- **Software Updates:** Regularly check for and install system updates to ensure your device has the latest features, security patches, and performance improvements. Go to Settings > System > System update.
- **Battery Care:** To prolong battery life, avoid exposing the tablet to extreme temperatures. Do not let the battery completely drain frequently.

TROUBLESHOOTING

Problem	Solution
Device does not power on	Ensure the battery is charged. Connect the tablet to the charger for at least 30 minutes, then try powering on again.
Touchscreen is unresponsive	Restart the device by holding the Power button for 10-15 seconds. If the issue persists, perform a factory reset (data will be lost).
Wi-Fi connection issues	Check if Wi-Fi is enabled in settings. Restart your router and the tablet. Forget the network and reconnect.
Apps are crashing or slow	Close background apps. Clear app cache (Settings > Apps > [App Name] > Storage > Clear cache). Restart the tablet.

For further assistance, refer to the official AGM support resources.

SPECIFICATIONS

Feature	Detail
Brand	AGM
Model Name	AGM PAD P1
Operating System	Android 13
Processor	MediaTek Helio G99 Octa-core (up to 2.2 GHz)
RAM	8 GB
Internal Storage	256 GB
Expandable Storage	microSD up to 2 TB

Feature	Detail
Screen Size	10.36 Inches
Display Resolution	1200 x 2000 Pixels (2K)
Display Refresh Rate	120 Hz
Rear Camera	8 MP
Front Camera	5 MP
Battery Capacity	7000 mAh Lithium-Ion
Connectivity	Wi-Fi (802.11a/b/g), Bluetooth, 4G, GPS
Durability	IP68/IP69K Waterproof, Drop-Proof, Dustproof
Dimensions (L x W x Thickness)	9.84"L x 6.29"W x 0.35"Th
Item Weight	0.94 Kilograms

WARRANTY AND SUPPORT

The AGM PAD P1 comes with a 1-year manufacturer's limited warranty. For warranty claims or technical support, please contact AGM Mobile directly. Keep your proof of purchase for warranty validation.

Manufacturer: AGM Mobile

For additional support and resources, visit the official AGM website or contact their customer service.