

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOY PLAYER](#) /

› [TOY PLAYER Kanroji Mitsuri Demon Sword Building Set Instruction Manual](#)

TOY PLAYER Kanroji Mitsuri (B0C7G7CSP6)

TOY PLAYER Kanroji Mitsuri Demon Sword Building Set Instruction Manual

Model: Kanroji Mitsuri (B0C7G7CSP6)

1. INTRODUCTION

This manual provides detailed instructions for assembling and caring for your TOY PLAYER Kanroji Mitsuri Demon Sword Building Set. This set allows you to construct a detailed replica of the Kanroji Mitsuri sword, complete with a scabbard and display stand, using 956 precision-fit building blocks. Please read all instructions carefully before beginning assembly.

Recommended Age: 8 years and up.

2. SAFETY INFORMATION

- Small Parts Warning:** This set contains small parts which may pose a choking hazard for children under 3 years of age. Adult supervision is recommended during assembly, especially for younger builders.
- Material Safety:** The building blocks are made from safe, non-toxic ABS material.
- Intended Use:** This product is a building model for display and light play. It is not designed for combat or rough handling. The sword is not sharp and is safe for handling.

3. PACKAGE CONTENTS

Before starting assembly, verify that all components are present. The package should contain:

- 956 premium-quality building blocks.
- Detailed step-by-step instruction manual.
- Decorative stickers.
- Components for the Kanroji Mitsuri sword.
- Components for the scabbard.
- Components for the display stand.



Figure 1: Overview of the assembled Kanroji Mitsuri Demon Sword, scabbard, and display stand.

4. SETUP & ASSEMBLY

Follow the included printed instruction manual for detailed, step-by-step assembly. The process is divided into sections for the sword, scabbard, and display stand.

- 1. Preparation:** Unpack all building blocks and organize them by color or type if desired. Ensure you have a clean, flat surface for assembly.
- 2. Follow Instructions:** Refer to the provided instruction booklet. Each step illustrates the required pieces and their placement.
- 3. Precision Fit:** The bricks are designed for a secure, precision fit. Apply gentle, firm pressure to connect pieces. Avoid excessive force.
- 4. Sticker Application:** Apply decorative stickers as indicated in the instruction manual for enhanced detail.



Figure 2: Assembly in progress, showing the instruction manual, loose blocks, and partially constructed sword and scabbard.



Figure 3: Detailed view of the sword's hilt, blade design, and the scabbard's end cap, highlighting the intricate block construction.

5. OPERATING INSTRUCTIONS (DISPLAY AND HANDLING)

Once assembled, your Kanroji Mitsuri Demon Sword model is ready for display or light handling.

- **Display:** Place the assembled sword and scabbard on the dedicated display stand. Ensure the stand is on a stable, flat surface to prevent accidental falls.
- **Sheathing/Unsheathing:** The scabbard is designed to fit the sword. Gently slide the sword into and out of the scabbard. Avoid forcing it, as this may damage the blocks.
- **Handling:** The sword is approximately 39 inches long and offers a comfortable grip. It supports light swinging for display or posing. Avoid strong impacts or bending, which could cause pieces to detach.




Figure 4: The assembled sword and scabbard, demonstrating its size and how it can be held. The image also highlights the safe ABS material used in its construction.

6. MAINTENANCE

To ensure the longevity and appearance of your building set:

- **Cleaning:** Dust regularly with a soft, dry cloth. For more thorough cleaning, gently wipe with a damp cloth and mild soap, then dry immediately. Avoid harsh chemicals or abrasive materials.
- **Storage:** When not on display, store the set in a cool, dry place away from direct sunlight to prevent discoloration or material degradation.
- **Disassembly:** If disassembling, do so carefully to avoid damaging the connection points of the blocks.

7. TROUBLESHOOTING

- **Missing Pieces:** If you discover any missing pieces in your kit, please contact customer support with the details of the part. Refer to the parts list in your instruction manual to identify the specific missing components.
- **Loose Connections:** If blocks are not holding together securely, ensure they are fully pressed into

place. Check for any debris or foreign objects preventing a proper connection.

- **Difficulty with Instructions:** If you encounter difficulty understanding any step, review the previous steps and illustrations carefully. Online resources or community forums may also offer assistance.

8. SPECIFICATIONS

Attribute	Detail
Model Name	Kanroji Mitsuri Demon Sword Building Set
Model Number (ASIN)	B0C7G7CSP6
Brand	TOY PLAYER
Number of Pieces	956
Assembled Length	Approximately 39 inches (99 cm)
Material	ABS Plastic
Recommended Age	8 years and up
Package Dimensions	10.79 x 8.66 x 4.21 inches (27.4 x 22 x 10.7 cm)
Item Weight	2.2 pounds (1 kg)

Produkt Größe




Figure 5: Dimensional diagram of the assembled sword and scabbard, indicating overall length and other measurements.

9. WARRANTY AND SUPPORT

TOY PLAYER is committed to providing quality products. While this product does not come with an explicit warranty statement in the provided information, customer support is available for assistance.


Missing Parts: If you find any missing pieces in your building set, please contact TOY PLAYER customer support directly. Provide details of the missing part(s) for prompt assistance.

Contact Information: For support inquiries, please refer to the contact details provided on the product packaging or the official TOY PLAYER store page on Amazon: [TOY PLAYER Store](#).

© 2023 TOY PLAYER. All rights reserved.


Related Documents - Kanroji Mitsuri (B0C7G7CSP6)





[Sluban M38-B0955 Sports Car Building Toy Assembly Instructions](#)

Detailed assembly guide for the Sluban M38-B0955 262-piece Sports Car building toy. Includes safety warnings and step-by-step instructions for construction.



[K'NEX Rocket Launcher 500pc Building Set Instructions](#)

Detailed building instructions and parts list for the K'NEX Rocket Launcher 500pc Building Set (Model 80212). Includes building basics, parts identification, and safety information.



[Plus-Plus Siberian Husky Building Toy Assembly Instructions](#)

Step-by-step guide to building the Plus-Plus Siberian Husky toy. Learn how to assemble this creative construction toy with clear instructions and tips for builders.




[K'NEX Power & Play Motorized Building Set: Creative Construction for Ages 7-12](#)

Discover the K'NEX Power & Play Motorized Building Set, a comprehensive construction toy for ages 7-12. Learn building basics, battery requirements, and explore 50 model ideas. Find detailed instructions online.



[Classic World Temple of Heaven Building Set Assembly Instructions](#)

Step-by-step guide for assembling the Classic World Temple of Heaven toy building set, suitable for ages 3+.





[Galaxy Light Sword: Assembly, Play Modes, and Battery Instructions](#)

A comprehensive guide to the USA Toyz Galaxy Light Sword, covering assembly, how to use its various play modes, battery installation, and important safety information for users aged 6 and up.