

[Manuals.plus](#) /

› [WOBANE](#) /

› WOBANE 24W Power Adapter (Model WBE023) Instruction Manual

WOBANE WBE023

WOBANE 24W Power Adapter (Model WBE023) Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and efficient use of your WOBANE 24W Power Adapter (Model WBE023). Please read these instructions carefully before installation and operation to ensure proper functionality and longevity of the product.

PRODUCT OVERVIEW

The WOBANE 24W Power Adapter is designed to provide reliable power to compatible WOBANE LED light bars, including models CS6, CS6-COB, CS8, and CS03. It features an in-line switch for convenient control and supports connecting up to 14 LED light bars (totaling approximately 13.7 feet).

Key Features:

- 24W ETL listed adapter for safety and quality.
- Integrated in-line switch for easy power control.
- Compatible with various WOBANE LED light bar models (CS6, CS6-COB, CS8, Puck light).
- Supports connection of up to 14 light bars.
- Includes a 3-pin connector for expanding your lighting setup.



This image shows the WOBANE 24W power adapter with its specifications printed on the side, alongside an example of WOBANE LED strip lights installed under kitchen cabinets, illuminating the countertop.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove the power adapter and any included accessories from the packaging.
2. **Connect to Light Bar:** Ensure the power adapter's DC connector is securely plugged into the input port of your WOBANE LED light bar. If connecting multiple light bars, use the 3-pin connector to link them sequentially.
3. **Power Connection:** Insert the adapter's standard US 2-prong plug into a standard AC 100-240V wall outlet.
4. **Secure Cables:** Use cable holders (if provided or purchased separately) to neatly fix the DC plug and other cables, preventing accidental disconnections or damage.
5. **Compatibility Note:** This adapter can power a maximum of 14 WOBANE LED light bars. Exceeding this limit may lead to reduced performance or damage to the adapter.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Use the in-line switch located on the power cord to turn the connected LED light bars on or off.
2. **Continuous Use:** The adapter is designed for continuous operation within its specified limits. Avoid overloading the adapter by connecting more than the recommended number of light bars.

MAINTENANCE

- **Cleaning:** Disconnect the adapter from the power outlet before cleaning. Wipe the adapter with a dry, soft cloth. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid extreme temperatures and humidity.
- **Inspection:** Periodically inspect the power cord and adapter housing for any signs of damage. Discontinue use immediately if damage is observed.

TROUBLESHOOTING

Lights Not Turning On:

- Ensure the adapter is securely plugged into both the wall outlet and the LED light bar.
- Verify the in-line switch is in the 'On' position.
- Check the wall outlet by plugging in another device to confirm it has power.

Lights Flickering:

- Flickering can indicate an overloaded adapter. Reduce the number of connected LED light bars to ensure the total wattage does not exceed 24W.
- If flickering persists with a compatible load, the adapter may need replacement.

Partial Light Bar Illumination:

- Check all 3-pin connections between light bars for secure contact.
- Ensure no individual light bar is faulty.

SPECIFICATIONS

Brand	WOBANE
Model	WBE023
Input	AC 100-240V, 50/60Hz, 0.8A Max
Output	DC 12V, 2.0A
Wattage	24W
Connector Type	DC Barrel Connector, 3-Pin Connector
Compatible Devices	WOBANE LED Light Bars (CS6, CS6-COB, CS8, CS03, Puck light)
Special Features	ETL Listed, Short Circuit Protection
Included Components	Power Adapter, Accessories
Power Source	Corded Electric

Material	Plastic
----------	---------

WARRANTY AND SUPPORT

Warranty: This WOBANE 24W Power Adapter comes with a 1-year limited warranty from the date of purchase. This warranty covers manufacturing defects under normal use and conditions.

Support: For technical assistance, warranty claims, or further inquiries, please contact WOBANE customer support through the retailer's platform or the official WOBANE website. Please have your model number (WBE023) and purchase information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question