

[manuals.plus](#) /› [ZEBRONICS](#) /› [Zebronics 43P1 Smart LED TV User Manual](#)

## ZEBRONICS 43P1

# Zebronics 43P1 Smart LED TV User Manual

Model: Zebronics 43P1

## 1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Zebronics 43P1 Smart LED TV. Please read this manual thoroughly before using the product to ensure proper functionality and safety. Keep this manual for future reference.

## 2. PACKAGE CONTENTS

Verify that all items listed below are included in your product packaging:

- Smart LED TV - 1 Unit
- Remote Control - 2 Units
- Table Top Stand - 2 Units
- Wall Mounting Brackets with Fasteners - 1 Unit
- AAA Batteries - 1 Unit
- User Manual - 1 Unit



Image: The Zebronics 43P1 Smart LED TV shown with its included remote control and table-top stand. The screen displays an image of hands playing drums.

### 3. INITIAL SETUP

#### 3.1 Installing the Table Top Stand

1. Carefully place the TV screen-down on a soft, flat surface to prevent damage.
2. Align the two table top stand units with the screw holes on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are tightened firmly.
4. Carefully lift the TV and place it on a stable, level surface.

#### 3.2 Wall Mounting (Optional)

The TV supports wall mounting. Use the provided wall mounting brackets and fasteners. Professional installation is recommended for wall mounting to ensure safety and proper alignment.

#### 3.3 Connecting Power

1. Connect the power cord to the TV's power input.
2. Plug the other end of the power cord into a suitable electrical outlet.

## 3.4 Initial Power-On and Setup Wizard

1. Press the power button on the remote control or the TV.
2. Follow the on-screen instructions to complete the initial setup, including language selection, network connection, and channel scanning.

## 4. OPERATING INSTRUCTIONS

### 4.1 Remote Control Functions

Insert the provided AAA batteries into the remote control. The remote allows you to control all TV functions, including power, volume, channel selection, input source, and smart features. The remote also features a voice assistant button for convenient control.

### 4.2 Basic Navigation

- Use the directional arrows (**Up, Down, Left, Right**) to navigate menus.
- Press **OK** or **Enter** to confirm selections.
- Press **Back** or **Exit** to return to the previous screen or exit a menu.
- The **Home** button provides access to the Smart TV interface.

### 4.3 Input Source Selection

Press the **Source** button on the remote to switch between connected devices (e.g., HDMI 1, HDMI 2, AV, TV Tuner).

## 5. CONNECTIVITY

The Zebronics 43P1 offers multiple connectivity options:

- **HDMI Ports:** Two HDMI inputs, including one with Audio Return Channel (ARC) support for simplified audio connections to soundbars or AV receivers.
- **USB Ports:** Two USB ports for connecting external storage devices to play media files.
- **Optical Out:** For high-quality digital audio output to external audio systems.
- **AUX Out:** Analog audio output.
- **AV In:** Two AV inputs for connecting older devices using composite video and stereo audio cables.
- **RJ45 (Ethernet):** For a wired internet connection.
- **RF Input:** For connecting an antenna or cable TV signal.

## 6. SMART FEATURES

### 6.1 Wi-Fi Connection

1. Go to **Settings > Network & Internet**.
2. Select **Wi-Fi** and choose your network from the list.
3. Enter the Wi-Fi password if prompted.

### 6.2 Bluetooth Pairing

1. Go to **Settings > Remotes & Accessories**.

2. Enable Bluetooth on the TV and your desired device (e.g., headphones, soundbar).
3. Select your device from the list to pair.

## 6.3 Voice Assistant

Press the dedicated Voice Assistant button on your remote control. Speak clearly into the remote to issue commands such as changing channels, adjusting volume, searching for content, or opening applications.

## 6.4 App Support

The TV runs on an Android operating system, allowing access to a variety of applications through its app store. Ensure a stable internet connection for optimal app performance.

# 7. MAINTENANCE

## 7.1 Cleaning the Screen

- Turn off the TV and unplug it from the power outlet.
- Gently wipe the screen with a soft, lint-free microfiber cloth.
- For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner (do not spray directly onto the screen).
- Avoid using harsh chemicals, abrasives, or alcohol-based cleaners.

## 7.2 Cleaning the TV Body

Wipe the TV's frame and back panel with a soft, dry cloth. Do not use liquid cleaners directly on the TV body.

## 7.3 Safety Precautions

- Do not block ventilation openings.
- Keep the TV away from direct sunlight, heat sources, and moisture.
- Unplug the TV during lightning storms or when unused for extended periods.

# 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord disconnected; Power outlet issue	Ensure power cord is securely connected. Check if the power outlet is working.
No picture or sound	Incorrect input source; Loose cable connection	Press the <b>Source</b> button to select the correct input. Check all cable connections.
Remote control not working	Dead batteries; Obstruction between remote and TV	Replace batteries. Remove any obstructions. Ensure remote is pointed at the TV's IR sensor.
Wi-Fi connection issues	Incorrect password; Router issues; Signal interference	Re-enter Wi-Fi password. Restart your router. Move TV closer to router or reduce interference.
Poor picture quality	Low signal strength; Incorrect picture settings	Check antenna/cable connection. Adjust picture settings (brightness, contrast, sharpness) in the TV menu.

# 9. TECHNICAL SPECIFICATIONS

<b>Brand</b>	ZEBRONICS
<b>Model Name</b>	Zebronics 43P1
<b>Display Technology</b>	Smart LED
<b>Screen Size</b>	43 Inches (109 cm)
<b>Resolution</b>	1920 x 1080 (FHD)
<b>Refresh Rate</b>	60 Hz
<b>Operating System</b>	Android
<b>Audio Output</b>	20W Stereo Speakers
<b>Connectivity</b>	Built-in Wi-Fi, Bluetooth, 2x HDMI (1x ARC), 2x USB, Optical Out, AUX Out, 2x AV In, RJ45, RF Input
<b>Special Features</b>	Frameless Design, Voice Assistant Remote, A+ Grade Display Panel, Ultra Slim Bezel
<b>Mounting Type</b>	Wall Mount / Table Top Stand
<b>Product Dimensions (LxWxH)</b>	80 x 96 x 56 cm
<b>Item Weight</b>	1.88 kg

## 10. WARRANTY AND SUPPORT

### 10.1 Warranty Information

Your Zebronics 43P1 Smart LED TV comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your purchase receipt as proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

### 10.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Zebronics customer support. Refer to the official Zebronics website or your product packaging for the most current contact information.

### Related Documents - 43P1

15-7-22

The image shows the front cover of the Zebronics ZEB-43P1 LED TV User Manual. It features a large image of the TV on the left, with the text 'ZEBRONICS' at the top, 'ZEB-43P1' in the center, and 'USER MANUAL' at the bottom. The background is white with some decorative lines.

### [Zebronics ZEB-43P1 LED TV User Manual and Settings Guide](#)

Detailed guide for the Zebronics ZEB-43P1 LED TV, covering picture, sound, network, system, and Bluetooth settings. Includes setup information and disclaimer.

The image shows the front cover of the Zebronics Zeb-Bang Headphones User Guide and FAQ. It features a large image of the headphones on the left, with the text 'ZEBRONICS' at the top, 'Zeb-Bang Headphones' in the center, and 'User Guide & FAQ' at the bottom. The background is white with some decorative lines.

### [Zebronics Zeb-Bang Headphones User Guide and FAQ](#)

A comprehensive guide to connecting, operating, and troubleshooting the Zebronics Zeb-Bang wireless headphones, covering LED indications, modes, voice assistant, media control, call functions, and charging.

The image shows the front cover of the Zebronics ZEB-BOOM Wireless Headphone User Manual. It features a large image of the headphones on the left, with the text 'ZEBRONICS' at the top, 'Wireless Headphone' in the center, and 'User Manual' at the bottom. The background is white with some decorative lines.

### [Zebronics ZEB-BOOM Wireless Headphone User Manual](#)

Comprehensive user manual for the Zebronics ZEB-BOOM Wireless Headphone (Model ZEB-WHP2), covering features, specifications, button functions, connectivity, and LED indicators.

The image shows the front cover of the ZEB SOUND FEAST 50 FAQ. It features a large image of the speaker on the left, with the text 'ZEBSOUND' at the top, 'FEAST 50' in the center, and 'FAQ' at the bottom. The background is white with some decorative lines.

### [ZEB SOUND FEAST 50 FAQ: User Guide and Troubleshooting](#)

Frequently Asked Questions (FAQ) for the ZEB SOUND FEAST 50 portable speaker, covering connectivity, controls, TWS function, and charging. Get answers to common user queries.

The image shows the front cover of the Zebronics ZEB-MIST Wireless Earbuds User Manual. It features a large image of the earbuds and a charging case on the left, with the text 'ZEBRONICS' at the top, 'ZEB-MIST' in the center, and 'User Manual' at the bottom. The background is white with some decorative lines.

### [Zebronics ZEB-MIST Wireless Earbuds User Manual](#)


User manual for Zebronics ZEB-MIST wireless earbuds, covering features, specifications, pairing, charging, and usage instructions for a seamless audio experience.



### [Zebronics ZEB-PODS B15 Wireless Earbuds User Manual | Features, Specifications, and Usage Guide](#)

Comprehensive user manual for Zebronics ZEB-PODS B15 wireless earbuds. Find detailed information on features, technical specifications, pairing instructions, usage controls, charging methods, and warranty policy.

## Documents - ZEBRONICS – 43P1



### [Zebronics ZEB-43P1 LED TV User Manual and Settings Guide](#)

Detailed guide for the Zebronics ZEB-43P1 LED TV, covering picture, sound, network, system, and Bluetooth settings. Includes setup information and disclaimer.  
lang:en score:30 filesize: 11.36 M page\_count: 32 document date: 2022-07-19