

BARBERBOSS QR-2083

BarberBoss QR-2083 Hair and Beard Trimmer User Manual

Model: QR-2083

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the BarberBoss QR-2083 trimmer. Keep this manual for future reference.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use the trimmer if the blades are damaged or broken, as this may cause injury.
- Only use the charging cable provided with the trimmer.
- Do not immerse the charging adapter in water or other liquids.
- Ensure the trimmer is switched off before cleaning or performing maintenance.
- This trimmer is 100% waterproof and can be rinsed under running water. However, do not immerse the trimmer in water for extended periods.
- Keep the trimmer away from heat sources and direct sunlight.

2. PRODUCT OVERVIEW

The BarberBoss QR-2083 is a versatile hair and beard trimmer designed for precise grooming. It features advanced ceramic blades, multiple speed settings, and a waterproof design for convenience.

Key Features:

- **Advanced Ceramic Blade:** Precisely sharpened ceramic blades maintain sharpness for exceptional performance and a finer cut.
- **Customizable Speed Modes:** Four adjustable speed settings (55, 60, 65, 70 RPM) to suit different hair textures.
- **Versatile Comb Attachments:** Includes 8 comb attachments for cutting lengths from 3mm to 24mm.
- **Precision Trimming without Combs:** Achieve lengths of 1mm, 1.3mm, 1.6mm, and 1.9mm without comb attachments.
- **Wet and Dry Capability:** Suitable for use in both wet and dry conditions, compatible with shaving gel or foam.
- **100% Waterproof:** Easy to clean by rinsing under running water.
- **LED Indicator and Fast USB Charging:** Real-time LED display for battery life and 180 minutes of use on a 3-hour charge via USB.
- **Compact and Ergonomic Design:** Lightweight and comfortable for effortless operation.

Package Contents:

The BarberBoss QR-2083 grooming kit typically includes:

- BarberBoss QR-2083 Trimmer
- 8 Comb Attachments (3mm, 6mm, 9mm, 12mm, 15mm, 18mm, 21mm, 24mm)
- USB Charging Cable
- Cleaning Brush
- Lubricating Oil
- User Manual
- Hair Comb
- Hair Cutting Cape



Image: Contents of the BarberBoss QR-2083 grooming kit, including the trimmer, various comb attachments, USB cable, cleaning brush, oil, comb, and cape.

3. GETTING STARTED (SETUP)

3.1 Charging the Trimmer

Before first use, fully charge the trimmer for approximately 3 hours. A full charge provides up to 180 minutes of

cordless operation.

1. Ensure the trimmer is switched off.
2. Connect the USB charging cable to the trimmer's charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., computer, power bank, 5V USB wall adapter, car charger).
4. The LED display will show the charging progress. When fully charged, the display will indicate 100%.



Image: The BarberBoss QR-2083 trimmer connected to a USB port for charging, with the LED display showing battery status.



Image: Illustration of different USB charging options, including laptop, power bank, wall adapter, and car charger.

3.2 Attaching and Detaching Comb Guides

The trimmer comes with 8 comb attachments for various cutting lengths.

- **To Attach:** Align the comb guide with the trimmer blade and push it firmly until it clicks into place.
- **To Detach:** Gently pull the comb guide upwards from the trimmer blade.



Image: The BarberBoss QR-2083 trimmer shown with various comb attachments, demonstrating how they fit onto the blade.

4. OPERATION

4.1 Powering On/Off and Speed Adjustment

1. **To Power On:** Press the power button once. The LED display will light up, showing the current battery percentage and speed setting.
2. **To Adjust Speed:** Press the '+' or '-' buttons to cycle through the four speed settings (55 RPM, 60 RPM, 65 RPM, 70 RPM). Select the speed appropriate for your hair type and desired cut.
3. **To Power Off:** Press and hold the power button for a few seconds until the display turns off.



Image: Close-up of the trimmer's LED display showing battery percentage and speed settings (55, 60, 65, 70 RPM).

4.2 Using the Trimmer without Comb Guides

For very short cuts, precise edging, or detailing, the trimmer can be used without a comb attachment. The blade itself offers four precise cutting lengths:

- 1.0 mm
- 1.3 mm
- 1.6 mm
- 1.9 mm

To adjust these lengths, use the integrated adjustment lever on the side of the trimmer.



Image: The trimmer being used to demonstrate cutting hair at different lengths (1.0mm, 1.3mm, 1.6mm, 1.9mm) without a comb attachment.

4.3 Using the Trimmer with Comb Guides

For longer hair cuts, attach the desired comb guide (3mm to 24mm) as described in Section 3.2.

1. Select the appropriate comb guide for your desired hair length.
2. Turn on the trimmer and select a suitable speed setting.
3. Hold the trimmer with the comb guide flat against the head or beard, and move it slowly against the direction of hair growth.
4. For an even cut, ensure consistent pressure and movement.

4.4 Wet and Dry Use

The BarberBoss QR-2083 is designed for both wet and dry use. You can use it on dry hair, or with shaving gel or foam for a more comfortable wet shave. Its waterproof design ensures safe operation in wet conditions.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure optimal performance and extend the life of your trimmer.

5.1 Cleaning the Blades

1. Ensure the trimmer is switched off and disconnected from the charging cable.
2. Remove any attached comb guide.
3. Use the provided cleaning brush to brush away loose hairs from the blades.
4. Since the trimmer is 100% waterproof, you can rinse the blade head directly under running water to remove stubborn hair and debris.
5. Shake off excess water and allow the blades to air dry completely before storing or reattaching a comb guide.



Image: The BarberBoss QR-2083 trimmer being rinsed under running water, highlighting its waterproof feature for easy cleaning.

5.2 Lubricating the Blades

For best performance, it is recommended to lubricate the blades after every few uses, or if you notice the trimmer is pulling hair.

1. After cleaning and drying the blades, apply 1-2 drops of the provided lubricating oil onto the blades.
2. Turn on the trimmer for a few seconds to allow the oil to distribute evenly.
3. Wipe off any excess oil with a soft cloth.

5.3 Storage

Store the trimmer in a cool, dry place, away from direct sunlight and out of reach of children.

6. TROUBLESHOOTING

If you encounter any issues with your BarberBoss QR-2083 trimmer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer fully.
Trimmer pulls hair or cuts poorly.	Blades are dirty or not lubricated.	Clean and lubricate the blades as per Section 5.
Trimmer is making unusual noise.	Blades may be misaligned or dirty.	Clean and lubricate the blades. If the issue persists, contact customer support.
LED display is not working.	Trimmer may be damaged or battery is completely dead.	Attempt to charge the trimmer. If it still doesn't work, contact customer support.

If the problem persists after trying these solutions, please contact BarberBoss customer support for assistance.

7. SPECIFICATIONS

Feature	Detail
Model Name	QR-2083
Brand	BARBERBOSS
Blade Material	Ceramic
Power Source	Rechargeable Battery (USB)
Special Features	Cordless, Waterproof
Speed Settings	4 (55, 60, 65, 70 RPM)
Comb Attachments	8 (3mm, 6mm, 9mm, 12mm, 15mm, 18mm, 21mm, 24mm)
Precision Lengths (without comb)	1.0mm, 1.3mm, 1.6mm, 1.9mm
Charging Time	Approx. 3 hours
Operating Time	Up to 180 minutes
Target Audience	Men
Country of Origin	China
Package Dimensions	26.6 x 16.8 x 10.5 cm
Package Weight	770 grams

8. WARRANTY AND SUPPORT

BarberBoss products are manufactured to high-quality standards. For warranty information or if you require any assistance with your QR-2083 trimmer, please refer to the warranty card included in your package or contact BarberBoss customer support through the retailer where you purchased the product.

Please have your model number (QR-2083) and proof of purchase ready when contacting support.