

[Manuals.plus](#) /

› [Best Choice Products](#) /

› Best Choice Products 12V Kids Ride On Truck Car Instruction Manual

Best Choice Products SKY6743

Best Choice Products 12V Kids Ride On Truck Car Instruction Manual

Model: SKY6743

Brand: Best Choice Products

INTRODUCTION

This manual provides essential information for the safe and effective operation, assembly, and maintenance of your Best Choice Products 12V Kids Ride On Truck Car. Please read all instructions carefully before use to ensure proper function and safety for your child.

SAFETY INFORMATION

To reduce the risk of injury, adult supervision is required at all times. Never use this ride-on truck on roadways, near motor vehicles, on or near steep inclines or steps, swimming pools, or other bodies of water. Always ensure the child wears shoes, and never allow more than one rider at a time.

This product is intended for children 3 years and older with a maximum weight capacity of 61 lbs.

PRODUCT FEATURES

- **Powerful 12V Motor & Realistic Design:** Features a 12V motor, traction tires for various terrains, adjustable seatbelt, bright LED headlights, lockable doors, and a grid windshield for an authentic off-road style.
- **Manual and Parent Control:** Allows children to drive manually using the pedal and steering wheel, or parents can safely guide them using the included remote control with forward/reverse and steering functions.
- **Safe & Durable Construction:** Equipped with durable plastic wheels that will not deflate, a spring suspension system for smooth rides, and a safe maximum speed of 2.8mph.
- **Connect Your Music:** A built-in AUX outlet and Bluetooth speakers allow kids to connect media devices and enjoy their favorite music while driving.

COMPONENTS OVERVIEW



Figure 1: Overall view of the 12V Kids Ride On Truck Car in Hot Pink.



Bluetooth Speakers

Connect your favorite devices and add a soundtrack to playtime



Figure 2: Close-up of the dashboard featuring the steering wheel, media console with Bluetooth speakers, and control buttons.

Parent Remote Control

Stand back and watch or take control
and join your kids for playtime!



Figure 3: The parental remote control, allowing adults to safely guide the vehicle.

SETUP AND ASSEMBLY

The ride-on truck comes mostly assembled. Refer to the included "Assembly Guide" PDF for detailed step-by-step instructions on attaching wheels, steering wheel, and connecting the battery. Ensure all connections are secure before first use.

Charging the Battery

Locate the charging port, typically found under the seat or near the battery compartment. Connect the provided charger to the port and then to a standard wall outlet. The indicator light on the charger will show charging status. Allow sufficient time for a full charge before initial use, as specified in the assembly guide. Disconnect the charger once fully charged.

OPERATING INSTRUCTIONS

Manual Driving

- **Power On:** Press the power button on the dashboard to turn on the truck.
- **Forward/Reverse:** Use the gear shift lever (usually a switch on the dashboard) to select forward or reverse.
- **Acceleration:** Press the foot pedal to accelerate. The truck will automatically brake when the foot pedal is released.
- **Steering:** Use the steering wheel to control the direction of the truck.

Parental Remote Control

The remote control allows parents to override manual controls for added safety, especially for younger children. Ensure the remote control is paired with the truck as per the assembly guide.

- **Forward/Reverse:** Use the designated buttons on the remote for forward and reverse movement.
- **Steering:** Use the directional buttons on the remote to steer left or right.
- **Speed Control:** Some models may feature speed selection on the remote. Refer to your specific remote's instructions.

Audio Features

- **Horn:** Press the horn button on the steering wheel for sound.
- **Engine Sounds:** The truck may produce engine start-up sounds when powered on.
- **Bluetooth Connectivity:** To connect your phone, press the mode button on the media console until "Bluetooth" is announced. Then, search for "Best Choice Products" on your device's Bluetooth settings and pair.
- **AUX Port:** Use the AUX port to connect other media devices directly.

MAINTENANCE

- **Cleaning:** Wipe the truck with a damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Battery Care:** Charge the battery fully after each use. If storing for extended periods, charge the battery at least once a month to prolong its lifespan. Do not overcharge.
- **Storage:** Store the truck in a dry, cool place away from direct sunlight and moisture.
- **Inspection:** Regularly check all screws, nuts, and connections to ensure they are tight and secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Truck does not move.	Battery is low or disconnected.	Charge the battery; ensure battery connectors are secure.
Remote control not working.	Remote batteries are dead or not paired.	Replace remote batteries; re-pair remote as per instructions.
Unusual noise during operation.	Loose parts or debris in wheels.	Inspect and tighten loose components; clear any obstructions.

SPECIFICATIONS

- **Product Dimensions:** 39.25" (L) x 26" (W) x 26" (H)
- **Item Weight:** 32 pounds
- **Weight Capacity:** 61 lbs
- **Recommended Age:** 3 years and up
- **Max Speed:** 2.8mph
- **Model Number:** SKY6743

- **Manufacturer:** Best Choice Products

WARRANTY AND SUPPORT

For warranty information or further support, please refer to the contact details provided in your original purchase documentation or visit the official Best Choice Products website. Keep your proof of purchase for any warranty claims.

Additional resources, including the full Assembly Guide, can be found at: <https://m.media-amazon.com/images/I/B11y1aHGPyL.pdf>

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question