

[Manuals.plus](#) /

› [Ludex](#) /

› Ludex Magazine Speed Loader Instruction Manual

Ludex speed loader

Ludex Magazine Speed Loader Instruction Manual

Model: Speed Loader | Brand: Ludex

1. PRODUCT OVERVIEW

The Ludex Magazine Speed Loader is designed to facilitate quick and effortless loading of 9mm and .40 caliber ammunition into compatible Glock magazines. Its unique design minimizes thumb contact, providing a pain-free loading experience. This device is constructed from durable polymer materials, offering resistance to heat and scratches.



Image: The Ludex Magazine Speed Loader in Army Green, showcasing its compact and robust design.

ARE YOU STILL LOADING LIKE THIS?

My fingers hurt and I
loaded slowly.



FASTEST AND EASIEST TO LOAD



INNOVATIVE DESIGN

There is no contact
between the thumb
and the magazine
opening when you are
loading. Achieve "no
pain" in the true sense.

Image: Illustration highlighting the innovative design of the speed loader, which prevents direct thumb contact with the magazine opening during loading, ensuring a comfortable experience.

2. COMPATIBILITY

This speed loader is compatible with 9mm and .40 S&W caliber magazines. It is specifically designed to fit the following Glock models:

- Glock 17
- Glock 18
- Glock 19
- Glock 22
- Glock 23
- Glock 24
- Glock 26

- Glock 27
- Glock 34
- Glock 35
- Glock 45
- Glock 47

It also accommodates magazines from other brands that are compatible with the listed Glock models.



Image: A visual representation listing the various Glock models compatible with the Ludex speed loader, including Glock 17, 18, 19, 22, 23, 24, 26, 27, 34, 35, 45, and 47.

3. OPERATING INSTRUCTIONS

The Ludex Magazine Speed Loader simplifies the loading process into just two main steps. Follow these instructions for efficient and fast magazine loading:

1. **Insert Magazine:** Place your compatible Glock magazine into the designated mounting port on the speed loader. Ensure it is seated firmly.
2. **Insert Bullet and Load:** Insert a bullet into the bullet inlet. Then, press the magazine downwards firmly from the direction of the warhead. This action will push the bullet into the magazine. Repeat this step for each subsequent round until the magazine is full.

THE SIMPLEST DESIGN.

Only 2 steps to complete the loading when you insert the magazine into the loader.



Image: A close-up view of the speed loader, clearly labeling the 'Magazine Mounting Port' where the magazine is inserted and the 'Bullet Inlet' where ammunition is placed.

EXTREMELY FAST LOADING

Compatible caliber 9mm and .40
S&W.

Fits Glock 17,18,19,22,23,24,
26,27,34,35,45,47.

Also fits mags of other brands
compatible with the above models.

1 **FASTEST**
BULLET/SECOND



Image: A visual demonstrating the process of loading a bullet into a magazine with the speed loader, emphasizing the speed and ease of the operation.

LOADING STEP



Insert magazine into speed loader.



Put bullet slide into speed loader.



Press forward firmly from the direction of the warhead, and then release. Repeat the steps until it is full.

Image: A sequential three-step diagram illustrating the loading process: 1) Inserting the magazine, 2) Placing the bullet, and 3) Pressing down to load, with clear arrows indicating motion.

4. CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your Ludex Magazine Speed Loader, follow these general care and maintenance guidelines:

- **Cleaning:** Wipe the speed loader with a clean, dry cloth after each use to remove any dust, debris, or residue. Avoid using harsh chemicals or abrasive cleaners, as they may damage the polymer material.
- **Storage:** Store the speed loader in a cool, dry place away from direct sunlight and extreme temperatures. Protect it from impacts or heavy objects that could cause deformation or damage.
- **Inspection:** Periodically inspect the speed loader for any signs of wear, cracks, or damage. If any significant damage is observed, discontinue use and consider replacement.

5. TROUBLESHOOTING

If you encounter any issues while using your Ludex Magazine Speed Loader, consider the following common troubleshooting tips:

- **Difficulty Loading:** Ensure the magazine is fully seated in the loader. Verify that the ammunition caliber matches the loader's compatibility (9mm or .40 S&W). Apply firm, consistent pressure when pushing down to load.
- **Magazine Not Fitting:** Confirm that your magazine is one of the compatible Glock models listed in Section 2, or a compatible equivalent. Do not force the magazine into the loader if it does not fit properly.
- **Loader Feels Stiff:** New loaders may feel slightly stiff initially. Continued use should smooth out the operation. Ensure no foreign objects are obstructing the mechanism.

If problems persist after attempting these solutions, please refer to the Warranty and Support section for further assistance.

6. SPECIFICATIONS

Feature	Detail
Brand	Ludex
Model Name	speed loader
Color	Army Green
Material	Plastic
Product Dimensions (L x W x H)	2.91" x 1.61" x 3.19"
Item Weight	0.12 Kilograms
UPC	735280792986




Image: A detailed view of the Ludex speed loader with its key dimensions labeled: 3.19 inches in height, 1.61 inches in width, and 2.91 inches in length, illustrating its compact size.

POCKET SIZE EASY TO CARRY



Image: The speed loader being placed into a jeans pocket, demonstrating its small and portable size for easy carrying.

7. WARRANTY AND SUPPORT

Ludex offers a worry-free **1-year manufacturer warranty** for this speed loader. This warranty covers defects in materials and workmanship under normal use.

For any issues, questions, or concerns regarding your Ludex Magazine Speed Loader, please contact Ludex customer service.

Friendly customer service is available to assist you.

Please retain your proof of purchase for warranty claims.

© 2025 Ludex. All rights reserved.

This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question