

Silvercrest SKMS 1200 A1

Silvercrest® Monsieur Cuisine Smart SKMS 1200 A1 Food Processor User Manual

Brand: Silvercrest® | Model: SKMS 1200 A1

1. INTRODUCTION

The Silvercrest® Monsieur Cuisine Smart SKMS 1200 A1 is a versatile food processor designed to simplify your cooking experience. It features a powerful 1200W motor for cooking and 1000W for mixing, an intuitive 8-inch touchscreen, and Wi-Fi connectivity for access to over 600 pre-installed recipes and monthly updates. This appliance offers a wide range of functions including mixing, chopping, kneading, steaming, roasting, pureeing, and more, making it an indispensable tool in any modern kitchen. Its integrated scale and various automatic programs ensure precise and convenient food preparation.

2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance to prevent injury or damage. Keep this manual for future reference.

- Always ensure the appliance is placed on a stable, flat, and heat-resistant surface.
- Do not immerse the main unit in water or other liquids. Clean with a damp cloth only.
- Keep hands and utensils away from moving parts during operation. Use the spatula provided.
- Ensure the lid is securely locked before starting any function.
- Unplug the appliance from the power outlet when not in use, before cleaning, or before changing accessories.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been dropped.
- This appliance is for household use only. Do not use outdoors or for commercial purposes.
- Children should be supervised to ensure they do not play with the appliance.
- Be cautious when handling sharp blades and hot surfaces.

3. PRODUCT OVERVIEW

Familiarize yourself with the components and accessories of your Monsieur Cuisine Smart.

3.1 Main Unit and Components



Image: Front view of the Silvercrest Monsieur Cuisine Smart food processor, showing the main unit with the mixing bowl inserted and the 8-inch touchscreen display.

- **Main Unit:** Houses the motor, heating element, and control panel.
- **8-inch Touchscreen Display:** For navigating menus, recipes, and settings.
- **Control Dial:** For adjusting speed, temperature, and time, and confirming selections.
- **Mixing Bowl:** Large removable stainless steel bowl with a cooking volume of 3 liters (4.5 liters total capacity).
- **Lid with Filling Opening:** Securely covers the mixing bowl, with an opening for adding ingredients during operation.
- **Measuring Cup:** Fits into the lid's filling opening.

3.2 Included Accessories



Image: The Silvercrest Monsieur Cuisine Smart food processor with the deep steaming attachment placed on top of the mixing bowl, ready for use.

- **Steaming Attachment (Deep and Flat):** For steaming vegetables, fish, and other foods. Includes a lid.
- **Cooking Insert:** For cooking smaller quantities or separating ingredients within the mixing bowl.
- **Knife Insert:** The main blade for chopping and mixing.
- **Mixer Attachment:** For whisking and emulsifying.
- **Spatula:** Heat-resistant spatula for stirring and scraping.
- All accessories are dishwasher-safe and BPA-free.

4. SETUP

Follow these steps for the initial setup of your appliance.

1. **Unpack:** Carefully remove all components and accessories from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, thoroughly clean all parts that will come into contact with food (mixing bowl, lid, accessories) with warm soapy water. Rinse and dry completely.
3. **Placement:** Place the main unit on a clean, dry, stable, and level surface, away from heat sources and direct sunlight. Ensure adequate ventilation around the appliance.
4. **Assemble Mixing Bowl:** Insert the knife insert into the mixing bowl. Place the mixing bowl into the main unit, ensuring it is securely seated.
5. **Connect Power:** Plug the power cord into a suitable grounded electrical outlet (230 Volts AC). The appliance will power on automatically.
6. **Initial Setup on Display:** Follow the on-screen instructions to select your language, connect to Wi-Fi, and set up your user account for recipe updates and additional features.



Image: A hand demonstrating how to easily remove the stainless steel mixing bowl from the main unit of the Silvercrest Monsieur Cuisine Smart.

5. OPERATING INSTRUCTIONS

This section details how to use the various functions of your Monsieur Cuisine Smart.

5.1 Basic Operation

- **Power On/Off:** The appliance powers on when plugged in. To turn off, unplug it.
- **Touchscreen Navigation:** Use the responsive 8-inch touchscreen to navigate through menus, select programs, and view recipes.
- **Control Dial:** Rotate the dial to adjust settings like speed, temperature, and time. Press the dial to confirm selections or start/pause operations.



Image: The 8-inch touchscreen display of the Silvercrest Monsieur Cuisine Smart showing active cooking parameters, including a timer and temperature setting.

5.2 Key Functions and Programs

- **Mixing (Left Rotation):** Ideal for gentle stirring of soups, risottos, stews, and delicate food preparation without chopping.
- **Chopping (Right Rotation):** Use for finely chopping ingredients.
- **Speed Adjustment:** Select from 10 speed levels. The additional turbo function provides pulse mixing for quick, powerful bursts.
- **Automatic Programs:** The appliance includes pre-set programs for:
 - Kneading
 - Steaming
 - Roasting
 - Smoothie Preparation
 - Pureeing
 - Cleaning
 - Egg Cooking
 - Fermentation
 - Slow Cooking
 - Sous-Vide
- **Integrated Scale:** Weigh ingredients directly in the mixing bowl up to 5 kg.



Image: Top-down view of the Silvercrest Monsieur Cuisine Smart, demonstrating the integrated scale function with a bowl of vegetables weighing 220g on the display.

- **99-Minute Timer:** Set precise cooking times for your recipes.
- **Guided Cooking:** Access over 600 pre-installed recipes with step-by-step instructions. Some recipes include video cooking guides. Recipes can be prepared in different portion sizes.
- **Wi-Fi Functionality:** Connect to Wi-Fi for monthly recipe updates, user account features, and voice control via Google Assistant (with active Wi-Fi).



Image: The Silvercrest Monsieur Cuisine Smart appliance shown alongside a tablet and smartphone, illustrating its Wi-Fi connectivity and integration with the recipe app.

- **Recipe Management:** Easily save your own notes within recipe steps, use the weekly planner, and add recipes directly to your shopping list.

5.3 Example Usage: Steaming

1. Ensure the mixing bowl is clean and filled with the appropriate amount of water (refer to recipe).
2. Place the cooking insert or steaming attachment onto the mixing bowl.
3. Arrange your ingredients (e.g., vegetables, fish) in the steaming attachment.



Image: A person carefully placing pieces of salmon onto the steaming tray of the Silvercrest Monsieur Cuisine Smart, preparing for a steamed meal.

4. Close the steaming attachment lid securely.
5. Select the steaming program or set the temperature (e.g., 120°C) and time manually.
6. Press the control dial to start.

5.4 Example Usage: Smoothie Preparation

1. Add your desired fruits, vegetables, and liquids to the mixing bowl.
2. Secure the lid with the measuring cup.
3. Select the "Smoothie Preparation" automatic program.



Image: A person adding ice cubes into the mixing bowl of the Silvercrest Monsieur Cuisine Smart, with the screen displaying a smoothie recipe, indicating preparation for a cold beverage.

4. Press the control dial to start. The appliance will blend the ingredients to a smooth consistency.

6. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will ensure the longevity and optimal performance of your appliance.

- **Unplug:** Always unplug the appliance from the power outlet before cleaning.
- **Main Unit:** Wipe the main unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Mixing Bowl and Accessories:** The mixing bowl, lid, and all accessories are dishwasher-safe. Alternatively, they can be washed by hand with warm soapy water. Ensure all parts are thoroughly dried before reassembly or storage.
- **Automatic Cleaning Program:** For quick cleaning of the mixing bowl, use the dedicated automatic cleaning program. Add water and a drop of dish soap to the bowl and run the program.
- **Storage:** Store the appliance and its accessories in a clean, dry place when not in use. The cable storage

compartment helps keep the cord tidy.

7. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; check circuit breaker; try a different outlet.
Motor not running or stops during operation.	Lid not properly closed; mixing bowl not correctly seated; overload protection activated.	Ensure lid is securely locked; re-seat the mixing bowl; reduce ingredients if overloaded and restart.
Display is unresponsive.	Temporary software glitch.	Unplug the appliance for a few minutes, then plug it back in.
Wi-Fi connection issues.	Incorrect password; out of range; router issues.	Verify Wi-Fi password; move appliance closer to router; restart router.
Ingredients not mixing/chopping effectively.	Incorrect blade/attachment; too much or too little liquid; ingredients too large.	Ensure correct attachment is used; adjust liquid content; cut ingredients into smaller pieces.

8. SPECIFICATIONS

Technical details of the Silvercrest® Monsieur Cuisine Smart SKMS 1200 A1.

Feature	Detail
Model Number	SKMS 1200 A1
Cooking Power	1050 W
Mixing Power	1000 W
Rotation Speed	Approx. 125 to 5500 rpm
Temperature Range	37 to 130 °C
Mixing Bowl Capacity (Cooking Volume)	3 Liters
Mixing Bowl Capacity (Total)	4.5 Liters
Integrated Scale Capacity	Up to 5 kg
Display	8-inch Touchscreen
Voltage	230 Volts (AC)
Material	Stainless Steel (bowl), BPA-free accessories

Feature	Detail
Dimensions (Product)	50P x 32l x 38H centimeters (approx.)
Weight	3 Kilograms
Dishwasher Safe Parts	All accessories

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or contact Silvercrest customer service. Keep your proof of purchase for warranty claims.

Online Resources: Visit the official Silvercrest website for FAQs, additional recipes, and software updates.



[Manuel d'utilisation SILVERCREST Monsieur Cuisine Smart SKMS 1200 A1](#)

Guide complet pour le robot culinaire SILVERCREST Monsieur Cuisine Smart SKMS 1200 A1. Découvrez ses fonctions, recettes, conseils d'utilisation et d'entretien pour une cuisine facile et connectée.

lang:fr score:17 filesize: 4.63 M page_count: 121 document date: 2022-10-12



[Lidl Angebote: Frühling, Ostern & Monsieur Cuisine Smart - KW 13/2025](#)

Entdecken Sie die neuesten Lidl Angebote der Woche (24.03.-29.03.2025). Sparen Sie bei Lebensmitteln, Osterartikeln, dem Monsieur Cuisine Smart, Gartenmöbeln, Haushaltswaren und mehr. Jetzt Angebote sichern!

lang:de score:16 filesize: 48.16 M page_count: 64 document date: 2025-03-17



[Lidl Wochenangebote: Mode, Haushalt, Werkzeug und mehr](#)

Entdecken Sie die neuesten Wochenangebote von Lidl mit Mode von esmara und LIVERGY, Haushaltswaren, PARKSIDE Werkzeugen, crelando Bastelbedarf und vielem mehr.

lang:de score:12 filesize: 82.19 M page_count: 31 document date: 2024-02-09



[\[pdf\]](#)

Fantastische Ostermomente Mar 4 2024 — Mehr Informationen zu unseren Aktionsartikeln oder unserem dauerhaften Ostersortiment findest du im wöchentlichen Handzettel auf lidl.de 03 04 LiDL DE 064 1100 usercontent one wp info24service |||

Kostenlos zum Mitnehmen ab Montag, 11.3. Fantastische Ostermomente Superlecker starten Auf ins k ... Zubehr splmaschineng eeignet SILVERCREST KITCHEN TOOLS Kchenmaschine mit Kochfunktion Typ „smart **SKMS 1200 A1** . ber 1.000 Guided Cooking-Rezepte1 mit Schritt-fr-Schritt-Anleitung mit regelm igen ko...

lang:de score:11 filesize: 42.5 M page_count: 41 document date: 2024-03-01

