

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Citizen](#) /

› [Citizen Promaster Sea Dive Automatic Watch NY0129-58L User Manual](#)

Citizen NY0129-58L

Citizen Promaster Sea Dive Automatic Watch NY0129-58L User Manual

Model: NY0129-58L | Brand: Citizen

INTRODUCTION

This manual provides essential instructions for the proper use, care, and maintenance of your Citizen Promaster Sea Dive Automatic Watch, model NY0129-58L. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.



Figure 1: Front view of the Citizen Promaster Sea Dive Automatic Watch.

SETUP

1. Initial Winding

Your Citizen Promaster Sea Dive Automatic Watch is powered by an automatic mechanical movement, which means it winds itself through the motion of your wrist. If the watch has stopped or is running low on power, it can be manually wound.

- To manually wind, unscrew the crown (located at the 3 o'clock position) counter-clockwise until it springs out.
- Turn the crown clockwise approximately 40 times. This will provide sufficient power to start the watch.
- Once started, normal daily wear will keep the watch wound. The power reserve is approximately 40 hours.

2. Setting Time and Date

- **Unscrew the crown** as described above.

- **Pull the crown out to the first click position** to set the day and date. Turn the crown to adjust. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.
- **Pull the crown out to the second click position** to set the time. Turn the crown to move the hands. The second hand will stop (hacking feature) allowing for precise time setting.
- Once the time and date are set, **push the crown back in and screw it down clockwise firmly** against the case to ensure water resistance.



Figure 2: Side view illustrating the screw-down crown mechanism.

3. Adjusting the Unidirectional Bezel

The watch features a unidirectional rotating bezel, designed for dive timing. It rotates only counter-clockwise to prevent accidental extension of dive time.

- Rotate the bezel counter-clockwise to align the triangle marker with the minute hand at the start of your dive.
- The minute hand will then indicate the elapsed time on the bezel.

4. Bracelet Adjustment

The stainless steel bracelet uses a pin and collar system for adjustment. This requires specialized tools and careful handling to avoid losing the tiny collars. It is recommended to have a professional watch repairer or jeweler adjust the bracelet for proper fit.

OPERATING YOUR WATCH

Your Promaster Sea Dive watch is built for reliability and functionality, especially in aquatic environments.

- **Automatic Movement:** The watch is powered by the natural motion of your arm. Consistent wear ensures it remains wound.
- **Luminous Display:** The hands and markers are treated with luminous material for enhanced visibility in low-light conditions, crucial for diving.
- **Water Resistance:** This watch is ISO compliant and water resistant up to 200 meters (660 feet), suitable for professional marine activity and serious surface water sports, but not high-impact water sports. Always ensure the crown is fully screwed down before exposing the watch to water.
- **Day/Date Display:** The watch displays both the day of the week and the date at the 3 o'clock position.





Figure 3: Key features of the watch dial and case.

MAINTENANCE

- **Cleaning:** Regularly wipe the watch case and bracelet with a soft, dry cloth. For stainless steel, a slightly damp cloth can be used, followed by drying. For dive watches, rinse with fresh water after exposure to saltwater to prevent corrosion.
- **Water Resistance Check:** It is recommended to have the water resistance checked annually by an authorized service center, especially if the watch is frequently used for diving.
- **Avoid Extreme Conditions:** Protect your watch from extreme temperatures, direct sunlight for prolonged periods, and strong magnetic fields, as these can affect the movement's accuracy.
- **Professional Service:** For any internal repairs or battery replacement (not applicable for automatic movement, but for other watch types), always consult an authorized Citizen service center.



Figure 4: Rear view of the watch, highlighting the durable case back.

TROUBLESHOOTING

- Watch Not Running:** If the watch has stopped, it likely needs to be wound. Manually wind it by turning the crown clockwise approximately 40 times after unscrewing it. Ensure the crown is screwed back down.
- Inaccurate Time:** Automatic watches can have slight variations in accuracy. If the watch is consistently gaining or losing significant time, it may require adjustment by an authorized service center.

- **Day/Date Not Changing:** Ensure the time is set correctly, especially past midnight. If the day/date mechanism is stuck, avoid forcing it and consult a professional.

SPECIFICATIONS

Feature	Detail
Model Number	NY0129-58L
Movement	Automatic (Miyota 8204 series)
Water Resistance	200M (ISO Compliant)
Case Material	Silver-Tone Stainless Steel
Crystal	Dual Spherical Mineral Crystal
Dial Color	Blue Gradient
Hands & Markers	Luminous
Functions	Day / Date, 3 Hand
Case Diameter	41.4 mm
Case Thickness	Approximately 13 mm
Power Reserve	Approximately 40 hours

WARRANTY INFORMATION

Your Citizen Promaster Sea Dive Automatic Watch comes with a **5 Year Limited Warranty**. Please refer to the official Citizen warranty documentation provided with your purchase for full terms and conditions. Keep your proof of purchase for warranty claims.

SUPPORT

For further assistance, technical support, or to locate an authorized service center, please visit the official Citizen website or contact their customer service department. Always ensure any service or repair is performed by authorized personnel to maintain warranty validity and watch integrity.

ADDITIONAL RESOURCES

While there are no seller-provided videos directly for this specific model, general information about automatic dive watches can be found from various sources. Always ensure information is from reputable sources when seeking advice not covered in this manual.

© 2023 Citizen Watch Company. All rights reserved.