

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Acepene](#) /

› [Acepene Graphics Drawing Tablet User Manual](#)

Acepene AP-901

Acepene Graphics Drawing Tablet User Manual

Model: AP-901

INTRODUCTION

The Acepen Graphics Drawing Tablet is a versatile digital art tool designed for drawing, design, teaching, and general computer work. This manual provides comprehensive instructions for setting up, operating, and maintaining your tablet to ensure optimal performance and longevity.

WHAT'S IN THE BOX

Upon unboxing your Acepen Graphics Drawing Tablet, please verify that all the following components are included:

- Acepen Graphics Drawing Tablet (9x6 inch active area)
- Battery-Free Stylus
- USB Cable
- Nib Clip
- Drawing Glove
- 2x OTG Adapters (Type-C & Micro)
- 8x Replacement Nibs
- Quick Start Guide



Figure 1: Included components of the Acepen Graphics Drawing Tablet package.

SETUP

- 1. Connect the Tablet:** Connect the Acepen Graphics Drawing Tablet to your computer (Windows PC or Mac) or Android mobile device using the provided USB cable. Use the appropriate OTG adapter for mobile devices if necessary.
- 2. Install Drivers:** For optimal performance and full functionality, it is recommended to install the latest drivers from the official Acepen website. This will enable features such as pressure sensitivity, tilt-response, and customizable hot keys.
- 3. Configure Settings:** After driver installation, open the Acepen driver software. Here you can customize pen pressure, assign functions to the 8 hot keys, and adjust the active area mapping to your screen.



The Acepen graphic tablet supports
Mac 10 or later,
Windows10/8/7,
and Android 6.0 or later.



Android



MacOS



Windows

Figure 2: The tablet supports Windows, macOS, and Android operating systems.

OPERATING THE TABLET

Using the Battery-Free Stylus

The Acepen tablet comes with a battery-free stylus, eliminating the need for charging or batteries. This ensures uninterrupted workflow and a natural drawing experience.

- **Pressure Sensitivity:** The stylus supports 8192 levels of pressure sensitivity, allowing for precise control over line thickness and opacity based on the pressure applied.
- **Tilt-Response:** With $\pm 60^\circ$ tilt-response, the stylus can simulate traditional brush strokes, providing a more natural and expressive drawing experience.
- **Accuracy:** The stylus offers virtually lag-free tracking, ensuring that your strokes appear on screen accurately and instantly.

Battery-Free Pen Brings Smooth and Precise Drawing



battery-
Free



5080LPI
pen resolution



266 RPS
report rate



8192 Levels
of Pressure
Sensitivity




Figure 3: Key features of the battery-free stylus for smooth and precise drawing.

Customizable Hot Keys

The tablet features 8 customizable shortcut keys. These keys can be programmed through the driver software to perform various functions, enhancing your workflow and reducing reliance on the keyboard and mouse.

8 Customizable Shortcut Keys



Figure 4: The 8 customizable shortcut keys for efficient operation.

Software Compatibility

The Acepen Graphics Drawing Tablet is compatible with a wide range of major creative software applications, making it suitable for various artistic and professional tasks.

Supported software includes, but is not limited to: Office, SketchBook, Photoshop, SAI, Painter, Illustrator, Clip Studio, GIMP, Medibang Paint, Artflow, Pen Up, and Bamboo Paper.

Broad Compatibility



Figure 5: Broad compatibility with popular design and drawing software.

Usage Scenarios

The compact and portable design of the Acepen tablet allows for flexible usage in various environments, whether for professional design work, online education, daily sketching, or outdoor creative sessions.

Multiple Usage for One Acepen



Figure 6: Versatile usage for different creative and professional needs.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the tablet surface and stylus. Avoid using harsh chemicals or abrasive materials.
- **Stylus Nibs:** The stylus nibs will wear down over time. Replace them when they become too short or sharp to maintain optimal drawing performance. Use the provided nib clip for easy replacement.
- **Storage:** Store the tablet and stylus in a dry, cool place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the USB cable excessively to prevent damage.

TROUBLESHOOTING

Tablet not responding:

- Ensure the USB cable is securely connected to both the tablet and your device.
- Try connecting to a different USB port.
- Restart your computer/device.
- Reinstall the tablet drivers from the Acepen website.

Stylus not working or no pressure sensitivity:

- Check if the stylus nib is properly inserted and not overly worn. Replace if necessary.
- Ensure the tablet drivers are correctly installed and updated.
- Verify that pressure sensitivity is enabled in your drawing software settings.

Hot keys not functioning:

- Make sure the tablet drivers are installed.
- Open the Acepen driver software and check the hot key assignments. Reconfigure if needed.
- Ensure the driver software is running in the background.

SPECIFICATIONS

Feature	Detail
Brand	Acepen
Model Number	AP-901
Product Dimensions	6 x 9 x 0.01 inches
Item Weight	1.54 pounds
Active Area	9x5 inch (implied from product title)
Connectivity Technology	USB
Pressure Sensitivity	8192 Levels
Tilt-Response	±60°
Operating System Compatibility	Windows, macOS, Android 6.0 or later
Special Feature	Shortcut Key (8 customizable hot keys)



Smaller Size but Bigger Working Area

Figure 7: Physical dimensions of the Acepen Graphics Drawing Tablet.


WARRANTY AND SUPPORT

Acepen offers a **ONE-year warranty** on the tablet. For any issues or support inquiries, please contact Acepen customer support. Lifetime customer support is provided to assist with any questions or problems you may encounter.

Refer to the Quick Start Guide included in your package for contact information or visit the official Acepen website for further assistance.

© 2023 Acepen. All rights reserved.

Related Documents - AP-901



[JM Stylus User Guide - Just Mobile](#)

User guide for the JM Stylus by Just Mobile, detailing its features, charging modes, tip replacement, Bluetooth pairing, and specifications for compatible iPads.

 <p>Aruba Instant AP Basic Operation Guide a Hewlett-Packard Enterprise company</p> <p>Aruba Instant AP 基本操作ガイド 日本エレクトロニクス販売株式会社 Aruba事業部技術本部</p> <p>Table of Contents 1. Getting Started</p>	<p>Aruba Instant AP</p> <p>Aruba Instant AP SSID</p>
 <p>HPE Aruba Networking Instant Operating System 8.12.0.3 Release Notes Hewlett Packard Enterprise</p>	<p>HPE Aruba Networking Instant Operating System 8.12.0.3 Release Notes</p> <p>This document provides release notes for HPE Aruba Networking Instant Operating System version 8.12.0.3, detailing new features, supported platforms, resolved issues, and upgrade procedures.</p>
 <p>Instagrid ONE Manual for ONE</p>	<p>Instagrid ONE User Manual</p> <p>User manual for the Instagrid ONE portable power station, detailing its features, operation, safety instructions, and technical specifications. Learn how to use Instagrid ONE for reliable mobile power.</p>
 <p>HPE Aruba Networking Instant Operating System 8.12.0.4 Release Notes Hewlett Packard Enterprise</p>	<p>HPE Aruba Networking Instant OS 8.12.0.4 Release Notes</p> <p>This document provides release notes for HPE Aruba Networking Instant Operating System version 8.12.0.4, detailing new features, enhancements, resolved issues, and known issues for various Aruba Access Point models.</p>
 <p>Aruba Instant 8.10.0.0 Release Notes Aruba Instant 8.10.0.0 Release Notes Hewlett Packard Enterprise</p>	<p>Aruba Instant 8.10.0.0 Release Notes</p> <p>Release notes for Aruba Instant 8.10.0.0, detailing new features, enhancements, resolved issues, known issues, and upgrade procedures for Aruba access points.</p>