

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SZELAM](#) /

› [SZELAM SZ-8853A-GD Digital Alarm Clock User Manual](#)

SZELAM SZ-8853A-GD

SZELAM SZ-8853A-GD Digital Alarm Clock User Manual

Model: SZ-8853A-GD

INTRODUCTION

The SZELAM SZ-8853A-GD Digital Alarm Clock is designed to provide clear time display, customizable lighting, and convenient charging capabilities. This manual provides instructions for setup, operation, and maintenance to ensure optimal performance of your device.

SZELAM

RGB Digital Alarm Clock with Night Light



10 Modes Night light



11 Modes Time Display



USB A+C Charging Port



Mirror Surface



Auto Dimming



5 Levels Volume



Alarm Clock



12/24H Mode



Snooze Mode



Memory Battery



Figure 1: SZELAM SZ-8853A-GD Digital Alarm Clock.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x SZELAM Digital Alarm Clock (Model SZ-8853A-GD)
- 1 x Power Adapter
- 1 x USB Charging Cable (Type-C)
- 1 x Product Manual



1 X Digital Alarm Clock



1 X Packing box



1 X Power Adapter



1 X USB Type-C Cable



1 X User Manual

Figure 2: Contents of the SZELAM Alarm Clock package.

PRODUCT OVERVIEW

The SZELAM Digital Alarm Clock features a 7.4-inch mirror display with large, easy-to-read digits. It includes multiple buttons on the top for various settings and two charging ports on the side.

Key Features:

- **11-Color RGB Digital Display:** Choose from 4 dynamic RGB modes and 7 fixed color modes for the time display.
- **10-Color Modes Night Light:** Integrated LED light with 3 dynamic RGB colors and 7 fixed color modes, adjustable to 5 brightness levels.

- **USB-C Charging Port:** Equipped with one USB Type-C and one USB-A output port for simultaneous charging of two electronic devices.
- **7.4-Inch Mirror Display:** High-definition display with large digital fonts, also functions as a makeup mirror.
- **Automatic/Manual Dimming:** 6 levels of brightness adjustment. Automatic light sensing mode adjusts display brightness based on ambient light.
- **5 Levels Volume Adjustable:** Alarm volume options from 55-95dB, suitable for various sleep depths.
- **Snooze + 12/24h Mode:** Snooze function (5-60 minutes) and selectable 12-hour or 24-hour time display.



Figure 3: Front view of the alarm clock.

SETUP

1. **Power Connection:** Connect the provided USB Type-C charging cable to the "INPUT" port on the side of the

alarm clock and plug the power adapter into a standard wall outlet. The display will illuminate.

2. **Initial Time Setting:** Upon first power-on, the clock may display a default time. Refer to the "Operating Instructions" section for detailed steps on setting the correct time.
3. **Memory Battery:** The clock includes a memory battery to retain time settings during power outages. Ensure the protective strip is removed from the battery compartment (located on the bottom) if applicable.

OPERATING INSTRUCTIONS

1. Setting Time and 12/24h Mode

1. Press and hold the "SET" button (usually located on the top) for 2 seconds to enter time setting mode. The hour digits will flash.
2. Use the "+" or "-" buttons to adjust the hour.
3. Press "SET" again to confirm the hour and move to minute setting. The minute digits will flash.
4. Use the "+" or "-" buttons to adjust the minutes.
5. Press "SET" a third time to confirm minutes and enter 12/24h mode selection.
6. Use the "+" or "-" buttons to switch between 12-hour and 24-hour display.
7. Press "SET" to exit time setting.



11 Color Modes Time Display

4 Dynamic Modes + 7 Fixed Modes



Figure 4: Time display with various color modes.

2. Adjusting RGB Digital Display Colors

In normal time display mode, press the "Light" button (often combined with snooze) to cycle through the 11 available color modes for the time digits. These include 4 dynamic RGB modes and 7 fixed color modes.

Your browser does not support the video tag.

Video 1: Demonstrates how to change the RGB digital display colors on the SZELAM EN8853A Digital Alarm Clock.

3. Setting RGB Night Light Modes

The clock features a bottom atmosphere light. Press the "Light" button (separate from the display color button, or a long press on the same button depending on model) to cycle through 10 night light modes (3 dynamic RGB, 7 fixed colors). The brightness of the night light can also be adjusted through 5 levels.



Figure 5: Various 10-color RGB night light modes.

4. Brightness Adjustment (Auto/Manual)

The display brightness has 6 adjustable levels. In manual mode, repeatedly press the "Brightness" button (often combined with snooze) to cycle through the levels. For automatic adjustment, activate the auto-dimming feature (refer to specific button functions in the included manual) which adjusts brightness based on ambient light.



6 Levels Brightness Automatic/Manual Adjustment




Figure 6: Six levels of brightness adjustment for the display.

5. Alarm Setting, Snooze, and Volume

1. **Set Alarm:** Press and hold the "AL" (Alarm) button for 2 seconds. The hour digits will flash. Use "+" or "-" to set the alarm hour. Press "AL" again to set minutes, then use "+" or "-" to adjust. Press "AL" a third time to set snooze duration (5-60 minutes). Press "AL" to save and exit.
2. **Activate/Deactivate Alarm:** Briefly press the "AL" button to turn the alarm on or off. An alarm icon will appear/disappear on the display.

3. **Snooze Function:** When the alarm sounds, press the large "SNOOZE" button on top to activate snooze. The alarm will sound again after the set snooze duration.
4. **Adjust Alarm Volume:** In normal time display mode, press the "VOL" button to cycle through 5 volume levels (55-95dB).

Your browser does not support the video tag.

Video 2: Instructions for setting the alarm on the SZELAM EN8853A Digital Alarm Clock.



Figure 7: Snooze button on top of the alarm clock.

6. USB Charging Ports

The alarm clock is equipped with one USB Type-C output port and one USB-A output port. These ports can be used to charge compatible electronic devices simultaneously.

USB A + USB C Charging Port

It can charge your iPhone and Android devices at the same time.



Figure 8: USB A and USB C charging ports on the side of the clock.

MAINTENANCE

- Clean the mirror display and body with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- Keep the device away from water and high humidity.
- Do not disassemble the device. Refer to qualified personnel for repairs.

TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Display is blank.	Ensure the power adapter is securely connected to the clock and a working power outlet. Check if the brightness is set to OFF.
Alarm does not sound.	Verify the alarm is activated (alarm icon visible). Check the alarm volume setting. Ensure the alarm time is correctly set.
Time is incorrect after power outage.	Ensure the memory battery's protective strip is removed. If the battery is depleted, replace it or reset the time manually.
USB ports not charging devices.	Ensure the clock is powered on. Check the charging cable and device compatibility.

SPECIFICATIONS

Feature	Detail
Brand	SZELAM
Model Number	SZ-8853A-GD
Display Type	Digital LED (Mirror Surface)
Display Size	7.4 inches
Time Display Modes	12h / 24h
Digital Display Colors	11 (4 Dynamic RGB + 7 Fixed)
Night Light Modes	10 (3 Dynamic RGB + 7 Fixed)
Brightness Levels	6 (Automatic/Manual)
Alarm Volume Levels	5 (55-95dB)
Snooze Duration	Adjustable (5-60 minutes)
Charging Ports	1 x USB Type-C Output, 1 x USB-A Output
Power Source	Corded Electric
Product Dimensions	6.6"W x 3.8"H
Material	Acrylic, Acrylonitrile Butadiene Styrene

WARRANTY AND SUPPORT

The SZELAM SZ-8853A-GD Digital Alarm Clock comes with a **30-day unconditional money-back/exchange policy** and a **1-year warranty** from the manufacturer.

For any product inquiries, issues, or support needs, please contact SZELAM customer service via email. A solution will be provided within 24 hours.