

P Panoraxy A20A

P Panoraxy AI 2K 3MP WiFi Security Indoor Camera

Model: A20A - User Instruction Manual

- Introduction
- Product Overview
- Setup
- Operating Instructions
- Maintenance
- Troubleshooting
- Specifications
- Warranty & Support

1. INTRODUCTION

Thank you for choosing the P Panoraxy AI 2K 3MP WiFi Security Indoor Camera. This manual provides essential information for the proper installation, operation, and maintenance of your new security camera. Please read this manual thoroughly before using the product and retain it for future reference.

2. PRODUCT OVERVIEW

The P Panoraxy AI 2K 3MP WiFi Security Indoor Camera is designed to provide comprehensive indoor surveillance with advanced features. It offers 2K (3MP) resolution for clear video, 24/7 human and sound detection, pan-tilt-zoom (PTZ) functionality, two-way audio communication, and color night vision. The camera is compatible with Amazon Alexa and Google Home for convenient voice control.

2.1 Package Contents

The standard package typically includes:

- P Panoraxy AI 2K 3MP WiFi Security Indoor Camera (Model A20A)
- User Manual
- Mounting accessories (if applicable, not specified in detail)

2.2 Camera Features

Easy and Quick Installation

Simply plug the camera into a power socket and ready to play!



Easy Installation: The camera plugs directly into a standard wall outlet for power, simplifying setup.

Wide Viewing Angle & 2K 3MP



Wide Viewing Angle & 2K 3MP: Enjoy a broad view of your room with high-definition 2K (3MP) video quality.


Monitoring and real-time interaction



Two-Way Talk: Communicate directly with individuals in the camera's view using the built-in microphone and speaker.



Smart Home Integration: Control and view your camera feed using voice commands with Amazon Alexa and Google Home.



Advanced Motion Detection: Receive real-time alerts on your smartphone when motion is detected.



Multiple Night Vision Modes: Choose between Infrared, Color, and Siren Night Vision for enhanced visibility in low-light conditions.

2.3 Product Video

Your browser does not support the video tag.

This video demonstrates the features and functionality of the P Panoraxy Wireless Plug-in 3MP WiFi Camera, including its pan-tilt capabilities and motion detection.

3. SETUP INSTRUCTIONS

Follow these steps to set up your P Panoraxy AI 2K 3MP WiFi Security Indoor Camera:

1. **Download the App:** Search for the official P Panoraxy app (or the app specified in the packaging) on your smartphone's app store (iOS or Android) and install it.
2. **Create an Account:** Open the app and follow the on-screen instructions to create a new user account or log in if you already have one.
3. **Power On the Camera:** Plug the camera directly into a standard wall outlet. The camera will power on and initiate its startup sequence. Wait for the indicator light to flash, indicating it's ready for pairing.
4. **Add Device:** In the app, tap the "Add Device" or "+" icon. Select your camera model from the list of available devices.
5. **Connect to Wi-Fi:** Follow the app's instructions to connect the camera to your 2.4GHz Wi-Fi network. Ensure your smartphone is also connected to the same 2.4GHz Wi-Fi network during this process. *Note: This camera supports 2.4GHz Wi-Fi only.*
6. **Pairing:** The app will guide you through the pairing process, which may involve scanning a QR code displayed on your phone with the camera, or listening for an audible prompt from the camera.
7. **Placement:** Position the camera in your desired indoor location. Ensure it has a clear line of sight to the area you wish to monitor and is within range of your Wi-Fi signal.
8. **Finalize Setup:** Once connected, you can name your camera and configure initial settings within the app.

4. OPERATING INSTRUCTIONS

Once your camera is set up, you can utilize its features through the mobile app and smart home integrations:

- **Live View:** Open the app and select your camera to view the live video feed.
- **Pan/Tilt/Zoom (PTZ):** Use the directional controls within the app to remotely adjust the camera's horizontal (pan) and vertical (tilt) viewing angles. Digital zoom is also available.
- **Two-Way Talk:** While in live view, tap the microphone icon in the app to speak through the camera's speaker. Tap the speaker icon to listen to audio from the camera's environment.
- **Motion & Sound Detection:** Configure detection sensitivity and alert preferences in the app settings. You will receive push notifications on your smartphone when human motion or sound is detected.
- **Night Vision:** The camera automatically switches to night vision in low-light conditions. You can typically select between Infrared, Color, or Siren Night Vision modes in the app settings for optimal viewing.
- **Smart Home Integration (Alexa & Google Home):**
 - Link your P Panoraxy account with your Amazon Alexa or Google Home app.
 - Use voice commands such as "Alexa, show me the [Camera Name]" or "Hey Google, show me the [Camera Name]" to view the live feed on compatible smart displays.
- **Video Recording & Storage:** The camera supports local storage via a microSD card (not included) and cloud storage (subscription may be required). Manage recording settings and review footage through the app.

5. MAINTENANCE

To ensure optimal performance and longevity of your camera:

- **Cleaning:** Gently wipe the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Firmware Updates:** Regularly check the app for available firmware updates. Install updates to ensure your camera has the latest features and security enhancements.
- **Placement:** Ensure the camera is placed in a stable, dry indoor environment, away from direct sunlight, extreme

temperatures, and sources of strong electromagnetic interference.

6. TROUBLESHOOTING

If you encounter issues with your camera, refer to the following common solutions:

- **Camera Offline:**
 - Check if the camera is properly plugged into a working power outlet.
 - Verify your Wi-Fi network is active and functioning correctly.
 - Ensure the camera is within range of your Wi-Fi router.
 - Restart the camera by unplugging it and plugging it back in.
- **Unable to Connect to Wi-Fi:**
 - Confirm you are connecting to a 2.4GHz Wi-Fi network. 5GHz networks are not supported.
 - Double-check your Wi-Fi password.
 - Move the camera closer to your Wi-Fi router during setup.
 - Reset the camera (refer to app or product for specific reset instructions) and try pairing again.
- **No Video Feed:**
 - Ensure the camera is online in the app.
 - Check your internet connection speed.
 - Restart the app or your smartphone.
- **Motion Detection Not Working:**
 - Verify motion detection is enabled in the app settings.
 - Adjust the sensitivity level.
 - Ensure there are no obstructions blocking the camera's view.

7. SPECIFICATIONS

Feature	Detail
Brand	P Panoraxy
Model Number	A20A
Video Capture Resolution	1080p, 2K (3MP)
Connectivity Technology	Wireless (Wi-Fi)
Connectivity Protocol	Wi-Fi (2.4GHz)
Power Source	Corded Electric
Special Features	Motion Sensor, Night Vision, PTZ Technology (Pan-Tilt-Zoom)
Night Vision Range	33 Feet
Low Light Technology	Color Night
Controller Type	Amazon Alexa, Google Assistant

Feature	Detail
Compatible Devices	Smartphone
Indoor/Outdoor Usage	Indoor
Product Dimensions	4.5 x 2.7 x 4.3 inches
Item Weight	10.5 ounces
Batteries Required?	No

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official P Panoraxy website. If you require assistance, please contact P Panoraxy customer service directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C7NFSXJG>

More documents and user manuals: <https://manuals.plus/>