

pTron Zenbuds

pTron Zenbuds Ultima ANC Earbuds User Manual

Model: Zenbuds

PRODUCT OVERVIEW

The pTron Zenbuds Ultima ANC Earbuds are advanced wireless headphones designed for an immersive audio experience. Featuring 35dB Hybrid Active Noise Cancellation (ANC) and Transparency Mode, they allow you to control your sound environment. Equipped with 4 QuadPro Microphones and TruTalk Environmental Noise Cancellation (ENC), these earbuds ensure crystal-clear calls. Enjoy up to 50 hours of total playtime with the charging case, 4D Panoramic Audio, and ultra-low 40ms latency for gaming. The earbuds are also IPX5 water-resistant, making them suitable for various activities.



This image displays the pTron Zenbuds Ultima ANC Earbuds in Jade Black, alongside their sleek charging case. The earbuds feature a stem design with an in-ear fit, showcasing their compact and modern aesthetic.

PACKAGE CONTENTS

Please check the box for the following items:

- 1 x Pair of pTron Zenbuds Ultima ANC Earbuds
- 1 x Charging Case
- 1 x USB Type-C Charging Cable
- 1 x Set of Extra Ear Tips (S/M/L sizes)
- 1 x User Manual
- 1 x Warranty Card

SETUP GUIDE

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case, ensuring they are correctly seated. Connect the provided USB Type-C cable to the charging port on the case and the other end to a 5V-1A power adapter (not included). The indicator lights on the case will show the charging status. A full charge typically takes approximately 1.5 hours for the earbuds and 2 hours for the case.

2. Pairing with Your Device

The pTron Zenbuds Ultima feature 1-step pairing for convenience.

1. Ensure the charging case has sufficient power.
2. Open the charging case lid. The earbuds will automatically power on and enter pairing mode, indicated by a flashing LED light on the earbuds.
3. On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings.
4. Search for "pTron Zenbuds Ultima" in the list of available devices.
5. Select it to connect. Once connected, you will hear a confirmation tone, and the earbud LED lights will turn off.
6. For subsequent uses, the earbuds will automatically connect to the last paired device when the case lid is opened, provided Bluetooth is enabled on your device.



This image shows the pTron Zenbuds Ultima earbuds removed from their charging case, ready for use or pairing. The open case is visible in the background, highlighting the compact design.

OPERATING INSTRUCTIONS

Touch Controls

The pTron Zenbuds Ultima feature intuitive touch controls on each earbud. The following table outlines the common functions:

Action	Function
Single Tap (L/R)	Play/Pause Music, Answer/End Call
Double Tap (L)	Previous Track

Action	Function
Double Tap (R)	Next Track
Triple Tap (L/R)	Activate Voice Assistant (Google Assistant/Siri)
Long Press (2s) (L/R)	Switch between ANC / Transparency / Normal Mode
Long Press (2s) during call	Reject Call

Active Noise Cancellation (ANC) and Transparency Mode

The Zenbuds Ultima feature 35dB Hybrid ANC to significantly reduce ambient noise, allowing for an immersive listening experience. Transparency Mode allows you to hear your surroundings without removing the earbuds, which is useful for awareness in busy environments. To switch between ANC, Transparency, and Normal modes, long-press either earbud's touch sensor for 2 seconds.



This image emphasizes the 35dB QuietSound ANC feature of the pTron Zenbuds Ultima, showing the earbuds with sound wave graphics indicating noise cancellation.

Making and Receiving Calls

Equipped with 4 QuadPro Microphones and TruTalk Environmental Noise Cancellation (ENC) technology, the Zenbuds Ultima ensure your voice is transmitted clearly during calls, even in noisy environments. Use the touch controls to answer, end, or reject calls.



This image depicts a person using the pTron Zenbuds Ultima earbuds, highlighting the QuadPro Mics with TruTalk ENC for clear communication in various settings.

Audio and Gaming Experience

The 13mm dynamic drivers deliver immersive stereo sound with deep bass and 4D Panoramic Audio. For gamers, the 40ms low-latency mode (AptSense) ensures synchronized audio and video, providing a seamless mobile entertainment experience.



This image focuses on one pTron Zenbuds Ultima earbud, emphasizing its 4D Panaromic Audio capabilities and Bluetooth 5.3 connectivity for an enhanced listening experience.

MAINTENANCE AND CARE

Cleaning

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene. Use a soft, dry, lint-free cloth to wipe the surfaces. For the ear tips, remove them and clean with a mild soap solution if necessary, then rinse thoroughly and dry completely before reattaching. Do not use harsh chemicals or abrasive materials.

Water Resistance (IPX5)

The pTron Zenbuds Ultima are rated IPX5 water-resistant, meaning they can withstand splashes of water and sweat. This makes them suitable for workouts and light rain. However, they are not designed for submersion in water or for use during swimming. Ensure the earbuds are dry before placing them back into the charging



This image visually represents the IPX5 water resistance of the pTron Zenbuds Ultima, showing the earbuds with water droplets, indicating their ability to withstand sweat and splashes.

Battery Care

To prolong battery life, avoid exposing the earbuds and case to extreme temperatures. Store them in a cool, dry place when not in use. It is recommended to fully charge the device at least once every three months if not used regularly.

TROUBLESHOOTING

If you encounter issues with your pTron Zenbuds Ultima, please refer to the following common solutions:

- **Earbuds not pairing:** Ensure both earbuds are charged. Place them back in the case, close the lid, wait a few seconds, then open the lid to re-enter pairing mode. On your device, forget the previous

Bluetooth connection and try pairing again.

- **Only one earbud working:** Check if both earbuds are charged. Try placing both earbuds back into the charging case, close the lid, and then take them out simultaneously. This often re-syncs them.
- **No sound:** Check the volume level on your device and the earbuds. Ensure the earbuds are properly connected to your device. Try playing audio from a different application or source.
- **Charging issues:** Ensure the charging cable is securely connected to both the case and the power adapter. Use a DC5V-1A charger. Clean the charging contacts on the earbuds and inside the case with a dry cotton swab.
- **Poor call quality:** Ensure the microphones are not obstructed. Try moving to an area with less background noise.
- **Intermittent connection:** Ensure your device is within the 10-meter Bluetooth range. Avoid obstacles between the earbuds and your device.

TECHNICAL SPECIFICATIONS

Feature	Specification
Model Name	Zenbuds Ultima
Bluetooth Version	5.3
Bluetooth Range	Up to 10 meters
Noise Control	35dB Hybrid Active Noise Cancellation (ANC)
Microphones	4 QuadPro Mics with TruTalk ENC
Driver Size	13mm Dynamic Driver
Low Latency	40ms (AptSense)
Total Playtime	Up to 50 hours (with charging case)
Water Resistance	IPX5 (Sweat & Water Resistant)
Charging Port	USB Type-C
Control Type	Touch Control, Voice Control
Compatible Devices	All Bluetooth Devices (iOS, Android, Laptops, PCs, Smart TVs)
Material	ABS, PC, Silicone
Item Weight	40 Grams
Product Dimensions	7.8 x 6.4 x 2.6 cm

WARRANTY AND CUSTOMER SUPPORT

The pTron Zenbuds Ultima ANC Earbuds come with a **1-Year Manufacturer Warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your purchase receipt for warranty claims.

For any product-related queries, technical support, or warranty claims, please contact pTron customer support:




Email: Support@ptron.in


Phone: 040-67138888

Please note: Using incompatible USB cables or high voltage chargers can damage the product and void the product warranty. We strongly recommend using DC5V-1A chargers and the USB cable included in the package.

© 2023 pTron. All rights reserved.


Related Documents - Zenbuds

	<p>pTron Zenbuds Nova User Guide and App Instructions</p> <p>Comprehensive user guide for pTron Zenbuds Nova wireless earbuds, covering setup, charging, controls, troubleshooting, and the 'Original Sound' companion app.</p>
	<p>pTron Zenbuds Evo X2 Pro (2024-Model) User Guide - Features, Controls, and Troubleshooting</p> <p>Comprehensive user guide for the pTron Zenbuds Evo X2 Pro (2024-Model) wireless earbuds. Learn about charging, pairing, controls, troubleshooting, safety precautions, and warranty information.</p>
	<p>pTron Zenbuds Evo X2 Pro (2025-Model) User Guide - Wireless Earbuds</p> <p>Comprehensive user guide for the pTron Zenbuds Evo X2 Pro (2025-Model) wireless earbuds, covering charging, pairing, controls, troubleshooting, safety, and warranty information.</p>



[pTron Zenbuds Evo X2 User Guide: Features, Pairing, and Troubleshooting](#)

Comprehensive user guide for the pTron Zenbuds Evo X2 wireless earbuds. Learn about charging, pairing, Bluetooth connectivity, mode control, call/music functions, volume adjustment, voice assistant, mono usage, troubleshooting, safety precautions, and warranty information.



[pTron Playbuds 1 Pro TWS Earbuds User Guide](#)

Official user guide for pTron Playbuds 1 Pro TWS Earbuds. Learn about charging, pairing, controls, troubleshooting, and warranty information.



[pTron Bassbuds Nyx TWS Earbuds - User Manual and Guide](#)

Comprehensive user manual for pTron Bassbuds Nyx True Wireless Stereo (TWS) earbuds. Learn about pairing, controls, charging, troubleshooting, and safety precautions.