

[Manuals.plus](#) /

> [ARSSLY](#) /

> ARSSLY LCD Display Replacement Instruction Manual for Lenovo Tab M10 Plus (TB-X606)

ARSSLY TB-X606

ARSSLY LCD Display Replacement Instruction Manual

For Lenovo Tab M10 Plus (Models TB-X606, TB-X606F)

1. PRODUCT OVERVIEW

This manual provides detailed instructions for replacing the LCD display and digitizer assembly on your Lenovo Tab M10 Plus tablet. The replacement unit includes the LCD screen and touch digitizer, designed to restore full display functionality to your device.

2. COMPATIBILITY

This LCD screen replacement is compatible exclusively with the following models:

- Lenovo Tab M10 Plus (10.3 inch)
- Model Numbers: TB-X606, TB-X606F

Please verify your device's model number before proceeding with the installation to ensure compatibility.

3. PACKAGE CONTENTS

The package includes the following items:

- 1 x LCD Screen Replacement for Lenovo Tab M10 Plus (TB-X606/TB-X606F)
- 1 x Repair Kit (includes various screwdrivers, spudger, tweezers, suction cup, picks, and adhesive tape)
- 1 x Tempered Glass Screen Protector

SCREEN REPLACEMENT FOR LENOVO REPAIR KIT



Image: The ARSSLY LCD screen replacement unit shown alongside the comprehensive repair kit, including various tools and a tempered glass screen protector.

4. INSTALLATION GUIDE

Warning: Screen replacement is a delicate procedure. Incorrect installation can damage your device. We highly recommend watching installation videos on platforms like YouTube or seeking professional assistance if you are not confident in your technical skills.

4.1. Pre-Installation Steps

1. **Power Off Device:** Ensure your Lenovo Tab M10 Plus is completely powered off before starting.
2. **Discharge Static Electricity:** Wear an anti-static wrist strap or frequently touch a grounded metal object to prevent static discharge, which can damage electronic components.
3. **Test the New Screen:** Before fully installing, connect the new LCD display's flex cables to the motherboard and power on the device to test display and touch functionality. Do not remove protective films or adhesive until the screen is confirmed working.

4.2. Step-by-Step Installation

The following steps outline the general process. Specific details may vary, so refer to a video guide for your exact model.

1. **Remove Back Cover:** Carefully use a spudger or plastic opening tool to pry open the back cover of the tablet.
2. **Disconnect Battery:** Locate and disconnect the battery flex cable from the motherboard to prevent accidental short circuits.
3. **Disconnect Old Screen:** Disconnect the flex cables connecting the old display assembly to the motherboard.
4. **Heat and Remove Old Screen:** Use a heat gun or hairdryer to gently heat the edges of the old screen to soften the adhesive. Carefully pry off the old screen using suction cups and plastic opening tools.
5. **Clean Frame:** Thoroughly clean any remaining adhesive residue from the tablet's frame.
6. **Apply New Adhesive:** Apply new adhesive tape (provided in the repair kit) around the frame where the new screen will sit.
7. **Connect New Screen:** Carefully connect the flex cables of the new LCD display to the corresponding connectors on the motherboard.
8. **Install New Screen:** Align the new screen with the tablet frame and gently press it into place, ensuring a secure fit.
9. **Reconnect Battery:** Reconnect the battery flex cable.
10. **Reassemble Device:** Reattach the back cover and secure it.



Image: Front and rear views of the replacement LCD display, highlighting the flex cable connectors on the back. The model number TV103WUM-LLO/LL1 ZY 210628D is visible on the back.




Image: A detailed view of the top portion of the screen, showing the flex cable connection point and the cutout for the front-facing camera. The serial number M4277BHSTC1YA17AMB4048 is visible.



Image: A close-up of the bottom flex cable connector on the reverse side of the LCD display. The serial number 8SSD68C58964AJBJ18G01TY is visible.

5. POST-INSTALLATION CHECK

After installation, perform the following checks to ensure proper functionality:

- **Power On:** Turn on your tablet.
- **Display Test:** Check for any dead pixels, discoloration, or lines on the screen.
- **Touch Functionality:** Test the touch response across the entire screen, including multi-touch gestures.
- **Brightness Adjustment:** Verify that screen brightness can be adjusted.
- **Camera Functionality:** Ensure the front camera, if applicable, is not obstructed and functions correctly.




Image: The installed LCD screen displaying a clear and vibrant image, demonstrating proper functionality after replacement.

6. MAINTENANCE

To ensure the longevity and optimal performance of your new screen:

- **Cleaning:** Use a soft, lint-free cloth and a screen-specific cleaner (or distilled water) to gently wipe the screen. Avoid harsh chemicals.
- **Protection:** Apply the included tempered glass screen protector to guard against scratches and minor impacts.
- **Handling:** Avoid dropping the device or applying excessive pressure to the screen.

7. TROUBLESHOOTING

If you encounter issues after installation, consider the following:

- **Screen Not Turning On:** Ensure all flex cables are securely connected. Recheck the battery connection.
- **Touch Not Responding:** Verify the digitizer flex cable is properly seated. Restart the device.
- **Lines or Discoloration:** Recheck flex cable connections. A faulty screen unit may be present; contact

support.

- **Ghost Touching:** Ensure the screen is properly seated and no debris is causing pressure. Recheck digitizer cable.

8. SPECIFICATIONS

Feature	Specification
Screen Size	10.3 Inches
Max Screen Resolution	1920x1080
Compatible Models	Lenovo Tab M10 Plus (TB-X606, TB-X606F)
Item Model Number	TB-X606

9. WARRANTY AND SUPPORT

We provide a 3-month product warranty service for this LCD display replacement. This warranty covers malfunctions not caused by user error or accidental damage.

If you encounter any quality problems during the warranty period, please contact us immediately. We are committed to providing free repair or replacement services for eligible issues.

For support, please refer to the contact information provided with your purchase or on the product packaging.