

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Mondaine](#) /
- › [Mondaine Evo2 MSE.30210.LCV Women's Watch Instruction Manual](#)

Mondaine MSE.30210.LCV

Mondaine Evo2 MSE.30210.LCV Women's Watch Instruction Manual

Model: MSE.30210.LCV

INTRODUCTION

This manual provides essential instructions for the setup, operation, maintenance, and care of your Mondaine Evo2 MSE.30210.LCV women's watch. Please read this guide thoroughly to ensure proper use and longevity of your timepiece.



Front view of the Mondaine Evo2 MSE.30210.LCV watch.

SETUP

1. Setting the Time

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) to the outermost position. You may feel a slight click.
2. **Adjust the time:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its original position. This will start the watch movement.



Side view of the watch, highlighting the crown for time adjustment.

2. Adjusting the Strap

The watch features a red vegan grape leather strap with a buckle clasp. To adjust the fit:

1. **Open the buckle:** Unfasten the buckle.
2. **Select a hole:** Insert the pin of the buckle into the desired hole on the strap to achieve a comfortable and secure fit on your wrist.
3. **Secure the strap:** Thread the end of the strap through the keepers to hold it in place.

OPERATING THE WATCH

Reading the Time

Your Mondaine Evo2 watch displays time using a classic analog dial with hour, minute, and a distinctive red second hand. The clear dial design ensures easy readability.

Water Resistance

This watch is water resistant up to 30 meters (3 ATM). This rating means the watch is suitable for everyday use and can withstand splashes or brief immersion in water, such as washing hands or rain. It is **not** suitable for swimming, showering, diving, or any water sports where it might be subjected to significant water pressure.

- Always ensure the crown is fully pushed in before any contact with water.
- Avoid operating the crown while the watch is wet or submerged.



Back view of the watch, indicating water resistance and Swiss Made origin.

MAINTENANCE AND CARE

Cleaning Your Watch

- **Case and Crystal:** Wipe the watch case and sapphire crystal with a soft, dry, lint-free cloth. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying.
- **Strap:** The vegan grape leather strap should be cleaned with a soft, damp cloth and allowed to air dry completely. Avoid harsh chemicals or excessive moisture, which can damage the material.

Battery Replacement

Your Swiss Quartz watch is powered by a battery. When the battery runs low, the second hand may start to jump every few seconds (End-of-Life indicator). Battery replacement should be performed by a qualified watchmaker or authorized service center to ensure the watch's water resistance and proper functioning are maintained.

General Care Tips

- Avoid exposing your watch to extreme temperatures (hot or cold) or sudden temperature changes.
- Keep the watch away from strong magnetic fields, as these can affect the accuracy of the quartz movement.
- Protect your watch from impacts and drops. While the sapphire crystal is scratch-resistant, it is not entirely shatterproof.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch is not running.	Battery is depleted.	Have the battery replaced by an authorized service center.
Watch hands are not moving.	Crown is pulled out.	Push the crown fully back into its normal operating position.
Time is inaccurate.	Watch exposed to strong magnetic fields.	Consult an authorized service center for demagnetization.
Condensation under crystal.	Water ingress due to open crown or seal damage.	Immediately take the watch to an authorized service center to prevent further damage.

SPECIFICATIONS

Brand	Mondaine
Model Name	Evo2 MSE.30210.LCV
Movement Type	Swiss Quartz
Case Material	Stainless Steel
Case Diameter	30 Millimeters
Case Thickness	9 Millimeters
Crystal Type	Sapphire Crystal
Band Material	Vegan Grape Leather
Band Color	Red
Band Width	24 Millimeters
Clasp Type	Buckle
Water Resistance Depth	30 Meters (3 ATM)
Display Type	Analog
Item Weight	0.21 Kilograms (approx. 7.41 ounces)

WARRANTY INFORMATION

Mondaine watches typically come with a manufacturer's warranty covering defects in materials and workmanship under normal use. The specific terms and duration of the warranty may vary by region and purchase date. Please refer to the warranty card included with your watch or visit the official Mondaine website for detailed warranty information and registration procedures.

The warranty generally does not cover:

- Normal wear and tear of the case, crystal, or strap.
- Damage resulting from improper handling, lack of care, accidents, or unauthorized repairs.
- Battery life.

CUSTOMER SUPPORT

For further assistance, service, or inquiries regarding your Mondaine Evo2 MSE.30210.LCV watch, please contact Mondaine customer support or an authorized service center.

You can typically find contact information on the official Mondaine website or through the retailer where you purchased the watch. When contacting support, please have your watch model number (MSE.30210.LCV) and purchase details readily available.

