

[Manuals.plus](#) /

> [Gizoon](#) /

> Gizoon 64" Kitchen Pantry Cabinet Instruction Manual (Model AP31)

Gizoon AP31

Gizoon 64" Kitchen Pantry Cabinet Instruction Manual

Model: AP31

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Gizoon 64-inch Kitchen Pantry Cabinet. Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation. Retain this manual for future reference.

SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always use the anti-tip devices provided with the cabinet to prevent tipping. Ensure the cabinet is securely mounted to the wall or placed on a stable, level surface.
- Do not overload the cabinet, as it may cause instability.
- Always follow the assembly instructions carefully to ensure the cabinet's stability and safety.
- Keep small parts and packaging materials away from children during assembly.



Image: Anti-toppling device for securing the cabinet.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts and hardware are present. If any items are missing or damaged, please contact customer support.

- Cabinet Panels (MDF, various sizes)
- Acrylic Glass Doors (for upper section)
- Adjustable Shelves
- Hardware Pack (screws, pins, hinges, magnetic door snaps, anti-tip devices)
- Assembly Instructions Manual
- Screwdriver (basic assembly tool)

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward. Each part and piece of hardware is labeled for easy identification. An adequate workspace is recommended. Wearing gloves during assembly can help prevent injury.



Image: Reviewing assembly instructions.

General Assembly Steps:

1. **Unpack and Verify:** Carefully unpack all components and compare them against the parts list in the included assembly guide. Ensure all screws and pins are coded and boards are numbered.
2. **Assemble Base:** Follow the step-by-step diagrams to construct the base of the cabinet.
3. **Attach Side Panels:** Secure the side panels to the base using the designated hardware.
4. **Install Shelves:** Insert fixed shelves and position adjustable shelves into the pre-drilled holes as desired.
5. **Attach Doors:** Install hinges and attach all doors, ensuring they open and close smoothly. The cabinet features stainless steel hinges and magnetic door snaps for secure closure.
6. **Install Anti-Tip Device:** For safety, securely attach the anti-tip device to the top rear of the cabinet and to a wall stud, following the specific instructions provided in the assembly guide.
7. **Final Checks:** Ensure all connections are tight and the cabinet is stable.

Recommended Assembly Team: 1-2 people

Average Assembly Time: 1-2 hours (time may vary based on experience)



Image: Stainless steel hinge detail.



Image: Magnetic door snap detail.

OPERATING INSTRUCTIONS

The Gizoon Kitchen Pantry Cabinet is designed for versatile storage in various rooms.

Adjustable Shelves:

The cabinet includes seven shelves in total, with three being adjustable. Utilize the pre-drilled holes on the interior sides of the cabinet to customize shelf heights. This allows for flexible storage options to accommodate items of various sizes, maximizing vertical space.

Adjustable Storage Spaces

Adjustable shelves allow you to place items of various sizes



Image: Adjustable shelf mechanism.

Storage Capacity:

The cabinet features two double-door cabinets with a total of 10 compartments. These are suitable for organizing drinks, canned goods, spices, and utensils. Additionally, four side-door storage racks provide dedicated space for items like wine bottles and condiments, keeping frequently used items easily accessible.



Image: Cabinet interior with various items stored.

Versatile Storage Options



Image: Versatile storage options.

MAINTENANCE

Proper care will ensure the longevity and appearance of your cabinet.

- **Cleaning:** The cabinet is finished with smooth white paint, making it resistant to scratches and easy to clean. Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Promptly clean any spills to prevent staining or damage to the wood.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Anti-Tip Device:** Regularly inspect the anti-tip device to confirm it is securely attached to both the cabinet and the wall.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Loose connections; uneven floor; anti-tip device not installed.	Ensure all screws are tightened. Place cabinet on a level surface. Install the anti-tip device as per instructions.
Doors do not close properly or are misaligned.	Hinges are loose or improperly installed; magnetic snaps misaligned.	Check hinge alignment and tighten screws. Adjust magnetic snaps if necessary.
Missing parts or damaged components upon arrival.	Shipping damage or packaging error.	Do not proceed with assembly. Contact Gizoon customer support immediately for assistance.

SPECIFICATIONS



Image: Product Dimensions.

Feature	Detail
Brand	Gizoon
Model Name	Kitchen Pantry Cabinet (AP31)
Color	White
Product Dimensions (D x W x H)	15.8" x 23.6" x 63.8"
Item Weight	69 Pounds
Material	Engineered Wood (Frame, Back), MDF and Acrylic Glass (Top Material)
Finish Type	Painted
Number of Shelves	7 (3 adjustable)
Number of Compartments	10
Weight Limit	100 Pounds
Special Features	Adjustable Shelf, Anti-tipping Device, Large Storage Space, Waterproof
Mounting Type	Floor Mount
Installation Type	Freestanding
Assembly Required	Yes
Recommended Uses	Tableware, Kitchen, Living Room, Dining Room, Bathroom, Home Office

WARRANTY INFORMATION

Gizoon products are manufactured with quality and durability in mind. For specific warranty details regarding your Gizoon 64" Kitchen Pantry Cabinet (Model AP31), please refer to the product packaging or contact Gizoon customer support directly. Warranty terms typically cover manufacturing defects under normal use.

CUSTOMER SUPPORT

Should you have any questions, require assistance with assembly, or need to report missing or damaged parts, please contact Gizoon customer support. Our team is available to provide professional and friendly service to ensure a positive experience with your product.

Please have your model number (AP31) and purchase information ready when contacting support.