

[Manuals.plus](#) /

› [Bnegynng](#) /

› Bnegynng YQ10S 10-inch Android 14 Tablet User Manual

Bnegynng YQ10S

Bnegynng YQ10S 10-inch Android 14 Tablet User Manual

Model: YQ10S

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Bnegynng YQ10S 10-inch Android 14 Tablet. Please read this manual thoroughly to ensure proper use and to maximize your device's performance and longevity.

WHAT'S IN THE BOX

Upon opening your Bnegynng YQ10S tablet package, you should find the following items:

- Bnegynng YQ10S 10-inch Android 14 Tablet
- Wireless Keyboard
- Wireless Mouse
- Foldable Protective Case
- Stylus
- Type-C Cable



The Bnogyng YQ10S tablet shown with its included accessories: a detachable keyboard, wireless mouse, stylus, and protective case.

PRODUCT OVERVIEW

Familiarize yourself with the physical components and ports of your Bnogyng YQ10S tablet.

6000mAh Large Battery Capacity



A detailed view of the tablet's physical features, including the 2MP front camera, 8MP rear camera, Type-C charging port, TF (microSD) card slot, volume controls, power button, and speaker locations.

- **Front Camera:** 2.0 Megapixels, suitable for video calls.
- **Rear Camera:** 8.0 Megapixels, for capturing photos and videos.
- **Type-C Port:** Used for charging the tablet and data transfer.
- **TF Card Slot:** For expanding storage with a microSD card (up to 1024GB).
- **Volume Buttons:** Adjust the audio output level.
- **Power Button:** Turns the tablet on/off or puts it to sleep/wakes it up.
- **Speakers:** Provide audio output.

SETUP

1. Initial Power On and Charging

1. Before first use, fully charge the tablet using the provided Type-C cable and a compatible power adapter.

2. Press and hold the **Power Button** until the Bneginng logo appears on the screen.
3. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account login.

2. Connecting Accessories (Keyboard and Mouse)

The included wireless keyboard and mouse connect via Bluetooth.



A visual guide demonstrating the process of pairing the Bluetooth keyboard with the tablet, including sliding the power switch, pressing the connect button, and selecting the device in settings.

Keyboard Pairing:

1. Ensure the keyboard is charged. Slide the power switch on the keyboard to the **ON** position.
2. Press the **"Connect"** button on the keyboard. The Bluetooth indicator light will flash.
3. On your tablet, go to **Settings > Connected devices > Bluetooth**.
4. Turn on Bluetooth. The tablet will search for available devices.
5. Select the keyboard (e.g., "Bluetooth Keyboard") from the list of available devices to pair.

Mouse Pairing:

1. Ensure the mouse has fresh batteries and is powered on.
2. Follow similar steps as the keyboard pairing: go to **Settings > Connected devices > Bluetooth** on your tablet.
3. Select the mouse from the list of available devices to pair.

3. Wi-Fi Connection

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle Wi-Fi to **On**.
3. Select your desired Wi-Fi network from the list.
4. Enter the network password if prompted, then tap **Connect**.

OPERATING THE TABLET

1. Basic Navigation

- **Touch Gestures:** Use taps, swipes, and pinch-to-zoom for interacting with the screen.
- **Home Screen:** Access your apps and widgets. Swipe left/right to navigate between screens.
- **Notifications:** Swipe down from the top of the screen to view notifications and quick settings.
- **Multitasking:** Swipe up from the bottom and hold, or tap the square icon (if available) to view recent apps.

2. Android 14 Operating System

Your tablet runs on the Android 14 operating system, offering enhanced privacy controls, improved security features, and a more responsive user experience. Explore the settings menu to customize your tablet's behavior and appearance.

Enough Memory For Daily Use

The tablet is powered by the Allwinner quad-core processor, which makes applications responsive on the tablet.



8 GB RAM

64GB ROM

1024GB Expandable

Android 14

Wi-Fi

The tablet is powered by an Allwinner quad-core processor, ensuring responsive application performance for daily use.

3. Camera Usage

The tablet features a 2MP front camera and an 8MP rear camera. Open the Camera app to capture photos and videos.

Tap the screen to focus and use the on-screen controls to switch between modes or adjust settings.

4. Storage Expansion

The tablet comes with 64GB of internal storage. To expand storage, insert a microSD card (TF card) into the designated slot. The tablet supports up to 1024GB of external storage. This allows for more space for apps, photos, videos, and documents.

Upgraded Large Storage Capacity

8GB RAM	64GB ROM	1024GB Expandable to
-------------------	--------------------	--------------------------------

An illustration of the tablet's memory specifications, highlighting 8GB RAM, 64GB internal storage, and support for up to 1024GB expandable storage via a microSD card.

5. Battery Management

The Bnegynng YQ10S is equipped with a 6000mAh battery, providing approximately 8-10 hours of mixed usage. To optimize battery life:

- Reduce screen brightness.
- Turn off Wi-Fi and Bluetooth when not in use.
- Close unused applications running in the background.
- Enable battery saver mode in settings.



A user interacting with the tablet using a stylus, with the screen displaying video content, highlighting the device's 6000mAh battery for extended use.

MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid abrasive cleaners or solvents.
- **Software Updates:** Regularly check for system updates in **Settings > System > System update** to ensure optimal performance and security.
- **Storage Management:** Periodically clear cache, uninstall unused apps, and transfer large files to external storage to maintain sufficient free space.
- **Environmental Conditions:** Avoid exposing the tablet to extreme temperatures, direct sunlight, or high humidity.

TROUBLESHOOTING

If you encounter issues with your tablet, refer to the following common solutions:

Issue	Solution
Tablet does not power on	Ensure the tablet is fully charged. Press and hold the power button for 10-15 seconds to perform a forced restart.
Slow performance	Close unused apps, clear cache, free up storage space, or restart the tablet.
Wi-Fi connectivity issues	Restart your Wi-Fi router and the tablet. Forget the network and reconnect. Ensure you are within range.
Bluetooth accessories disconnect	Ensure accessories are charged. Re-pair the device via Bluetooth settings. Keep accessories within close range of the tablet.
Screen flickering	Restart the tablet. Check for system updates. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Name	YQ10S
Operating System	Android 14
Screen Size	10.1 Inches
Screen Resolution	1280 x 800 Pixels (HD IPS)
Processor	Quad Core 2 GHz
RAM	8GB (2GB+6GB)
Internal Storage (ROM)	64GB
Expandable Storage	Up to 1024GB via MicroSD (TF) card (card not included)
Rear Camera	8 MP
Front Camera	2 MP
Battery Capacity	6000mAh
Average Battery Life	8-10 Hours
Wireless Connectivity	Wi-Fi (802.11b/g/n), Bluetooth
Dimensions (LxWxH)	6.95 x 3.98 x 0.98 inches
Item Weight	2.72 pounds

1280*800 IPS HD resolution

The 1280*800 IPS screen is adopted, which has a faster response speed than the traditional IPS screen.



The tablet's 1280x800 IPS HD screen resolution provides clear and vibrant visuals.

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the retailer. For technical support or further assistance, please visit the official Bnogyng website or contact their customer service department.

Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question