Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Smoby 7600420304

Smoby Modulo Space Desk (Model 7600420304) Instruction Manual

Your guide to assembly, operation, and maintenance.

1. Introduction

Thank you for choosing the Smoby Modulo Space Desk. This versatile and evolutive desk is designed to support your child's creativity and learning from the age of 3 years. It easily transforms between a flat desk and an easel, offering both a whiteboard and a blackboard surface. Crafted from solid beech wood and durable plastic, it is designed for easy assembly and convenient storage.



Image: Two children enjoying the Smoby Modulo Space Desk. One child stands, drawing on the whiteboard surface, while another child sits on the integrated bench, engaging with the desk. The desk is set up as an easel, showcasing its dual functionality.

2. Safety Information

- **Age Recommendation:** This product is suitable for children aged 3 years and older.
- **Adult Supervision:** Always supervise young children during use.
- **Assembly:** Ensure all parts are correctly assembled and securely fastened before allowing a child to use the desk.
- **Stability:** Place the desk on a flat, stable surface to prevent tipping.
- **Small Parts:** The accessory set contains small magnetic letters and numbers. Keep these away from very young children who may put objects in their mouths.
- **Cleaning:** Use only recommended cleaning methods to avoid damage to materials.

3. Package Contents

Please check the package to ensure all components are present:

- 1 x Smoby Modulo Space Desk (main structure with double-sided board and integrated bench)
- 1 x Erasable Felt-Tip Pen
- 6 x Colored Chalks
- 72 x Magnetic Letters and Numbers
- 1 x Cleaning Sponge (cloth)



Image: A detailed close-up of the 80 included accessories for the Smoby Modulo Space Desk. This image features colorful magnetic letters and numbers, a set of chalks, an erasable felt-tip pen, and a cleaning sponge, all essential for creative play and learning.

4. Setup and Assembly

The Smoby Modulo Space Desk is designed for minimal assembly, requiring no tools. Follow these steps:

1. Unpack all components from the box and verify against the package contents list.
2. Identify the main desk frame, the double-sided board, and the integrated bench.
3. Connect the main structural elements as indicated by the intuitive design. The desk features a tool-free assembly mechanism.
4. Ensure all connections are firm and secure before use.

Folding and Unfolding: The desk can be folded for compact storage in approximately 5 seconds without tools. Refer to the structural joints for the folding mechanism.



Image: The Smoby Modulo Space Desk is shown in its flat desk configuration, ready for drawing or writing. Icons highlight features like simplified assembly and its European manufacturing origin.

5. Operating Instructions

5.1 Desk Mode

- To use as a flat desk, position the double-sided board horizontally.
- Children can sit on the integrated bench to draw, write, or play with the magnetic letters and numbers on the desk surface.
- The desk surface is suitable for various creative activities.

5.2 Easel Mode (Whiteboard & Blackboard)

- To convert to an easel, adjust the double-sided board to a vertical position.
- **Whiteboard Side:** Use the erasable felt-tip pen for drawing and writing. Magnetic letters and numbers can also be used on this surface. Wipe clean with the provided sponge or a dry cloth.
- **Blackboard Side:** Use the colored chalks for drawing and writing. Wipe clean with the provided sponge or a slightly damp cloth.



Image: A young child is seated comfortably at the Smoby Modulo Space Desk, actively engaged in drawing on the blackboard surface with chalk. This demonstrates the desk's functionality as an easel with a traditional blackboard option.

5.3 Using Accessories

- **Magnetic Letters & Numbers:** Place these on the whiteboard surface for learning the alphabet and basic arithmetic.
- **Felt-Tip Pen:** Use only on the whiteboard surface. Recap after use to prevent drying.
- **Chalks:** Use only on the blackboard surface.
- **Sponge:** Use to erase markings from both whiteboard and blackboard surfaces.

6. Maintenance and Care

- **Cleaning Surfaces:** Wipe the desk surfaces (wood and plastic) with a dry or slightly damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Board Cleaning:** For the whiteboard, use the provided sponge or a soft, dry cloth. For the blackboard, use the sponge, which can be slightly dampened for stubborn marks.
- **Storage:** When not in use, the desk can be folded for compact storage. Store in a dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check all connections and components for wear or damage. Replace any damaged parts immediately.

7. Troubleshooting

Problem	Possible Cause	Solution
Desk feels wobbly after assembly.	Connections not fully secured.	Ensure all interlocking parts are firmly clicked into place. Check that the desk is on a flat surface.
Marks not erasing completely from whiteboard.	Incorrect pen used, or pen has dried.	Ensure only the provided erasable felt-tip pen (or similar whiteboard markers) is used. Try a slightly damp cloth for stubborn marks, then dry.
Chalk marks difficult to erase from blackboard.	Excessive pressure or old chalk residue.	Use the provided sponge, slightly dampened if necessary. Wipe gently and dry thoroughly.

8. Specifications

Model Name:	Modulo Space
Model Number:	7600420304
Brand:	Smoby
Dimensions (L x W x H):	64 cm x 60 cm x 102 cm (Easel Mode)
Item Weight:	6.125 kg (6125 Grams)
Materials:	Solid Beech Wood, Plastic
Color:	Multicolor
Age Recommendation:	From 3 years

Assembly Required:	Minimal, No Tools Needed
Country of Origin:	France




Image: A technical line drawing illustrating the overall dimensions of the Smoby Modulo Space Desk. The diagram indicates a height of 102 cm, a depth of 60 cm, and a width of 64 cm, providing a clear understanding of its physical footprint.

9. Warranty and Support

Warranty: This Smoby product comes with a 2-year manufacturer's warranty from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for any warranty claims.
Customer Support: For any questions, missing parts, or issues not covered in this manual, please contact Smoby customer service or your retailer. Visit the official Smoby website for contact information and further assistance: www.smoby.com

© 2024 Smoby. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C7W947XC

More documents and user manuals: **https://manuals.plus/**