

[Manuals.plus](#) /

> [Sojag](#) /

> Sojag Roma 8 ft. x 8 ft. Gazebo Instruction Manual

## Sojag 500-9161618

# Sojag Roma 8 ft. x 8 ft. Gazebo Instruction Manual

MODEL: 500-9161618

## Important Safety Information

Please read this entire instruction manual carefully before assembly or operation and retain for future reference. Always follow the illustrated instructions for assembly and disassembly.

- Secure the gazebo to a stable foundation to prevent it from tipping over in windy conditions.
- Keep children and pets away from the gazebo during assembly and disassembly.
- Do not use the gazebo in windy or stormy conditions.
- Check screws, nuts, and bolts periodically (or every 6 months). Tighten if required.

## Package Contents

Ensure all parts are present before beginning assembly. Refer to the diagram below for identification.



Figure 1: Assembled Sojag Roma 8 ft. x 8 ft. Gazebo with curtains and netting tied back.

**Table 1: Parts List**

Part No.	Quantity	Description
#1	4 pcs	Left up screen
#2	4 pcs	Left down screen
#3	4 pcs	Right up screen
#4	4 pcs	Right down screen
#5	4 pcs	Left beam
#6	4 pcs	Right beam
#7	4 pcs	Top Up tube
#8	4 pcs	Top Down tube

Part No.	Quantity	Description
#9	1 pc	Roof Connector
#10	1 pc	Fabric Cover
#11	1 pc	Netting
#12	8 pcs	Stake Kit
#13	48 pcs	Hook
#14	8 pcs	Finial

Figure 2: Detailed view of all parts included in the package.

## Setup: Assembly Instructions

Assembly requires at least two adults. Follow these steps carefully for proper setup.

### Step 1: Post Assembly

Connect the Left Up Screen (#1) to the Left Down Screen (#2) and the Right Up Screen (#3) to the Right Down Screen (#4) to form the four main posts of the gazebo. Ensure the parts align correctly and secure them as shown in the diagram.



Figure 3: Assembling the vertical posts (Parts 1, 2, 3, 4).

### Step 2: Beam Assembly

Attach the Left Beams (#5) and Right Beams (#6) to the top of the assembled posts. These beams will form the

upper perimeter of the gazebo frame. Ensure all connections are secure.



Figure 4: Connecting horizontal beams (Parts 5, 6) to the posts.

### **Step 3: Top Tube Assembly**

Assemble the Top Up Tubes (#7) and Top Down Tubes (#8) and connect them to the Roof Connector (#9). This forms the central roof structure. Then, attach this assembly to the main frame, ensuring all connections are firm. Finally, secure the Finials (#14) to the top of the posts for decorative and structural completion.



Figure 5: Assembling the roof tubes (Parts 7, 8) with the roof connector (Part 9) and attaching finials (Part 14).

#### **Step 4: Canopy and Netting Assembly**

Drape the Fabric Cover (#10) over the assembled roof frame. Ensure it is centered and evenly distributed. Secure the fabric cover to the frame using the provided hooks (#13) and any integrated fasteners. Next, attach the Netting (#11) around the perimeter of the gazebo, hanging it from the upper truss sections. Ensure the netting is properly aligned and can be zipped closed for full enclosure.

# I ROMA 8x8




Figure 6: Attaching the fabric cover (Part 10) and netting (Part 11).

## Step 5: Securing the Gazebo

Once the gazebo is fully assembled, use the Stake Kit (#12) to secure the base of each post to the ground. This is crucial for stability, especially in moderate wind conditions. For additional security, consider anchoring the gazebo to a deck or concrete slab if available.



Figure 7: The fully assembled and secured Sojag Roma Gazebo.

## Assembly Video Guide

For a visual guide on setting up a similar gazebo, please refer to the video below. While the model may vary slightly, the general assembly principles apply.

Your browser does not support the video tag.

Video 1: Assembly guide for a similar 8 ft. x 8 ft. gazebo. This video demonstrates the general steps for setting up the frame, attaching the canopy, and installing the mosquito netting.

## Operating Instructions

The Sojag Roma Gazebo is designed for versatile outdoor use, offering shade and protection from insects.

- **Mosquito Netting:** The gazebo is equipped with nylon mosquito net curtains. These can be zipped closed to provide full enclosure and protection from insects.
- **Curtains:** The tasteful polyester curtains can be drawn for privacy or tied back to allow for an open-air feel.
- **Ventilation:** The design allows for proper ventilation even when the netting is closed.

Your browser does not support the video tag.

Video 2: Demonstration of mosquito netting and curtain usage. This video illustrates how to close and tie back the netting and curtains for various outdoor conditions.

## Maintenance

Regular maintenance will extend the life and appearance of your gazebo.

- **Cleaning:** Clean the polyester roof and curtains with mild soap and water. Rinse thoroughly and allow to air dry completely before storage.

- **Frame Care:** The powder-coated aluminum frame is rustproof and requires minimal maintenance. Wipe down with a damp cloth as needed. Avoid abrasive cleaners.
- **Fastener Checks:** Periodically inspect all screws, nuts, and bolts. Tighten any loose fasteners to maintain structural integrity.
- **Winter Storage:** In regions with heavy snow or strong winds, it is recommended to disassemble and store the gazebo indoors during the off-season to prevent damage.

## Troubleshooting

If you encounter issues with your Sojag Roma Gazebo, refer to the following common solutions:

Problem	Possible Cause	Solution
Gazebo is unstable or wobbly.	Loose fasteners or inadequate anchoring.	Ensure all bolts and screws are tightened. Verify that the gazebo is properly staked to the ground or anchored to a solid surface. Do not use in high winds.
Water pooling on the canopy.	Improper canopy installation or heavy rainfall.	Ensure the canopy is stretched taut and correctly positioned on the frame. Clear any accumulated water promptly to prevent damage.
Mosquito netting does not close completely.	Netting is not properly aligned or snagged.	Check that the netting is correctly hung from all attachment points and that zippers are free from obstructions.
Missing or damaged parts.	Manufacturing defect or shipping damage.	Contact customer support with your model number and a description of the missing/damaged part.

## Specifications

Feature	Detail
Product Dimensions	2.5L x 2.5W x 2.61H Meters (8 ft. x 8 ft. x 8.5 ft.)
Item Weight	29 kg (63.93 Pounds)
Frame Material	Aluminum (Powder-coated)
Canopy Material	Polyester (Wrinkle and water resistant)
Netting Material	Nylon
Color	Charcoal
Assembly Required	Yes
Water Resistance Level	Water Resistant

## Warranty Information

This Sojag Roma Gazebo comes with a **1 Year Limited Manufacturer Warranty**. Please retain your proof of purchase for any warranty claims. The warranty covers manufacturing defects under normal use and conditions.

## Customer Support

For further assistance, missing parts, or warranty inquiries, please contact Sojag customer support. Have your model number (500-9161618) and proof of purchase ready when contacting support.

You can typically find contact information on the manufacturer's official website or through your retailer.