Tatybo WT01

Tatybo WT01 Gaming Headset User Manual

Model: WT01 | Brand: Tatybo

Introduction

Thank you for choosing the Tatybo WT01 Gaming Headset. This manual provides detailed instructions for setting up, operating, and maintaining your headset to ensure optimal performance and longevity. Please read this manual carefully before using the product.
The Tatybo WT01 Gaming Headset offers an immersive audio experience with its advanced features:

- **3D Surround Sound:** Experience rich, directional audio for an immersive gaming environment.
- **Noise-cancelling Microphone:** Ensures clear communication by reducing ambient noise.
- **Wide Compatibility:** Designed to work with almost all gaming consoles and devices.
- **Professional Comfort:** Ergonomically designed for extended wear during long gaming sessions.



Figure 1: Tatybo WT01 Gaming Headset with included USB and USB-C wireless adapters.

Setup Guide

The Tatybo WT01 headset offers multiple connection options for wide compatibility.

Wireless Connection (2.4GHz USB/USB-C Dongle)

For PC, PS4, PS5, and Nintendo Switch (docked mode):

1. Identify the appropriate wireless dongle (USB-A or USB-C) for your device.
2. Plug the 2.4GHz wireless dongle into an available USB or USB-C port on your gaming console or PC.
3. Turn on the Tatybo WT01 headset. It should automatically pair with the dongle. The LED indicator on the headset will confirm connection.
4. Adjust audio settings on your device to ensure the headset is selected as the primary audio output and input device.



Figure 2: The 2.4GHz wireless dongles (USB-A and USB-C) provide ultra-low latency and a transmission distance of up to 10 meters.

Bluetooth Connection (BT5.3)

For mobile phones, tablets, and Nintendo Switch (handheld mode, microphone not supported via Bluetooth on Switch):

1. Ensure the headset is powered on.
2. Activate Bluetooth pairing mode on the headset (refer to Operating section for button functions).
3. On your device, go to Bluetooth settings and search for "Tatybo WT01".
4. Select the headset to pair. Once connected, the headset's LED indicator will change.

Wired Connection (3.5mm Jack)

For Xbox Series devices and other devices with a 3.5mm audio jack:

1. Connect one end of the included 3.5mm audio cable to the headset's 3.5mm port.
2. Connect the other end of the 3.5mm audio cable to the audio jack on your controller or device.
3. No power is required for wired mode, but some features like LED lighting may be limited.



Figure 3: The Tatybo WT01 headset supports four connection types for broad compatibility across various gaming platforms and mobile devices.

Operating Instructions

Power On/Off

Press and hold the Power button (usually located on the earcup) for 3 seconds to turn the headset on or off.

Volume Control

Use the volume roller or buttons on the earcup to adjust the audio volume up or down.

Microphone Usage

The headset features a detachable, 360° adjustable ENC (Environmental Noise Cancellation) microphone.

- **Attaching/Detaching:** Align the microphone jack with the port on the left earcup and push firmly until it clicks into place. To remove, gently pull it out.
- **Mute Function:** Use the dedicated microphone mute button on the earcup to toggle the microphone on or off.
- **Noise Cancellation:** The ENC microphone is designed to reduce up to 95% of ambient noise, ensuring clear voice calls.



Figure 4: The 360° adjustable ENC microphone provides crystal clear voice communication by reducing ambient noise by up to 95%.

Sound Features

The Tatybo WT01 headset is equipped with 50mm drivers and supports 7.1 Pro Surround Sound for an immersive audio experience.

- **7.1 Pro Surround Sound:** Provides 360° stereo audio, allowing you to pinpoint footsteps and distant gunshots in games.
- **50mm Drivers:** Deliver powerful audio with extended bass and clear treble, enhanced by the latest AAC codec.



Figure 5: Experience immersive 7.1 Pro Surround Sound and pinpoint audio cues with the 50mm drive units.

Charging and Battery Life

The headset has a built-in 1000mAh lithium-ion battery.

- **Charging Time:** Approximately 3 hours for a full charge.
- **Playtime:** Over 40 hours with LED lights off, approximately 22 hours with LED lights on.
- **Charging Indicator:** The LED indicator will show charging status and turn off when fully charged.



Figure 6: The 1000mAh battery provides long-lasting power, with over 40 hours of playtime when LED lights are off.

Comfort and Design

The Tatybo WT01 is designed for extended comfort during long gaming sessions.

- **Earcup Material:** Protein-based material for soft, breathable earcups.
- **Adjustable Headband:** Ensures a secure and comfortable fit for various head sizes.



Figure 7: The headset features friendly and breathable earcups for professional comfort during prolonged use.

Maintenance

To ensure the longevity and optimal performance of your Tatybo WT01 Gaming Headset, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the headset. For earcups, a slightly damp cloth can be used, but ensure no moisture enters the speaker grilles or ports.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on top of the headset.
- **Cable Care:** Avoid sharp bends or kinks in the cables. Disconnect cables by pulling the plug, not the cord.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge the headset regularly, even if not in use for extended periods.

Troubleshooting

If you encounter issues with your Tatybo WT01 Gaming Headset, please refer to the following common solutions:

Problem	Possible Cause	Solution
No sound from headset	Headset not powered on; Volume too low; Incorrect audio output selected; Dongle not connected or paired.	Ensure headset is charged and powered on. Increase volume. Check device's audio settings to select "Tatybo WT01" as output. Re-plug dongle or re-pair Bluetooth.
Microphone not working	Microphone muted; Incorrect audio input selected; Microphone not fully inserted.	Unmute microphone. Check device's audio settings to select "Tatybo WT01" as input. Ensure microphone is securely attached.
Poor sound quality / Static	Interference (wireless); Low battery; Loose connection.	Move closer to the wireless dongle. Charge the headset fully. Ensure all connections (dongle, 3.5mm cable) are secure.
Headset not pairing (Wireless/Bluetooth)	Out of range; Pairing mode not activated; Interference.	Ensure headset is within range of the dongle/device. Activate pairing mode on headset. Try pairing in a different location to avoid interference.

If the problem persists, please contact customer support.

Specifications

Feature	Detail
Model Number	WT01
Brand	Tatybo
Connectivity Technology	Wireless (2.4GHz, Bluetooth 5.3), Wired (3.5mm Jack)
Compatible Devices	PS4, PS5, PC, Nintendo Switch, Mobile Phones, Tablets, Xbox Series (wired)
Audio Features	7.1 Pro Surround Sound, 50mm Drivers, 20 Hz - 20,000 Hz Frequency Range
Microphone	360° Adjustable ENC (Environmental Noise Cancellation)
Battery Type	Lithium-ion (1 included)
Battery Capacity	1000mAh
Charging Time	Approximately 3 hours
Playtime	40+ hours (LED off), ~22 hours (LED on)
Material	Protein-based material (earcups), unknown (headband and body)
Weight	520 Grams
Color	Black
Control Type	Touch Control

Feature	Detail
Water Resistance Level	Not waterproof

Warranty and Support

Tatybo offers a 3-year warranty for this product, as mentioned in customer reviews. For warranty claims, technical support, or any inquiries regarding your Tatybo WT01 Gaming Headset, please contact Tatybo customer service through the retailer where you purchased the product or visit the official Tatybo website for contact information.
Please retain your proof of purchase for warranty purposes.

© 2024 Tatybo. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question