Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY QYSY-MBE790-QYSY

ALLIMITY Air Conditioner Remote Control User Manual

Brand: ALLIMITY | **Model:** QYSY-MBE790-QYSY

1. Introduction

This user manual provides detailed instructions for the ALLIMITY YL-HD01, YL-HD04, YL-HD06 series compatible remote control for various air conditioning units. This remote control is designed to cover all functions of your original remote without requiring any programming. Simply insert batteries, and it is ready for use.
It is compatible with a wide range of models, including but not limited to: AS50TDBHRA, AS68TEBHRA, AS25TACHRA, AS35TACHRA, AS20TADHRA-2, AS25TADHRA-2, AS35TADHRA-2, AS25THMHRA-C, AS35TAMHRA-C, AS50TDMHRA-C, AS68TEMHRA-C, AS25TEDHRA(M1), AS09GB2HRA, AS12GB2HRA, AS18GD2HRA, AS24GF2HRA, AS09GN3ERA, AS12GN3ERA, AS18GN3ERA, AS25TAEHRA-THC, AS35TAEHRA-THC, AS50TDDHRA-THC, AS68TEDHRA-THC, HSU-09HEG03/R2(DB), HSU-12HEG03/R2(DB), HSU-18HEG03/R2(DB), HSU-24HEG03/R2(DB), HSU-09HEK03/R2(DB), HSU-12HEK03/R2(DB), HSU-18HEK03/R2(DB), HSU-24HEK03/R2(DB), AS35TB1HRA, AS26TB1HRA, AS26TB4HRA, 0010401511E, 0010401715B, ASO9TA2HRA, AS12TA2HRA, AS18TD2HRA, AS24TD2HRA, AS25TAAHRA, AS35TAAHRA, AS50TDAHRA, AS68TEAHRA, AS25TABHRA, AS35TABHRA.

2. Setup

2.1 Battery Installation

The remote control requires two AAA alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.








Figure 2.1: Battery compartment with batteries inserted. Ensure correct polarity.





Figure 2.2: Rear view of the remote control with the battery cover closed.

No programming is required. The remote control is ready for use immediately after battery installation.

3. Operating Instructions

Point the remote control directly at the air conditioning unit's receiver. Ensure there are no obstructions between the remote and the unit.





Figure 3.1: Front view of the remote control with button layout.

3.1 Button Functions

- **Power Button** (Pink, top right): Turns the air conditioning unit ON or OFF.
- **QUIET** (Green, top left): Activates or deactivates the quiet operation mode.
- **COOL** (Blue): Sets the air conditioning unit to cooling mode.
- **HEAT** (Orange): Sets the air conditioning unit to heating mode.
- **DRY** (Grey): Sets the air conditioning unit to dehumidification mode.
- **TEMP+** / **TEMP-**: Adjusts the temperature setting upwards or downwards.
- **AUTO**: Sets the air conditioning unit to automatic mode, where it selects the appropriate operation mode based on room temperature.
- **FAN**: Adjusts the fan speed. Press repeatedly to cycle through available fan speeds (e.g., Low, Medium, High, Auto).
- **SWING**: Controls the vertical or horizontal swing of the air deflector.
- **TIMER**: Sets the timer for automatic ON/OFF operations. Refer to your air conditioning unit's manual for specific timer programming details.
- **HEALTH**: Activates or deactivates health-related functions (e.g., air purification, ionizer), if supported by your AC

unit.

- **EXTRA FUNCTION**: Accesses additional functions. Specific functions may vary by AC model.
- **Confirm** / **Cancel**: Used to confirm settings or cancel operations, often in conjunction with timer or extra functions.
- **LOCK**: Locks the remote control buttons to prevent accidental changes. Press again to unlock.
- **LIGHT**: Turns the display backlight ON or OFF (if available).
- **RESET**: Resets the remote control to its factory default settings. Use a pointed object (like a paperclip) to press this recessed button.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's display becomes dim or the unit does not respond to commands. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

4.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the air conditioning unit's receiver.
  - Make sure you are within the effective operating range (up to 10 meters).
- **Display is dim or blank:**
  - Batteries are low. Replace them with new ones.
- **Remote functions are erratic:**
  - Try resetting the remote control by pressing the recessed RESET button with a pointed object.
  - Ensure no buttons are stuck or jammed.

6. Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	QYSY-MBE790-QYSY
Product Dimensions	4 x 12 x 0.3 cm
Product Weight	60 g
Battery Type	AAA Alkaline (not included)
Connectivity Technology	Infrared
Maximum Range	10 Meters
Special Feature	No programming required
Compatible Devices	AS26TB1HRA, AS35TB1HRA, AS26TB4HRA, and many other models listed in Section 1.

7. Warranty and Support

Specific warranty information for this product is not provided in the available data. For any issues, questions, or support regarding your ALLIMITY remote control, please contact the seller or manufacturer directly through your purchase platform.
Ensure you retain your proof of purchase for any warranty claims or support inquiries.

© 2023 ALLIMITY. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C812Y4Q9

More documents and user manuals: **https://manuals.plus/**